




Providing sustainable energy solutions worldwide

Installation- and maintenance instruction

B 55-2 FAME/RME

LMO24.255C2E

E 4N CK



-sv

1. Manualer på övriga språk

2. www.bentone.com\nedladdning eller scanna QR-koden.

3. Skriv in brännarens artikelnummer som finns på din typskylt (se bild) och välj ditt språk.

Detaljerad ecodesign information kan laddas ner på: www.bentone.com/ecodesign.

-en

1. Manuals in other languages

2. www.bentone.com\download or scan QR-code.

3. Enter the burner's article number on your data plate (see picture) and select language.

Detailed ecodesign information can be downloaded at: www.bentone.com/ecodesign.

-da

1. Manualer på andre sprog

2. www.bentone.com\download eller scan QR-koden.

3. Indtast brænderens artikelnummer, der findes på typeskiltet (se billede), og vælg dit sprog.

Detaljerede oplysninger om ecodesign kan downloades på: www.bentone.com/ecodesign.

-fr

1. Manuels dans d'autres langues

2. www.bentone.com\download ou scannez le code QR.

3. Saisir le numéro d'article du brûleur sur votre plaque signalétique (consultez l'illustration) et sélectionnez la langue.

Des informations détaillées sur l'ecodesign peuvent être téléchargées à l'adresse: www.bentone.com/ecodesign.

-de

1. Gebrauchsanweisungen in anderen Sprachen

2. www.bentone.com\download oder scannen Sie den QR-Code.

3. Geben Sie die Artikelnummer des Brenners auf Ihrem Typenschild ein, (siehe Bild) und wählen Sie die Sprache aus.

Detaillierte Informationen zum Ecodesign können unter www.bentone.com/ecodesign heruntergeladen werden.

Table of contents

| | | | |
|--|-----------|--|-----------|
| 1. General Information..... | 4 | 6. Pump E4NC-1069..... | 22 |
| 1.1 Delivery inspection..... | 4 | 6.1 Technical data | 22 |
| 1.2 Safety | 4 | 6.2 Components..... | 22 |
| 1.3 General requirements FAME/RME..... | 6 | 6.3 Oil connection..... | 22 |
| 2. Technical data..... | 7 | 6.4 Changing the filter | 22 |
| 2.1 Dimensions B 55-2..... | 7 | 6.5 Function | 23 |
| 2.2 Burner installation | 7 | 6.6 Preheating pump | 23 |
| 2.3 Working field | 8 | 7. Service | 24 |
| 2.4 Setting for nozzle assembly and air damper | 8 | 7.1 Burner Service Schedule, Oil | 24 |
| 2.5 Technical specification | 9 | 7.2 Component replacement intervals..... | 24 |
| 2.6 Setting of ignition electrodes and brake plate | 9 | 7.3 Combustion device | 25 |
| 2.7 Nozzle and pump pressure..... | 9 | 7.4 Air damper | 26 |
| 2.8 Nozzle table..... | 10 | 7.5 Replacement of damper motor, air | 27 |
| 2.9 Components..... | 12 | 7.6 Fan | 28 |
| 3. Electric equipment..... | 13 | 7.7 Replace oil pump | 29 |
| 3.1 Safety system | 13 | 7.8 Tightness check of solenoid valves | 30 |
| 3.2 Wiring diagram | 13 | 7.9 Replacement of electrical components..... | 31 |
| 3.3 Function | 14 | 7.10 Vibrations..... | 32 |
| 3.4 Colour codes | 15 | 8. Fault Location | 33 |
| 3.5 Fault codes | 15 | 8.1 Burner will not start..... | 33 |
| 4. Installation..... | 16 | 8.2 Burner will not start after normal use | 33 |
| 4.1 General instructions | 16 | 8.3 Delayed ignition | 34 |
| 4.2 Inspection and maintenance..... | 16 | 8.4 Noise in pump | 34 |
| 4.3 Start-up | 16 | 8.5 Pump pressure | 35 |
| 4.4 Preparing for installation..... | 16 | 9. Log of flue gas analysis | 36 |
| 4.5 Oil distribution | 16 | | |
| 4.6 Electrical connection | 17 | | |
| 4.7 Handling and lifting instruction | 18 | | |
| 5. Mounting | 19 | | |
| 5.1 Check oil line seals | 19 | | |
| 5.2 Example of Basic settings..... | 20 | | |
| 5.3 Settings Damper motor, 2-stage | 21 | | |

1. General Information

The burner may only be used for its intended purpose in accordance with the product's technical data.

We reserve the right to make design changes and cannot be held liable for any misprints or typographical errors.

Modifying the design or using accessories or components that have not been approved by Enertech in writing is strictly prohibited.

This Installation and Maintenance manual:

- is to be regarded as part of the burner and must always be kept near the installation site.
- must be read prior to installation.
- is intended for use by authorised personnel.

1.1 Delivery inspection

- Make sure everything is delivered and the goods have not been damaged during transit.
Transport damage must be reported to the shipping company.
- If something is wrong with a delivery, report it to the supplier.

1.2 Safety

- before installation:

- Installation and work on the burner and associated system components may only be carried out by persons who have undergone relevant training.
- The product is packaged to prevent damage from occurring when handled – Handle the product with care! Lifting equipment must be used to lift larger packages.
- The products must be transported/stored on a level surface in a dry environment, max. 80% relative humidity, no condensation.
Temperature -20 to +60 °C.



- installation:

- The burner must be installed in accordance with local regulations for fire safety, electrical safety, and fuel distribution.
- The premises must comply with local regulations pertaining to use of the burner, and must have adequate air supply.
- The installation site must be free of chemicals.
- Fire extinguisher with Class BE recommended.
- Make sure when installing the burner that there is enough space to service the burner.
- The electrical installation must be professionally carried out in accordance with current mains electricity regulations and in a professional manner.
- Make sure that the burner is suitable for the application (see Technical Data).
- All components must be installed without being bent, twisted or subjected to mechanical or thermal forces that affect components.

- Care must be taken by the installer to ensure that no electrical cables or fuel lines are pinched or otherwise damaged during installation or service.
- Flame tubes, fan wheels and air dampers, for example, may contain sharp edges.

- before first start:

- The burner must not be put into operation without proper safety and protection devices.
- Permitted ambient temperature during operation -10 to +60 °C. Max. 80% relative humidity, no condensation.
- The surface temperature of the burner's components may exceed 60 °C.
- Handle with caution – the burner has moving parts, and there is risk of crushing injuries.
- Seal inspections must be performed during installation and servicing to prevent leakage.
- fitting and installation work has been completed and approved.
- electrical installation has been correctly performed.
- flue gas ducts and combustion air ducts are not blocked.
- all actuators and control and safety devices are in working order and correctly set.
- If the boiler is equipped with an access hatch, this must be equipped with a hatch opening switch connected to the burner's safety system.
- When in operation, the burner's noise level can exceed 85 dBA – use hearing protection!



- Operation:

- Carry out all stipulated settings, service and inspection work within the set time.
- If the oil burner control has a solid red light, contact your installer.

1.3 General requirements FAME/RME

- The fuel must meet the requirements of standard EN 14214 for FAME.
- The fuel must be stored and used according to the manufacturer's instructions. It should typically be used within 6 months of manufacture. Fuel that is allowed to age loses its oxidation stability and produces aggressive constituents. These may cause oxidation damage to components in the oil system. The fuel should be stored in a cool and dark area.
- The RME tank must be made of metal or dark coloured plastics approved for the fuel.
- Burners fuelled by FAME (RME) are – and must be – equipped with parts designed for this fuel. This applies to oil-related parts such as the pump, solenoid valve, oil filter and hoses.
- Oil hoses must be of high-quality fluoride rubber or PTFE intended for FAME/RME, and the hoses must be fitted with fire-retardant sleeves in order to satisfy requirements according to EN-ISO 6806.
- The installation should be performed as a single-pipe system. Copper should be avoided the fuel system since the fuel and copper have an oxidising effect on each other.
- Annual cleaning and checking for the presence of water in the tank should be done to avoid corrosion and microorganisms.

2. Technical data


The burner is intended for:

- Operation in installations according to EN 303 and EN 267.
When operating with a hot air boiler, the LMO24.255 or LMO44.255 control unit must be used.

Fuels:

- FAME/RME according to EN 14214.
- Fuel oil according to DIN 51603-1.
- Fuel oil A Bio 10 according to DIN 51603-6.

2.1 Dimensions B 55-2



| A | Ø B | Ø C | D | E | F | G | H | *I |
|-------------|-----|-----|-----|-----|-----|-----|-----|-----|
| 274/374/474 | 159 | 155 | 606 | 321 | 123 | 269 | 307 | 200 |


* Min. recommended distance to floor.

2.2 Burner installation

2.2.1 Hole patten

Make sure the hole pattern on the boiler is designed for burner flange.

| d ₁ | d ₂ | d ₃ |
|----------------|----------------|-----------------|
| Ø (155) 165 | 14 | Ø (226) 254-300 |




165 205 86-4

2.3 Working field



! Do not exceed working field.

2.4 Setting for nozzle assembly and air damper



2.5 Technical specification

| B 55-2 | |
|--------------------------------------|----------------------------|
| Main supply, Operating ¹⁾ | 230V, 1~, 0.5A, 50Hz, IP20 |
| Main supply, Motor | 230/400V, 3.1/1.8A |
| Max fuse rating | 6.3A |
| NO _x -class | 3 |
| Noise level | 90dBA |


¹⁾ Motor excluded.

Measurements according to EN 15036-1:2006

Alt.1 The noise level of the burner can be reduced by equipping the burner with silencer. Installation must be done so it does not prevent air supply to the burner.

Alt.2 The burner's noise level can be reduced by connecting the burner's air intake to the air duct that opens into an appropriate location. Installation must be done so it does not prevent air supply to the burner.

2.6 Setting of ignition electrodes and brake plate



| a | b | c | d | e |
|---------|-----|---------|-----|---------|
| 2.5-3.0 | 2.0 | 6.5-7.0 | 2.0 | 6.0-7.0 |

! *NB It is important that the spark does not strike against the brake plate or nozzle.

2.7 Nozzle and pump pressure

Due to different furnace geometries and capacities, it is not possible to recommend a nozzle model.

| | |
|-----------------------|--|
| Nozzle: | 45° Solid/semisolid |
| | 60° Solid/semisolid |
| | 80° Solid/semisolid |
| Pump pressure: | 14 bar (14-21 bar) depending on pump model |

2.8 Nozzle table

| Pump pressure bar 14 | | | | 15 | | | 16 | | | 17 | | |
|----------------------|-------|------|--------|-------|------|--------|-------|------|--------|-------|------|--------|
| Gph | kg/h | kW | Mcal/h | kg/h | kW | Mcal/h | kg/h | kW | Mcal/h | kg/h | kW | Mcal/h |
| 1,00 | 4,40 | 52 | 45 | 4,56 | 54 | 46 | 4,71 | 56 | 48 | 4,85 | 57 | 49 |
| 1,10 | 4,84 | 57 | 49 | 5,01 | 59 | 51 | 5,18 | 61 | 53 | 5,34 | 63 | 54 |
| 1,20 | 5,29 | 63 | 54 | 5,47 | 65 | 56 | 5,65 | 67 | 58 | 5,82 | 69 | 59 |
| 1,25 | 5,51 | 65 | 56 | 5,70 | 68 | 58 | 5,89 | 70 | 60 | 6,07 | 72 | 62 |
| 1,35 | 5,95 | 70 | 61 | 6,15 | 73 | 63 | 6,36 | 75 | 65 | 6,55 | 78 | 67 |
| 1,50 | 6,60 | 78 | 67 | 6,83 | 81 | 70 | 7,06 | 84 | 72 | 7,27 | 86 | 74 |
| 1,65 | 7,27 | 86 | 74 | 7,52 | 89 | 77 | 7,77 | 92 | 79 | 8,01 | 95 | 82 |
| 1,75 | 7,71 | 91 | 79 | 7,97 | 95 | 81 | 8,24 | 98 | 84 | 8,49 | 101 | 87 |
| 2,00 | 8,81 | 104 | 90 | 9,12 | 108 | 93 | 9,42 | 112 | 96 | 9,71 | 115 | 99 |
| 2,25 | 9,91 | 118 | 101 | 10,26 | 122 | 105 | 10,60 | 126 | 108 | 10,92 | 130 | 111 |
| 2,50 | 11,01 | 131 | 112 | 11,39 | 135 | 116 | 11,77 | 140 | 120 | 12,13 | 144 | 124 |
| 2,75 | 12,11 | 144 | 123 | 12,53 | 149 | 128 | 12,95 | 154 | 132 | 13,35 | 158 | 136 |
| 3,00 | 13,21 | 157 | 135 | 13,67 | 162 | 139 | 14,13 | 168 | 144 | 14,56 | 173 | 148 |
| 3,50 | 15,42 | 183 | 157 | 15,95 | 189 | 163 | 16,49 | 196 | 168 | 16,99 | 201 | 173 |
| 4,00 | 17,62 | 209 | 180 | 18,23 | 216 | 186 | 18,84 | 223 | 192 | 19,42 | 230 | 198 |
| 4,50 | 19,82 | 235 | 202 | 20,51 | 243 | 209 | 21,20 | 251 | 216 | 21,84 | 259 | 223 |
| 5,00 | 22,03 | 261 | 225 | 22,79 | 270 | 232 | 23,55 | 279 | 240 | 24,27 | 288 | 247 |
| 5,50 | 24,23 | 287 | 247 | 25,07 | 297 | 256 | 25,91 | 307 | 264 | 26,70 | 317 | 272 |
| 6,00 | 26,43 | 313 | 270 | 27,49 | 326 | 280 | 28,27 | 335 | 288 | 29,13 | 345 | 297 |
| 6,50 | 28,63 | 340 | 292 | 29,63 | 351 | 302 | 30,62 | 363 | 312 | 31,55 | 374 | 322 |
| 7,00 | 30,84 | 366 | 314 | 31,91 | 378 | 325 | 32,98 | 391 | 336 | 33,98 | 403 | 374 |
| 7,50 | 33,04 | 392 | 337 | 34,19 | 405 | 349 | 35,33 | 419 | 360 | 36,41 | 432 | 371 |
| 8,00 | 35,25 | 418 | 359 | 36,47 | 433 | 372 | 37,69 | 447 | 384 | 38,80 | 460 | 396 |
| 8,50 | 37,45 | 444 | 382 | 38,74 | 459 | 395 | 40,04 | 475 | 408 | 41,26 | 489 | 421 |
| 9,00 | 39,65 | 470 | 404 | 41,02 | 486 | 418 | 42,40 | 503 | 432 | 43,69 | 518 | 446 |
| 9,50 | 41,85 | 496 | 427 | 43,30 | 514 | 442 | 44,75 | 531 | 456 | 46,11 | 547 | 470 |
| 10,00 | 44,06 | 523 | 449 | 45,58 | 541 | 465 | 47,11 | 559 | 480 | 47,11 | 559 | 480 |
| 11,00 | 48,46 | 575 | 494 | 50,14 | 595 | 511 | 51,82 | 615 | 528 | 53,40 | 633 | 545 |
| 12,00 | 52,87 | 627 | 539 | 54,70 | 648 | 558 | 56,53 | 670 | 576 | 58,25 | 691 | 594 |
| 14,00 | 62,68 | 732 | 629 | 63,81 | 757 | 651 | 65,95 | 778 | 669 | 67,96 | 806 | 693 |
| 16,00 | 70,49 | 836 | 719 | 72,93 | 865 | 744 | 75,38 | 894 | 769 | 77,67 | 921 | 792 |
| 18,00 | 79,30 | 940 | 809 | 82,05 | 973 | 837 | 84,80 | 1006 | 865 | 87,38 | 1036 | 891 |
| 20,00 | 88,11 | 1045 | 899 | 91,17 | 1081 | 930 | 94,22 | 1117 | 961 | 97,09 | 1151 | 990 |
| 22,00 | 96,92 | 1149 | 988 | 100 | 1189 | 1023 | 104 | 1229 | 1057 | 107 | 1267 | 1089 |
| 24,00 | 106 | 1254 | 1078 | 109 | 1297 | 1116 | 113 | 1341 | 1153 | 116 | 1382 | 1188 |
| 26,00 | 115 | 1359 | 1168 | 119 | 1406 | 1209 | 122 | 1453 | 1249 | 126 | 1497 | 1287 |

The table applies to oil with a viscosity of 4.4 mm²/s (cSt) at a density of 830 kg/m³.


RME energy content 10,4 kWh/kg.

| Pump pressure bar 18 | | | | 19 | | | 20 | | | 21 | | |
|----------------------|-------|-----|--------|-------|-----|--------|-------|-----|--------|-------|------|--------|
| Gph | kg/h | kW | Mcal/h | kg/h | kW | Mcal/h | kg/h | kW | Mcal/h | kg/h | kW | Mcal/h |
| 1,00 | 4,99 | 59 | 51 | 5,13 | 61 | 52 | 5,26 | 62 | 54 | 5,40 | 64 | 55 |
| 1,10 | 5,49 | 65 | 56 | 5,64 | 67 | 57 | 5,79 | 69 | 59 | 5,93 | 70 | 60 |
| 1,20 | 5,99 | 71 | 61 | 6,16 | 73 | 63 | 6,32 | 75 | 64 | 6,47 | 77 | 66 |
| 1,25 | 6,24 | 74 | 64 | 6,41 | 76 | 65 | 6,58 | 78, | 67 | 6,74 | 80 | 69 |
| 1,35 | 6,74 | 80 | 69 | 6,93 | 82 | 71 | 7,11 | 84 | 72 | 7,28 | 86 | 74 |
| 1,50 | 7,48 | 89 | 76 | 7,69 | 91 | 78 | 7,89 | 93 | 80 | 8,08 | 96 | 82 |
| 1,65 | 8,24 | 98 | 84 | 8,47 | 100 | 86 | 8,69 | 103 | 89 | 8,90 | 105 | 91 |
| 1,75 | 8,78 | 104 | 90 | 8,98 | 106 | 92 | 9,21 | 109 | 94 | 9,44 | 112 | 96 |
| 2,00 | 9,99 | 118 | 102 | 10,26 | 122 | 105 | 10,53 | 125 | 107 | 10,79 | 128 | 110 |
| 2,25 | 11,24 | 133 | 115 | 11,55 | 137 | 118 | 11,85 | 140 | 121 | 12,14 | 144 | 124 |
| 2,50 | 12,48 | 148 | 127 | 12,83 | 152 | 131 | 13,16 | 156 | 134 | 13,49 | 160 | 138 |
| 2,75 | 13,73 | 163 | 140 | 14,11 | 167 | 144 | 14,48 | 171 | 148 | 14,84 | 176 | 151 |
| 3,00 | 14,98 | 178 | 153 | 15,39 | 182 | 157 | 15,79 | 187 | 161 | 16,18 | 192 | 165 |
| 3,50 | 17,48 | 207 | 178 | 17,96 | 213 | 183 | 18,43 | 218 | 188 | 18,89 | 224 | 193 |
| 4,00 | 19,98 | 237 | 204 | 20,53 | 243 | 209 | 21,06 | 250 | 215 | 21,59 | 256 | 220 |
| 4,50 | 22,47 | 266 | 229 | 23,09 | 274 | 235 | 23,69 | 281 | 242 | 24,28 | 288 | 248 |
| 5,00 | 24,97 | 296 | 255 | 25,65 | 304 | 262 | 26,33 | 312 | 268 | 26,98 | 320 | 275 |
| 5,50 | 27,47 | 326 | 280 | 28,22 | 335 | 288 | 28,96 | 343 | 295 | 29,68 | 352 | 303 |
| 6,00 | 29,97 | 355 | 306 | 30,79 | 365 | 314 | 31,59 | 374 | 322 | 32,38 | 384 | 330 |
| 6,50 | 32,46 | 385 | 331 | 33,35 | 395 | 340 | 34,22 | 406 | 349 | 35,07 | 416 | 358 |
| 7,00 | 34,96 | 415 | 356 | 35,92 | 426 | 366 | 36,86 | 437 | 376 | 37,77 | 448 | 385 |
| 7,50 | 37,46 | 444 | 382 | 38,49 | 456 | 392 | 39,49 | 468 | 403 | 40,47 | 480 | 413 |
| 8,00 | 39,96 | 474 | 407 | 41,05 | 487 | 419 | 42,12 | 499 | 429 | 43,17 | 512 | 440 |
| 8,50 | 42,45 | 503 | 433 | 43,62 | 517 | 445 | 44,75 | 531 | 456 | 45,87 | 544 | 468 |
| 9,00 | 44,95 | 533 | 458 | 46,18 | 548 | 471 | 47,39 | 562 | 483 | 48,57 | 576 | 495 |
| 9,50 | 47,45 | 563 | 484 | 48,75 | 578 | 497 | 50,02 | 593 | 510 | 51,26 | 608 | 523 |
| 10,00 | 49,94 | 592 | 509 | 51,32 | 609 | 523 | 52,66 | 624 | 537 | 53,96 | 640 | 550 |
| 11,00 | 54,94 | 652 | 560 | 56,45 | 669 | 576 | 57,92 | 687 | 591 | 59,36 | 704 | 605 |
| 12,00 | 59,93 | 711 | 611 | 61,58 | 730 | 628 | 63,19 | 749 | 644 | 64,76 | 768 | 660 |
| 14,00 | 69,92 | 829 | 713 | 71,84 | 852 | 733 | 73,72 | 874 | 752 | 75,55 | 896 | 770 |
| 16,00 | 79,91 | 948 | 815 | 82,11 | 974 | 837 | 84,25 | 999 | 859 | 86,34 | 1024 | 880 |

The table applies to oil with a viscosity of 4.4 mm²/s (cSt) at a density of 830 kg/m³.

RME energy content 10,4 kWh/kg.

2.9 Components



- | | | |
|--|-----------------------------|--------------------------------|
| 1. Brake plate | 9. Switch I-0 | 18. Solenoid valve Stage 1 |
| 2. Nozzle | 10. Indicator lamp Stage 1 | 19. Solenoid valve Stage 2 |
| 3. Ignition electrodes | 11. Cover, inspection glass | 20. Nozzle assembly adjustment |
| 4. Fixing flange | 12. Switch I-II | 21. Damper motor |
| 5. Ignition transformer | 13. Indicator lamp Stage 2 | 22. Safety valve |
| 6. Flame detector | 14. Fan wheel | 23. Pump |
| 7. Control box | 15. Electrical connection | 24. Flame tube |
| 8. Contactor/Thermal overload protection | 16. Motor | 25. Air intake |
| | 17. Reset button | 26. Air damper |


3. Electric equipment

3.1 Safety system

The safety system (safety switch for hatches, doors, water level, pressure, temperature and other safety devices) must be installed in the safety circuit in accordance with current regulations for the system.

The cables of the safety system must be separated so that the outgoing signal is not placed in the same cable as the incoming signal.

3.2 Wiring diagram



3.2.1 Components

| | | | | | |
|----|-----------------------------|-----|--------------------------------------|-----|---|
| A1 | Oil burner control | S1 | Operating switch | X3 | Plug-in contact "Euro", burner |
| B1 | Flame detector | S2 | Switch, High/Low load | X4 | Plug-in contact "Euro", boiler |
| F1 | Operating fuse | S3 | Regulating thermostat | X5 | Plug-in contact "Euro", High/Low load, burner |
| F2 | Operating fuse | S4 | Temperature limiter | X6 | Plug-in contact "Euro", High/Low load, boiler |
| H1 | Lamp, Low load | S5 | Safety switch for hinged door | X7 | Plug-in contact "Euro" 3-phase, burner |
| H2 | Lamp, High load | S6 | Regulating thermostat, High/Low load | X8 | Plug-in contact "Euro", 3-phase, boiler |
| H5 | Lamp, lock-out signal 230V | S7 | Main switch 3-phase | Y1 | Solenoid valve 1 |
| K1 | Thermal overload protection | S20 | Main switch, Operation | Y2 | Solenoid valve 2 |
| M1 | Motor | T1 | Ignition transformer | Y1S | Safety valve |
| M2 | Damper motor | X1 | Connection terminal board | | |
| P1 | Timer, total operating time | X2 | Earth terminal | | |
| P2 | Timer, High load | | | | |

3.3 Function

1 Switch on operating switch and twin thermostat

A spark is formed. The air damper motor opens the damper to low load position. The burner motor starts, the prepurge goes on till the prepurge period expires and the solenoid valve 1 opens (2).

2. Solenoid valve 1 opens

Oil mist is formed and ignited. The photocell indicates a flame. The ignition spark goes out after flame indication (See Technical data oil burner control).

3. The safety time expires

- a If no flame is established before this time limit the control cuts out.
- b If for some reasons the flame disappears after this time limit, the burner will make an attempt to re-start.

4 High/Low thermostat ON

The burner is in operating position and can now change between full load and low load.

4-5 Operating position

If the burner operation is interrupted by means of the main switch or the thermostat, a new start takes place when the conditions in accordance with point 1 are fulfilled.

The oil burner control cuts out


A red lamp in the control is lit. Press the reset button and the burner re-starts.

! Mains connection and fuse in accordance with local regulations.

3.3.1 Technical data

| | LMO14.113... | LMO24.255... |
|--|--------------|--------------|
| Preignition time | 15 s | 25 s |
| Prepurge time | 16 s | 26 s |
| Postignition time | 3 s | 5 s |
| Safety lockout time | < 10 s | < 5 s |
| Reset time after lockout | < 1 s | < 1 s |
| Reaction time on flame failure | < 1 s | < 1 s |
| Ambient temperature | -5 - +60°C | -20 - +60°C |
| Min detector current required (with flame) | 45 µA dc | 45 µA dc |
| Max perm. detector current (without flame) | 5.5 µA dc | 5.5 µA dc |

160303-333



3.4 Colour codes

When the burner starts, three signal lights in the reset switch indicate the normal sequence, as well as provide indication if something abnormal is happening in accordance with the following table:

| | |
|------------------------------|---------------------|
| Preheater in operation | Solid yellow |
| Ignition switched on | Flashing yellow |
| Normal operation | Solid green |
| Operation, poor flame signal | Flashing green |
| Undervoltage | Flashing yellow-red |
| Fault, alarm | Solid red |
| False light | Flashing red-green |
| Communication mode | Fluttering red |

3.5 Fault codes

When the red light for a blocked relay box comes on, you can get information about what has caused the problem by pressing and holding the reset button for 3 seconds.

The number of flashes below is repeated with a pause in between.

| | |
|------------|---|
| 2 flashes | No flame signal when safety time expires |
| 4 flashes | False light during start |
| 7 flashes | 3 x Losses of flame during operation |
| 8 flashes | Time-out for preheater * |
| 10 flashes | Incorrect wiring, internal fault or simultaneous occurrence of two faults |

- * In order for this fault code to occur, the preheater shall not reach its cut-off temperature within 10 mins. from switch on.

To return to normal operation: Press the reset button for 1 second.

If the reset button is instead kept pressed a second time for at least 3 seconds, you can, via an interface, obtain the corresponding information on a computer or flue gas analyser.

To return to normal operation: Press the reset button for 1 second.

4. Installation

4.1 General instructions

Oil burners must be installed in accordance with local regulations. The installer must therefore be knowledgeable of the regulations pertaining to oil and combustion.

Only oil suitable for the burner must be used and then in combination with a suitable oil filter installed before the burner's oil pump.

If the burner is replacing an existing burner, ensure that the oil filter is replaced or cleaned. Installation may only be performed by qualified personnel.

Care should be taken by the installer to ensure that electrical cables and oil lines are not pinched or otherwise damaged during installation or servicing.

4.2 Inspection and maintenance

The system must be maintained at the interval specified in the service schedule. If the burner is in a dirty environment, service should be done at more frequent intervals.

4.3 Start-up

In order to obtain the correct setting, a flue gas analysis and temperature measurement must be carried out. Otherwise, there is a risk of soot build up, poor efficiency or condensation in the chimney. The system must be fine-tuned at start-up. The temperature in the chimney at a depth of 0.5 m must be at least 60 °C to prevent condensation.

4.4 Preparing for installation

Check that the burner's dimensions and capacity range are suitable for the relevant boiler. The power data on the rating plate refers to the burner's minimum and maximum power.

4.5 Oil distribution

In order to achieve good reliability, it is important that the oil distribution system is designed correctly.

Take the following into account:

- Selection of pipe diameter, pipe length and height difference; see Pump instruction.
- Pipelines are to be laid with the fewest possible number of glands.
- The pipes are to be laid so that the oil supply hoses are not subjected to tensile stresses or become excessively bent when the burner is swung out or removed for servicing.
- The oil filter should be installed so that the filter cartridge can easily be replaced or cleaned.
- Parts in contact with oil must be selected in materials that are capable of withstanding the medium's physical properties.
- When installing oil hoses, check that the inlet and return hoses are fitted to the appropriate connection on the oil pump. The hoses must be located so that they do not bend or become subject to tensile load.
- Bleed the oil system. The oil pump/oil preheater may be damaged if run dry. The vacuum in the suction line should not fall below 0.3 bar during start-up.



The oil filter must be installed before the burner's oil pump.



Be sure to fill the burner oil system before starting it for the first time.

4.6 Electrical connection

- Before work on the electrical connection, the current must be disconnected so that the installation is isolated.
- Electrical connection must be done in accordance with the applicable regulations.
- Burners must be connected to an all-pole switch.
- Connection must conform to the wiring diagram.
- Use appropriately sized fuses.



If any electrical connection is used other than that recommended by Enertech, there may be a risk of damage to property and personal injury.

4.7 Handling and lifting instruction



The lifting aid are available as accessories.



165 205 33-2

5. Mounting

1. Remove fan housing from fixing flange.
2. Remove the brake plate from the oil line.
3. Install the selected nozzles, (see Technical data).
4. Install the brake plate on the oil line.
5. Remove flame tube from fixing flange.
6. Install fixing flange with gasket on boiler.
7. Install the flame tube on the fixing flange. Make sure that the holes in the front edge of the flame tube are pointing down (not on all flame tubes), allows any drops of oil to run out.





If the burner tube must be installed from the inside of the boiler, this means that the boiler must be opened or have a spectacle flange that is designed so that it can be reconnected with the burner tube mounted.


8. Insulate between burner and boiler door to reduce radiated heat.
9. Install fan housing on fixing flange and lock with nuts.
10. Connect oil lines to the pump.
11. Connect the burner electrically.

5.1 Check oil line seals

When the burner has been installed and put into operation, the tightness of the various coupling elements should be checked, in case of leakage - tighten the coupling elements.



Use Loctite 5188 on threaded oil lines.



5.2 Example of Basic settings

Basic settings should only be seen as setting values to get burner to start. Once the burner has started and established flame, it is necessary to adjust the settings so that they are adapted to the installation and the fuel used.

B 55-2

| | |
|--------------------------|-------------------------------------|
| Burner output: | 627 kW |
| Estimated nozzle output: | $627 / 11.86^* = 52.9 \text{ kg/h}$ |

(* Calorific value Fuel oil = 11.86 kWh/kg)

This provides the following nozzle according to the nozzle table, (see Technical data).

| | | |
|------------------------------------|----------|--------|
| 627 kW distributed over 2 nozzles: | | |
| Nozzle Stage 1: | 7.00 Gph | 392 kW |
| Nozzle Stage 2: | 4.50 Gph | 235 kW |
| Pump pressure: | 14.0 bar | |

Setting values for 627 kW according to basic setting diagram, (see Technical data).

| | | | |
|---------------|------------------|---|----|
| Insert | Stage 2 | = | 25 |
| Air | Stage 1 | = | 32 |
| Fuel, Stage 2 | Solenoid valve 2 | = | 48 |
| Air | Stage 2 | = | 65 |

Selection of output and connection between the different power stages must be selected and adjusted so that the system achieves good functionality.

5.3 Settings Damper motor, 2-stage

Air adjustment

The damper motor rotates the air damper between three preset positions: completely closed, low load and high load. These positions are controlled in the motor by colored cam discs, the black cam disc controls the switching on/off of the solenoid valve. Adjust the amount of air by changing the position of the cam discs.

Blue cam disc is the limit position for closed air dampers and does not normally need to be changed.

Low load

- Set control switch for load position to position II (high load).
- Turn orange cam disc to 0° to reduce airflow and to 90° to increase airflow.
- Return the control switch to position I (low load) and check the combustion values.

High load


- Set control switch for load position to position I (low load).
- Turn red cam disc to 0° to reduce airflow and to 90° to increase airflow.
- Place black cam disc in a position between red and orange cam discs and adjust to obtain a good load change.
- Return the control switch to position II (high load) and check the combustion values.

Release

By pressing the button, the motor is disengaged and the air damper can be turned. The function is used when servicing air dampers.

Recommended excess air

| Excess air flue gases | | Max % CO ₂ |
|-----------------------|------------------------------|-----------------------|
| % O ₂ | % CO ₂ Lambda 1.2 | |
| 3 - 5 | ≈12.5 | 15.4 |



165 205 39-3 2022-10-27

6. Pump E4NC-1069


6.1 Technical data

| | |
|---|--------------------------------|
| Viscosity range: * | 3.0 to 75.0 mm ² /s |
| Pressure range: | 14-30 bar |
| Oil temperature: | 0 to +130°C |
| Max. pressure on the suction and return side: | 3.5 bar |

* Oils of higher viscosity may be used if it is pumped to the burner oil pump or if the oil viscosity is lowered to below 75 mm²/s by it being kept hot.

6.2 Components

1. Manometer connection G 1/8"
2. Connection for nozzle G 1/4"
3. Suction line G 1/2"
4. Return line G 1/2", plug, by-pass (3/16 Allen key)
5. Pressure regulation with 4 mm Allen key
6. Holes Immersion heaters
7. Filter
8. Head gasket
9. Cover




6.3 Oil connection

The pump should be connected using a two-pipe system when it is operated using oils with higher viscosity. A one-pipe system is not recommended.

6.4 Changing the filter

Change the oil pump oil filter in accordance with the following.

- Close the oil valves
- Unscrew the cover on the pump.
- Replace the oil filter.
- Replace head gasket.
- Mount the cover on the pump.
- Open the oil valves.




6.5 Function

The pump gear (1) draws oil through the pump suction port (5) from the tank through the filter in the pump and transports the oil to the valve (6) which controls the oil pressure to the nozzle. Oil that does not go through the outlet (7) to the nozzle will be bypassed (2) through the valve (6) back to the return port (8) on the pump.

6.6 Preheating pump

The pump has the facility to fit an immersion heater to providing preheating. The pump should be equipped with an immersion heater in order to facilitate cold starting and operation where oils of a higher viscosity are used. The burner is of a standard design and equipped with an immersion heater to preheat the pump.



7. Service

Service and maintenance work may only be performed by qualified personnel. Perform operational check of all safety systems and components at each service. Only Enertech original parts should be used when replacing components.



Use caution when operating the burner, surfaces may be hot.



7.1 Burner Service Schedule, Oil

Servicing must be carried out twice a year or after 3,000 hours of operation.

| | | |
|-------------|--|---|
| Burner | Twice a year | 3,000 h |
| Filter | Twice yearly replacement | 3,000 h replacement |
| Oil hose | Once yearly replacement | |
| Nozzle | Twice yearly replacement | 3,000 h replacement |
| Electrodes | Replace/Clean twice a year | Replace/Clean 3,000 h |
| Brake disc | Replace/Clean twice a year | Replace/Clean 3,000 h |
| Motor | Twice a year | 3,000 h |
| Drive shaft | Check/replace in the event of damage | Check/replace in the event of damage |
| Fan wheel | Twice a year Replace if need for cleaning/imbalance | 3,000 h Replace if need for cleaning/imbalance |
| Tank | Check for water once a year Clean tank once a year | |
| Oil filter | Twice a year | 3,000 h replacement |
| Oil valve | Leakage check twice a year | Replace if leaky |

7.2 Component replacement intervals

| Components | Service life - Recommended replacement | Service life - Recommended replacement Operating cycles |
|----------------------------------|--|---|
| Control system | 10 years | 250,000 cycles |
| Pressure switch | 10 years | 250,000 cycles |
| Ignition system with flame guard | 10 years | 250,000 cycles |
| UV flame sensor | 10,000 h | N/A |
| Damper motor | | 500,000 cycles |
| Contactator | 10 years | 500,000 cycles |



The burner and its components must be recycled according to applicable regulations.

7.3 Combustion device

1. Disconnect the main power and shut off the fuel supply.



Before obtaining access to electrical and fuel line components all supply circuits must be disconnected.


2. Loosen nut (D) and pull out the fan housing from fixing flange.
3. Remove brake plate from the oil pipe.
4. Replace nozzle.
5. Clean or replace brake plate.
6. Fit brake plate (see Technical data for adjustment).
7. Check ignition electrodes, replace if necessary (see Technical data for adjustment).
8. Refit fan housing and fixing flange, lock with nut (D).
9. Open boiler/hinged flange to access the burner tube, remove and clean.
10. Install flame tube, be sure to install the drainage hole downwards (not available on all flame tubes) so that any oil spills can drain out.
11. Close boiler/hinged flange.
12. Switch on the main power and open the fuel supply.
13. Start burner and check/adjust combustion.



Use caution when operating the burner, surfaces may be hot.



NB: When soiled, always replace nozzles with new nozzles. Do not clean.



When servicing/replacing components that affect combustion, flue gas analysis and soot test must be carried out following installation.


7.4 Air damper

1. Disconnect the main power and shut off the fuel supply.



Before obtaining access to electrical and fuel line components all supply circuits must be disconnected.

2. Undo the nuts (E) and pull out the burner body on its guides.
3. Remove the intake grille at the air intake.
4. Release the damper motor.
5. Clean the air damper (F) and air intake, lubricate the damper shaft if necessary.
6. Refit the damper motor.
7. Refit the intake grille.
8. Slide the burner together and secure it with the nuts (E).
9. Switch on the main power and open the fuel supply.
10. Start burner and check/adjust combustion.



When servicing/replacing components that affect combustion, flue gas analysis and soot test must be carried out following installation.

7.5 Replacement of damper motor, air

1. Disconnect the main power and shut off the fuel supply.





Before obtaining access to electrical and fuel line components all supply circuits must be disconnected.

2. Note the connection position of the cables on the damper motor.
3. Disconnect cables from damper motor.
4. Release the damper motor.
5. Remove the screws (G) securing the damper motor mounting plate.
6. Turn the damper approx. 30°.
7. Lift up the damper motor.
8. Disconnect the link arm (H) from the motor shaft.
9. Remove the damper motor from the mounting plate (I).
10. Install the new damper motor on the mounting plate.
11. Connect the link arm to the damper motor shaft. It is important that the screw is at right angles to the plane of the shaft.
12. Release the damper motor and lock it at 30°.
13. Fit the mounting plate by guiding the link arm into the attachment point on the air damper and the air damper shaft into the mounting plate (make sure that the bushings are fitted between the mounting plate and damper shaft).
14. Release the damper motor and check that the damper moves freely. Close the damper and zero the graduated scale on the damper motor.
15. Make the electrical connections to the damper motor.
16. Reset the damper motor cams.
17. Switch on the main power and open the fuel supply.
18. Start burner and check/adjust combustion.



When resetting dampers, ensure that they do not engage in the close damper position. If dampers do engage, the automatic control unit will report an error message.



When servicing/replacing components that affect combustion, flue gas analysis and soot test must be carried out following installation.


7.6 Fan

1. Disconnect the main power and shut off the fuel supply.



Before obtaining access to electrical and fuel line components all supply circuits must be disconnected.

2. Detach the electrical panel (Y).
3. Loosen the motor electrical connection and screws (X) enough to turn and lift out the motor.
4. Check the fan wheel attachment and any skew, replace if damaged.
5. Clean or replace the fan wheel.
6. Refit the parts, making sure that the drive shaft is correctly connected at both ends.
7. Switch on the main power and open the fuel supply.
8. Start burner and check/adjust combustion.



7.6.1 Replace drive shaft

1. Disconnect the main power and shut off the fuel supply.
2. Detach the electrical panel (Y).
3. Loosen the motor electrical connection and screws (X) enough to turn and lift out the motor.
4. Remove drive shaft and drive coupling from motor.
5. Replace drive shaft coupling on pump.
6. Refit coupling, pump and motor, making sure drive shaft is connected correctly at both ends.
7. Switch on the main power and open the fuel supply.



When servicing/replacing components that affect combustion, flue gas analysis and soot test must be carried out following installation.


7.7 Replace oil pump

1. Disconnect the main power and shut off the fuel supply.



Before obtaining access to electrical and fuel line components all supply circuits must be disconnected.

2. Disconnect oil hoses from the pump.
3. Loosen screws (J) and pull out the oil pump.
4. Move/replace the pump coupling over to the new pump and set the same distance (K) between pump and pump coupling as before to avoid pressure on the pump packing box.
5. Install the oil pump on the burner and tighten the screws (J). It is important that the splines of the pump shaft are correctly inserted in the pump coupling.
6. Fit new oil hoses.
7. Switch on the main power and open the fuel supply.
8. Bleed the pump.
9. Start burner and check/adjust combustion.



Use caution when operating the burner, surfaces may be hot.



When servicing oil bearing components, check the oil density when the burner is commissioned after servicing.



When servicing/replacing components that affect combustion, flue gas analysis and soot test must be carried out following installation.

7.8 Tightness check of solenoid valves

7.8.1 Burners with single solenoid valve

- Disconnect the power supply to solenoid valves Y1, Y2 and Y3.
- Run motor and pump - check that no oil is coming out of the nozzle, replace solenoid valve if necessary.

7.8.2 Burner with safety solenoid valve Y1S

Check safety solenoid valve Y1S

- Disconnect power supply to safety solenoid valve Y1S.
- Provide power to solenoid valve Y1.
On multi-stage burners, it is sufficient to power one valve.
- Run motor and pump - check that no oil is coming out of the nozzle, replace solenoid valve if necessary.

Check solenoid valves Y1, Y2 and Y3

- Disconnect the power supply to solenoid valves Y1, Y2 and Y3.
- Provide power to safety solenoid valve Y1S.
- Run motor and pump - check that no oil is coming out of the nozzle, replace solenoid valve if necessary.



Use Loctite 5188 on threaded oil pipelines.



When servicing/replacing components that affect combustion, flue gas analysis and soot test must be carried out following installation.

7.9 Replacement of electrical components

1. Disconnect the main power and switch off the fuel supply.



Before obtaining access to terminals, all supply circuits must be disconnected.

2. Note the connection of the existing component and disassemble.
3. Fit new component with same connection or with specified alternative connection.
4. Switch on the main power and check the operation of the new component.
5. Start burner and check/adjust combustion.




When servicing/replacing components that affect combustion, flue gas analysis and soot test must be carried out following installation.

7.10 Vibrations

Maximum permitted vibration level is 5.0 mm/s.

- Check tightness of fasteners.
- Check fan wheel for damage and contamination (replace if necessary).
- Check motor shaft and bearings. If they are worn, replace the motor.

Use screw to attach the
vibration sensor.



8. Fault Location


8.1 Burner will not start

| Symptom | Causes | Remedies |
|-----------------------|---|--|
| Motor starts | Unstable flame | Adjust the damper |
| Burner pre-ventilates | Excess air | Check the oil pressure |
| | Low oil pressure | Check the nozzle in relation to the combustion apparatus dimensions and the ignition electrode position |
| Flame formed | Incorrect combustion apparatus settings | Check the flame monitor is clean and can register light |
| Burner trips | | Check with using new photocell |
| Motor starts | Flame monitor does not register light | Check using new oil burner control (Note: replacement of photocell recommended if oil burner control replaced) |
| Burner pre-ventilates | Defective flame monitor | Check the oil supply to the burner and that there are no air bubbles in the pump |
| No flame formed | Defective oil burner control | Check function of solenoid |
| Burner trips | | Check flame monitor does not register ambient light |
| | No oil | Check high voltage wiring and ignition electrodes |
| | False light | Check preheater function |
| | No spark | |
| Motor does not start | Preheater does not get up to temperature. | |


8.2 Burner will not start after normal use

| Symptom | Causes | Remedies |
|-----------------------|---|---|
| Burner does not start | Fuse blown | Check and replace fuse as necessary. Investigate cause of fault |
| | Boiler thermostat has not reset | Adjust thermostat |
| | Preheater does not get up to temperature | Check preheater function |
| Burner pre-ventilates | Overheating protection has deployed | Reset the overheating protection. Investigate the cause of its deploying. Remedy fault |
| | Defective preheater | Check by replacing with new |
| | Defective oil burner control or flame monitor | |
| Burner stops | No oil supply | Check that tank, oil lines, solenoid valves, pump and nozzle are in good condition |
| | Too great a pressure drop at brake plate | Adjust the burner |
| | Too strong draught prevents flame forming | Correct the boiler draught |
| | No spark | Check the ignition transformer. Check the ignition electrode settings and ceramics |
| | Preheater temperature too low | Check preheater function |
| | New oil type | Adjust the preheater's set operating temperature |
| | | Check that the oil used has the physical parameters that the burner is rated for. If not, change the oil. |

8.3 Delayed ignition



8.4 Noise in pump



8.5 Pump pressure

| Symptom | Causes | Remedies |
|---|--|--|
| The burner pump can not build up pressure | No oil | Check that there is oil and that it reaches the pump |
| | Oil viscosity too low | Check that the oil reaching the pump has the physical parameters that the pump can handle. Change the oil or the pump's oil parameters |
| | Pump worn | Replace the pump |
| | Pump run using impure oil that has worn the pump out prematurely | Replace pump and install self-cleaning filter in the oil system |
| | Blocked pump filter | Check, clean pump filter |

9. Log of flue gas analysis

| | | |
|--------------|---------|----------|
| Owner | Adresss | Tel. no: |
| | | |
| Installation | | Tel. no: |

Boiler

| | | |
|------|------|----------|
| Type | Make | Power kW |
|------|------|----------|

Burner

| | | | |
|------|-------|------------|------|
| Type | Model | Serial no. | Fuel |
|------|-------|------------|------|

| | Step 1 | Step 2 | Step 3 |
|----------------------|--------|--------|--------|
| Draught in fireplace | | | |
| Fan Press mbar | | | |
| Filter smoke number | | | |
| CO ₂ | | | |
| O ₂ | | | |
| NOx | | | |
| CO | | | |
| Flue gas temp. °C | | | |
| Setting brake disc | | | |
| Setting Air damper | | | |
| Pump pressure bar | | | |
| Nozzle | | | |

| | |
|---------------------|----------------|
| Test performed / 20 | Address |
| Test performed by: | Postal address |
| Company name: | Tel. no: |



EU Declaration of conformity

Bentone Oil Burners

Type:

| | | | |
|--------|--------|------|------|
| BF 1 | ST 133 | B 40 | B 65 |
| ST 108 | ST 146 | B 45 | B 70 |
| ST 120 | B 30 | B 55 | B 80 |

This declaration of conformity is issued under the sole responsibility of the manufacturer.
The object of the declaration described above is in conformity with:

- Machinery Directive 2006/42/EC
- EMC 2014/30/EU
- The Restriction of the Use of Certain Hazardous Substances (RoHS) Directive 2011/65/EU

References to the relevant harmonised standards used or references to the other technical specifications in relation to which conformity is declared:

EN 267:2020 Excluding the requirements of Annex J/K.
Automatic forced draught burners for liquid fuels.

Additional information can be downloaded at: www.bentone.com

Manufacturer: Enertech AB
Näsvägen 8
SE-341 34 LJUNGBY
Sweden

Notified Body: TUV SÜD Product Service GmbH
Ridlerstraße 65
D-80339 München, Germany
Notified Body Number: 0123

Ljungby, 2022-10-10

Joachim Hultqvist
Technical Manager
Enertech AB

Ola Karlsson
Quality Manager
Enertech AB

UK Declaration of conformity

Bentone Oil Burners

Type:

| | | | |
|--------|--------|------|------|
| BF 1 | ST 133 | B 40 | B 65 |
| ST 108 | ST 146 | B 45 | B 70 |
| ST 120 | B 30 | B 55 | B 80 |

This declaration of conformity is issued under the sole responsibility of the manufacturer.
The object of the declaration described above is in conformity with:

- **Supply of Machinery (Safety) Regulations 2008**
- **Electromagnetic Compatibility Regulations 2016**
- **The Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations 2012**

References to the relevant harmonised standards used or references to the other technical specifications in relation to which conformity is declared:


BS EN 267:2020 Excluding the requirements of Annex J/K.
Automatic forced draught burners for liquid fuels.

Additional information can be downloaded at: www.bentone.com

Manufacturer: Enertech AB
Näsvägen 8
SE-341 34 LJUNGBY
Sweden

Approved Body: TUV SÜD BABT Unlimited
Octagon House,
Concorde Way, Segensworth North,
Fareham, Hampshire,
PO 15 5RL, United Kingdom
Approved Body Number: 0168

Ljungby, 2022-10-10



Joachim Hultqvist
Technical Manager
Enertech AB



Ola Karlsson
Quality Manager
Enertech AB

