




Providing sustainable energy solutions worldwide

Installation- and maintenance instruction

B 70-3R

BP230UVFR-S3

RSA125



-sv

1. Manualer på övriga språk

2. www.bentone.com/download eller scanna QR-koden.

3. Skriv in brännarens artikelnummer som finns på din typskylt (se bild) och välj ditt språk.

Detaljerad ecodesign information kan laddas ner på:
www.bentone.com/ecodesign.

-en

1. Manuals in other languages

2. www.bentone.com/download or scan QR-code.

3. Enter the burner's article number on your data plate (see picture) and select language.

Detailed ecodesign information can be downloaded at:
www.bentone.com/ecodesign.

-da

1. Manualer på andre sprog

2. www.bentone.com/download eller scan QR-koden.

3. Indtast brænderens artikelnummer, der findes på typeskiltet (se billede), og vælg dit sprog.

Detaljerede oplysninger om ecodesign kan downloades på:
www.bentone.com/ecodesign.

-fr

1. Manuels dans d'autres langues

2. www.bentone.com/download ou scannez le code QR.

3. Saisir le numéro d'article du brûleur sur votre plaque signalétique (consultez l'illustration) et sélectionnez la langue.

Des informations détaillées sur l'écodesign peuvent être téléchargées à l'adresse:
www.bentone.com/ecodesign.

-de

1. Gebrauchsanweisungen in anderen Sprachen

2. www.bentone.com/download oder scannen Sie den QR-Code.

3. Geben Sie die Artikelnummer des Brenners auf Ihrem Typenschild ein, (siehe Bild) und wählen Sie die Sprache aus.

Detaillierte Informationen zum Ecodesign können unter www.bentone.com/ecodesign heruntergeladen werden.

Table of contents

| | | | |
|---|-----------|---|-----------|
| 1. Safety Information | 4 | 7. Electrical equipment | 30 |
| 2. Technical data | 7 | 7.1 Wiring diagram | 30 |
| 2.1 Dimensions B 70-3R | 7 | 7.2 Component list | 31 |
| 2.2 Working field B 70-3R | 8 | 8. Control | 32 |
| 2.3 Setting of brake plate and air flow | 8 | 8.1 Technical data | 32 |
| 2.4 Electric Specification | 8 | 8.2 LED indicator lamps | 32 |
| 2.5 Setting of brake disc and air flow | 9 | 8.3 Explanation of the different sequence modes | 33 |
| 2.6 Burner installation | 9 | 8.4 BurnerPro LED fault/lock code table | 34 |
| 2.7 Recommended nozzle and pressure | 9 | 9. Fault Location | 38 |
| 2.8 Nozzle table. | 10 | 9.1 Burner will not start | 38 |
| 2.9 Description | 12 | 9.2 Burner will not start after normal use | 38 |
| 3. General instructions | 13 | 9.3 Delayed ignition | 39 |
| 3.1 General rules | 13 | 9.4 Noise in pump | 39 |
| 4. Installation | 14 | 9.5 Pump pressure | 40 |
| 4.1 Handling and lifting instruktion | 14 | 10. Log of flue gas analysis | 41 |
| 4.2 Acceptance inspection | 15 | 11. Oil burners maintenance instructions | 42 |
| 4.3 Preparations for installation | 15 | | |
| 4.4 Distribution of oil | 15 | | |
| 4.5 Electrical connection | 16 | | |
| 4.6 Mount the burner on the boiler | 17 | | |
| 4.7 Check oil line seals | 17 | | |
| 4.8 Example of basic settings | 18 | | |
| 4.9 Recommended surplus air | 18 | | |
| 4.10 Setting values for nozzle and air damper | 19 | | |
| 4.11 Insert control movable brake disc | 20 | | |
| 4.12 Air setting | 20 | | |
| 5. Burner servicing | 21 | | |
| 5.1 Servicing the combustion device | 21 | | |
| 5.2 Servicing air dampers | 22 | | |
| 5.3 Replacement of damper motor, air | 23 | | |
| 5.5 Replacing the oil pump | 24 | | |
| 5.6 Replacement of electrical components | 25 | | |
| 5.7 Vibration | 26 | | |
| 6. Instructions Pump RSA95, RSA125 | 27 | | |
| 6.1 Technical data | 27 | | |
| 6.2 Components | 27 | | |
| 6.3 Mounting/dismounting by-pass plug | 27 | | |
| 6.4 Purging | 27 | | |
| 6.5 Replacing the filter | 27 | | |
| 6.6 Function Danfoss RSA 95 - 125 | 28 | | |
| 6.7 Suction line tables | 29 | | |

1. Safety Information

This Installation and Maintenance manual:

- is to be regarded as part of the burner and must always be kept near the installation site.
- is intended for use by authorised personnel.
- must be read prior to installation.
- must be observed by all who work with the burner and associated system components.
- work with the burner may only be carried out by certified installers/ personnel.
- Enertech AB is not liable for any typographical errors and reserves the right to make design changes without prior notice.
- The burner may only be used for its intended purpose in accordance with the product's technical data.
- The burner may only be installed and operated by authorised personnel.
- The product is packaged to prevent damage from occurring during handling. Handle the product with care. Lifting equipment must be used to lift larger packages.
- The products must be transported/stored on a level surface in a dry environment, max. 80% relative humidity, no condensation. Temperature -20 to +60 °C.
- Check that the burner is compatible with the boiler's output range.
- The label information on the rating plate refers to the burner's minimum and maximum power.
- The power data on the type sign refers to the burner's min. and max. power.
- All components must be installed without being bent, twisted or subjected to mechanical or thermal forces which can affect the components.
- The burner must be installed so that it complies with local regulations for fire safety, electrical safety, and fuel distribution.
- Make sure when installing the equipment that there is enough space to service the burner.
- Permitted ambient temperature during operation -0 to +60 °C. Max 80% relative humidity, no condensation.
- The installer must ensure that the room has adequate air supply.
- The room must comply with local regulations pertaining to its intended use.
- The installation site must be free of chemicals.
- Burner pipes, fan wheels and air dampers may contain sharp edges.
- The surface temperature of the burner's components can exceed 60 °C.
- Caution: The burner has moving parts, and there is risk of crushing injuries.



165 105 01

- The electrical installation must be professionally carried out in accordance with applicable high voltage regulations, as per Enertech's recommendations.
- Before servicing, shut off the fuel supply and turn off the power to the burner.
- Leak checks must be performed during installation and servicing to prevent fuel leakage.
- Care should be taken by the installer to ensure that no electrical cables or fuel lines are crushed or otherwise damaged during installation or servicing.
- If the boiler is equipped with an access hatch, this must be equipped with a hatch opening switch connected to the burner's safety system.
- When in operation, the burner's noise level can exceed 85 dBA. Use hearing protection.
- The burner must not be put into operation without proper safety and protection devices.
- A Class BE fire extinguisher is recommended.
- It is forbidden to alter the design or use accessories which have not been approved by Enertech in writing.
- Prior to operation, the following points must be checked:
 - fitting and installation work has been completed and approved.
 - electrical installation has been correctly performed.
 - flue gas ducts and combustion air ducts are not blocked.
 - all actuators and control and safety devices are in working order and correctly set.
- After commissioning, if a steady red light on the burner control is displayed, contact your installation technician.



Burner servicing schedule

Servicing must be carried out once a year or after 3000 hours of operation.

| | | |
|----------------|--|--|
| Burner | 1 year | 3000 hrs |
| Filter | 1 year | 3000 hrs Change |
| Oilhose | 1 year Control/change | |
| Nozzle | 1 year Change | 3000 hrs Change |
| Electrods | 1 year Change/cleaning | 3000 hrs Change/cleaning |
| Brake plate | 1 year Change/cleaning | 3000 hrs Change/cleaning |
| Motor | 1 year | 3000 hrs |
| Cuppling chaft | 1 year Control/change | 3000 hrs Control/change |
| Fan wheel | "1 year Change when dirty / unbalance" | "3000 hrs Change when dirty / unbalance" |
| Oil filter | 1 year | 3000 hrs Change |
| Oil valve | Tightness check 1 year | Replacement in case of leakage |

Component replacement intervals

| Components | Service life – Recommended replacement | Service life – Recommended replacement Operating cycles |
|-----------------|--|---|
| Control system | 10 years | 250 000 cycles |
| Pressure switch | 10 years | 250 000 cycles |
| Flame guard | 10 years | 250 000 cycles |
| UV flame sensor | 10 000 hrs | N/A |
| Damper motor | | 500 000 cycles |
| Contaktor | 10 years | 500 000 cycles |



The burner and its components must be recycled according to applicable regulations.

Delivery check

- Make sure everything is delivered and the goods have not been damaged during transit.
- If something is wrong with a delivery, report it to the supplier.
- Transport damage must be reported to the shipping company.

2. Technical data


The burner is intended for:

- Light oil, B10 heating oil/biofuel blend (as defined in DIN V51603-6)

and is used for:

- Water heating generators
- Hot air generators

2.1 Dimensions B 70-3R




| | A | Ø B | Ø C | D | E | F | G | H | *I |
|----------------|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| B 70-3R | 324 | 220 | 205 | 730 | 408 | 504 | 420 | 830 | 200 |
| B 70-3R | 624 | 220 | 205 | 730 | 408 | 504 | 420 | 830 | 200 |



* Min. recommended distance to floor.

2.2 Working field B 70-3R

41-139 kg/h
490-1650 kW



2.3 Setting of brake plate and air flow



| Burner, Type | a | b | c | d |
|--------------|---------|----------|---------|-----------|
| B 70-3R | 3,5-4,0 | 8,0-10,0 | 2,0-3,0 | 10,0-13,0 |

! *NB It is important that the spark does not strike against the brake plate or nozzle.

2.4 Electric Specification

Burner correspond to IP 20

| Type | Motor supply | Main supply | Sound |
|--|--------------------|-----------------|------------------|
| B 70-3R | 230/400V 10,4/6,0A | 230V 0,7 A 50Hz | 89 dBA ± 0,5 dBA |
| Max operating current, see data plate. | | | |

2.5 Setting of brake disc and air flow

Once the different output modes have been selected prior to commissioning, basic settings for the burner can be made as shown in the air damper and brake disc diagrams. See under Default settings. Note that it is simply a matter of a default setting that should be adjusted retrospectively once the burner has started. You should then conduct a flue gas analysis and soot quantity measurement.

2.6 Burner installation


2.6.1 Hole pattern

Make sure the hole pattern on the boiler is designed for burner flange.

| Combustion device | d_1 | d_2 | d_3 |
|-------------------|-----------|-------|---------------|
| B 70-3 | (205) 225 | M14 | (310) 324-390 |

d_1^* If the burner tube is installed from inside the boiler.

d_3^* The hole pattern can be moved down if the burner tube is installed from the front and the tabs in the flange are removed.



2.7 Recommended nozzle and pressure

Because of the various boiler types with varying furnace geometries and furnace loads, it is impossible to commit to a certain scattering angle or a specific distribution pattern.

It should be noted that the scattering angle and distribution pattern changes with pump pressure.

| | |
|----------------|--|
| Nozzle: | 45° Solid/semisolid |
| | 60° Solid/semisolid |
| | 80° Solid/semisolid |
| Pump pressure: | 14 bar (12-16 bar) depending on pump model |

2.8 Nozzle table.

Pump pressure bar

| Gph | 10 | | | 11 | | | 12 | | | 13 | | |
|-------|-------|------|--------|--------|------|--------|--------|------|--------|--------|------|--------|
| | kg/h | kW | Mcal/h | kg/h | kW | Mcal/h | kg/h | kW | Mcal/h | kg/h | kW | Mcal/h |
| 1,00 | 3,72 | 44 | 38 | 3,90 | 46 | 40 | 4,08 | 48 | 42 | 4,24 | 50 | 43 |
| 1,10 | 4,09 | 48 | 42 | 4,29 | 51 | 44 | 4,48 | 53 | 46 | 4,67 | 55 | 48 |
| 1,20 | 4,47 | 53 | 46 | 4,68 | 55 | 48 | 4,89 | 58 | 50 | 5,09 | 60 | 52 |
| 1,25 | 4,65 | 55 | 47 | 4,88 | 58 | 50 | 5,10 | 60 | 52 | 5,30 | 63 | 54 |
| 1,35 | 5,02 | 59 | 51 | 5,27 | 62 | 54 | 5,50 | 65 | 56 | 5,73 | 68 | 58 |
| 1,50 | 5,58 | 66 | 57 | 5,85 | 69 | 60 | 6,11 | 72 | 62 | 6,36 | 75 | 65 |
| 1,65 | 6,14 | 73 | 63 | 6,44 | 76 | 66 | 6,73 | 80 | 69 | 7,00 | 83 | 71 |
| 1,75 | 6,51 | 77 | 66 | 6,83 | 81 | 70 | 7,14 | 85 | 73 | 7,42 | 88 | 76 |
| 2,00 | 7,45 | 88 | 76 | 7,81 | 93 | 80 | 8,16 | 97 | 83 | 8,49 | 101 | 87 |
| 2,25 | 8,38 | 99 | 85 | 8,78 | 104 | 90 | 9,18 | 109 | 94 | 9,55 | 113 | 97 |
| 2,50 | 9,31 | 110 | 95 | 9,76 | 116 | 100 | 10,19 | 121 | 104 | 10,61 | 126 | 108 |
| 2,75 | 10,24 | 121 | 104 | 10,73 | 127 | 109 | 11,21 | 133 | 114 | 11,67 | 138 | 119 |
| 3,00 | 11,16 | 132 | 114 | 11,71 | 139 | 119 | 12,23 | 145 | 125 | 12,73 | 151 | 130 |
| 3,50 | 13,03 | 154 | 133 | 13,66 | 162 | 139 | 14,27 | 169 | 146 | 14,85 | 176 | 151 |
| 4,00 | 14,89 | 176 | 152 | 15,62 | 185 | 159 | 16,31 | 193 | 166 | 16,97 | 201 | 173 |
| 4,50 | 16,75 | 199 | 171 | 17,57 | 208 | 179 | 18,35 | 218 | 187 | 19,10 | 226 | 195 |
| 5,00 | 18,62 | 220 | 190 | 19,52 | 231 | 199 | 20,39 | 242 | 208 | 21,22 | 252 | 216 |
| 5,50 | 20,48 | 243 | 209 | 21,47 | 255 | 219 | 22,43 | 266 | 229 | 23,34 | 277 | 238 |
| 6,00 | 22,34 | 265 | 228 | 23,42 | 278 | 239 | 24,47 | 290 | 250 | 24,46 | 302 | 260 |
| 6,50 | 24,20 | 287 | 247 | 25,37 | 301 | 259 | 26,51 | 314 | 270 | 27,58 | 327 | 281 |
| 7,00 | 26,06 | 309 | 266 | 27,33 | 324 | 279 | 28,55 | 339 | 291 | 29,70 | 352 | 303 |
| 7,50 | 27,92 | 331 | 285 | 29,28 | 347 | 299 | 30,59 | 363 | 312 | 31,83 | 377 | 325 |
| 8,00 | 29,79 | 353 | 304 | 31,23 | 370 | 318 | 32,63 | 387 | 333 | 33,95 | 403 | 346 |
| 8,50 | 31,65 | 375 | 323 | 33,18 | 393 | 338 | 34,66 | 411 | 353 | 36,07 | 428 | 368 |
| 9,00 | 33,59 | 398 | 343 | 35,14 | 417 | 358 | 36,71 | 435 | 374 | 38,19 | 453 | 389 |
| 9,50 | 35,37 | 419 | 361 | 37,09 | 440 | 378 | 38,74 | 459 | 395 | 40,31 | 478 | 411 |
| 10,00 | 37,23 | 441 | 380 | 39,04 | 463 | 398 | 40,78 | 484 | 416 | 42,44 | 503 | 433 |
| 11,00 | 40,96 | 486 | 418 | 42,94 | 509 | 438 | 44,86 | 532 | 457 | 46,68 | 554 | 476 |
| 12,00 | 44,68 | 530 | 456 | 46,85 | 556 | 478 | 48,94 | 580 | 499 | 50,92 | 604 | 519 |
| 14,00 | 52,12 | 618 | 531 | 54,65 | 648 | 557 | 57,10 | 677 | 582 | 59,41 | 705 | 606 |
| 16,00 | 59,57 | 706 | 607 | 62,46 | 741 | 637 | 65,26 | 774 | 666 | 67,90 | 805 | 692 |
| 18,00 | 67,02 | 795 | 683 | 70,27 | 833 | 717 | 73,41 | 871 | 749 | 76,39 | 906 | 779 |
| 20,00 | 74,47 | 883 | 759 | 78,08 | 926 | 796 | 81,57 | 967 | 832 | 84,87 | 1007 | 865 |
| 22,00 | 81,91 | 971 | 835 | 85,89 | 1019 | 876 | 89,73 | 1064 | 915 | 93,36 | 1107 | 952 |
| 24,00 | 89,36 | 1060 | 911 | 93,70 | 1111 | 956 | 97,88 | 1161 | 998 | 101,85 | 1208 | 1039 |
| 26,00 | 96,81 | 1148 | 987 | 101,50 | 1204 | 1035 | 106,04 | 1258 | 1081 | 110,33 | 1308 | 1168 |


The table applies to oil with a viscosity of 4.4 mm²/s at a density of 830 kg/m³.

Pump pressure bar

| Gph | 14 | | | 15 | | | 16 | | | 17 | | |
|-------|-------|------|--------|-------|------|--------|-------|------|--------|-------|------|--------|
| | kg/h | kW | Mcal/h | kg/h | kW | Mcal/h | kg/h | kW | Mcal/h | kg/h | kW | Mcal/h |
| 1,00 | 4,40 | 52 | 45 | 4,56 | 54 | 46 | 4,71 | 56 | 48 | 4,85 | 57 | 49 |
| 1,10 | 4,84 | 57 | 49 | 5,01 | 59 | 51 | 5,18 | 61 | 53 | 5,34 | 63 | 54 |
| 1,20 | 5,29 | 63 | 54 | 5,47 | 65 | 56 | 5,65 | 67 | 58 | 5,82 | 69 | 59 |
| 1,25 | 5,51 | 65 | 56 | 5,70 | 68 | 58 | 5,89 | 70 | 60 | 6,07 | 72 | 62 |
| 1,35 | 5,95 | 70 | 61 | 6,15 | 73 | 63 | 6,36 | 75 | 65 | 6,55 | 78 | 67 |
| 1,50 | 6,60 | 78 | 67 | 6,83 | 81 | 70 | 7,06 | 84 | 72 | 7,27 | 86 | 74 |
| 1,65 | 7,27 | 86 | 74 | 7,52 | 89 | 77 | 7,77 | 92 | 79 | 8,01 | 95 | 82 |
| 1,75 | 7,71 | 91 | 79 | 7,97 | 95 | 81 | 8,24 | 98 | 84 | 8,49 | 101 | 87 |
| 2,00 | 8,81 | 104 | 90 | 9,12 | 108 | 93 | 9,42 | 112 | 96 | 9,71 | 115 | 99 |
| 2,25 | 9,91 | 118 | 101 | 10,26 | 122 | 105 | 10,60 | 126 | 108 | 10,92 | 130 | 111 |
| 2,50 | 11,01 | 131 | 112 | 11,39 | 135 | 116 | 11,77 | 140 | 120 | 12,13 | 144 | 124 |
| 2,75 | 12,11 | 144 | 123 | 12,53 | 149 | 128 | 12,95 | 154 | 132 | 13,35 | 158 | 136 |
| 3,00 | 13,21 | 157 | 135 | 13,67 | 162 | 139 | 14,13 | 168 | 144 | 14,56 | 173 | 148 |
| 3,50 | 15,42 | 183 | 157 | 15,95 | 189 | 163 | 16,49 | 196 | 168 | 16,99 | 201 | 173 |
| 4,00 | 17,62 | 209 | 180 | 18,23 | 216 | 186 | 18,84 | 223 | 192 | 19,42 | 230 | 198 |
| 4,50 | 19,82 | 235 | 202 | 20,51 | 243 | 209 | 21,20 | 251 | 216 | 21,84 | 259 | 223 |
| 5,00 | 22,03 | 261 | 225 | 22,79 | 270 | 232 | 23,55 | 279 | 240 | 24,27 | 288 | 247 |
| 5,50 | 24,23 | 287 | 247 | 25,07 | 297 | 256 | 25,91 | 307 | 264 | 26,70 | 317 | 272 |
| 6,00 | 26,43 | 313 | 270 | 27,49 | 326 | 280 | 28,27 | 335 | 288 | 29,13 | 345 | 297 |
| 6,50 | 28,63 | 340 | 292 | 29,63 | 351 | 302 | 30,62 | 363 | 312 | 31,55 | 374 | 322 |
| 7,00 | 30,84 | 366 | 314 | 31,91 | 378 | 325 | 32,98 | 391 | 336 | 33,98 | 403 | 374 |
| 7,50 | 33,04 | 392 | 337 | 34,19 | 405 | 349 | 35,33 | 419 | 360 | 36,41 | 432 | 371 |
| 8,00 | 35,25 | 418 | 359 | 36,47 | 433 | 372 | 37,69 | 447 | 384 | 38,80 | 460 | 396 |
| 8,50 | 37,45 | 444 | 382 | 38,74 | 459 | 395 | 40,04 | 475 | 408 | 41,26 | 489 | 421 |
| 9,00 | 39,65 | 470 | 404 | 41,02 | 486 | 418 | 42,40 | 503 | 432 | 43,69 | 518 | 446 |
| 9,50 | 41,85 | 496 | 427 | 43,30 | 514 | 442 | 44,75 | 531 | 456 | 46,11 | 547 | 470 |
| 10,00 | 44,06 | 523 | 449 | 45,58 | 541 | 465 | 47,11 | 559 | 480 | 47,11 | 559 | 480 |
| 11,00 | 48,46 | 575 | 494 | 50,14 | 595 | 511 | 51,82 | 615 | 528 | 53,40 | 633 | 545 |
| 12,00 | 52,87 | 627 | 539 | 54,70 | 648 | 558 | 56,53 | 670 | 576 | 58,25 | 691 | 594 |
| 14,00 | 62,68 | 732 | 629 | 63,81 | 757 | 651 | 65,95 | 778 | 669 | 67,96 | 806 | 693 |
| 16,00 | 70,49 | 836 | 719 | 72,93 | 865 | 744 | 75,38 | 894 | 769 | 77,67 | 921 | 792 |
| 18,00 | 79,30 | 940 | 809 | 82,05 | 973 | 837 | 84,80 | 1006 | 865 | 87,38 | 1036 | 891 |
| 20,00 | 88,11 | 1045 | 899 | 91,17 | 1081 | 930 | 94,22 | 1117 | 961 | 97,09 | 1151 | 990 |
| 22,00 | 96,92 | 1149 | 988 | 100 | 1189 | 1023 | 104 | 1229 | 1057 | 107 | 1267 | 1089 |
| 24,00 | 106 | 1254 | 1078 | 109 | 1297 | 1116 | 113 | 1341 | 1153 | 116 | 1382 | 1188 |
| 26,00 | 115 | 1359 | 1168 | 119 | 1406 | 1209 | 122 | 1453 | 1249 | 126 | 1497 | 1287 |

The table applies to oil with a viscosity of 4.4 mm²/s at a density of 830 kg/m³.

2.9 Description



- | | |
|-------------------------|--------------------|
| 1. Inspection window | 8. Damper motor |
| 2. Connection box | 9. Solenoid valve |
| 3. Solenoids with block | 10. Pump |
| 4. Flange | 11. Insert control |
| 5. Burner pipe | 12. Motor |
| 6. Flange lock | 13. Fan wheel |
| 7. Air intake | |

3. General instructions

3.1 General rules

The installation of an oil burner should be carried out in accordance with local regulations. The installer of the burner must therefore be aware of all regulations relating to oil and combustion.

Only oil suitable for the burner should be used and then in combination with a suitable oil filter before the oil pump of the burner.

If the burner is replacing an existing burner make sure that the oil filter is replaced or cleaned. The installation must only be undertaken by experienced personnel. Care should be taken by the installer to ensure that no electrical cables or fuel/gas pipes are trapped or damaged during installation or service/maintenance.

3.1.1 Installation and maintenance instructions

The maintenance instructions supplied with the burner must be kept at an easily accessible location in the boiler room.

3.1.2 Instructions

The user must be receive detailed instructions concerning the functionality of the oil burner and entire system. It is the responsibility of the supplier to provide the user with instructions.

3.1.3 Inspection and maintenance

Refer to servicing schedule

3.1.4 Before commissioning

The 3-stage thermostat must be installed before operation. Contact Bentone for more information about the appropriate product.

3.1.5 Start up

In order to obtain the correct setting, a flue gas analysis and temperature measurement must be carried out. Otherwise, there is a risk of soot build up, poor efficiency or condensation precipitation in the chimney. The system must be fine-tuned at start-up. The temperature in the chimney must be at least 60 °C at 0.5 m down in the chimney to prevent condensation.

4. Installation

4.1 Handling and lifting instruktion



The lifting aid are available
as spare parts.

4.2 Acceptance inspection

Make sure everything is delivered and the goods have not been damaged during transit. If something is wrong with the delivery, report it to the supplier. Transport damage must be reported to the shipping company.

4.3 Preparations for installation

Check that the burner's dimensions and capacity range are suitable for the boiler in question. The power data on the type sign refers to the burner's min. and max. power.

4.4 Distribution of oil

In order to achieve good reliability, it is important that the oil distribution system is designed correctly.


Take the following into account:

- Selection of pipe diameter, pipe length and height difference; see Pump instruction.
- Pipelines are to be laid with a minimal number of glands.
- The pipes are to be laid so that the oil supply hoses are not subjected to tensile stresses or are excessively bent when the burner is swung out or removed for service.
- The oil filter should be installed so that the filter cartridge can easily be replaced or cleaned. Self-cleaning filters are recommended for oils of a higher viscosity or oils that contain significant impurities.
- Oil-affected parts shall be selected in materials that are capable of withstanding the medium's physical properties.
- When installing oil hoses, check that the inlet and return hoses are fitted to the appropriate connection on the oil pump. The hoses shall be located so that they do not bend or become subject to tensile load.
- Bleed the oil system. The oil pump/oil preheater may be damaged if run dry. The vacuum should not fall below -0.3 bar in the suction line during start-up.


! Be sure to fill the burner oil system before starting it for the first time.

4.4.1 Proposed pipe routing for oil distribution systems without transport pump

This type of connection should be used only when the oil has a viscosity less than 6 mm²/s.



4.4.2 Pipe routing suggestion for oil distribution systems with a transport pump, coarse filter and fine filter



1. Transport pump
2. Coarse filter
3. Bypass valve 0,5 - 2,0 bar
4. Fine filter
5. Manometer 1
6. Manometer 2

4.5 Electrical connection

- Before work on the electrical connection, the current should be disconnected so that the installation is isolated.
- Electrical connection must be done in accordance with the applicable regulations.
- Burners should be connected to an isolator switch.
- The connection should be made in accordance with the wiring diagram.
- Fuse rating is as required.



If any electrical connection is used other than that recommended by Bentone, there may be a danger of damage to property and personal injury.

4.6 Mount the burner on the boiler

1. Separate the burner body and the flange.
2. Pull out the burner on the guides.
3. Remove the brake disc from the oil pipe.
4. Install the selected nozzle, (see Technical data).
5. Install the brake disc on the oil pipe.




! If the burner tube must be installed from the inside of the boiler, this means that the boiler must be opened or have a spectacle flange that is designed so that it can be reconnected with the burner tube mounted.

6. Remove the burner pipe from the flange.
7. Install the flange with gasket on the boiler.
8. Install the burner pipe on the flange. Make sure that the holes in the front edge of the burner pipe are pointing down (not on all burner pipes). This allows any drops of oil to run out.
9. Insulate between the burner and boiler door to reduce radiated heat.
10. Install the burner body on the flange.
11. Lock the burner body using with the nut/nuts.
12. Connect the oil pipes to the pump, refer to the chapter - servicing of burners.
13. Connect the burner electrically, refer to the chapter - servicing of burners.

4.7 Check oil line seals

Once the burner has been installed and commissioned, the seals of the various coupling elements should be checked (A).

When a leak is detected, it is usually sufficient to tighten the coupling element that is leaking.



4.8 Example of basic settings

Choice of nozzle B 70-3R

| | |
|----------------|---------|
| Burner output | 1250 kW |
| Output stage 1 | 627 kW |
| Output stage 2 | 313 kW |
| Output stage 3 | 313 kW |

According to the nozzle table, this provides the following nozzle.

| | |
|--------|----------|
| Step 1 | 12,0 Gph |
| Step 2 | 6,0 Gph |
| Step 3 | 6,0 Gph |

Basic settings B 70-3R

Effects and nozzle selection from the example above. The values are available in the tables for setting values of inserts or air dampers.

| | |
|--------|---------------|
| Insert | Step 1/2 = 17 |
| | Step 3 = 37 |

| | |
|---------------------|------|
| Low load air damper | =22° |
| MV2 open | =35° |
| Air damper step 2 | =52° |
| MV3 open | =60° |
| Air damper step 3 | =75° |


These are the default settings and controlling the combustion will take place during operation.

Selection of power and connection between the different power stages must be selected and adjusted so that the system achieves good functionality.

4.9 Recommended surplus air

| Oil type | Excess air flue gases | | Max. % CO ₂ |
|---|-----------------------|------------------------------|------------------------|
| | % O ₂ | % CO ₂ Lambda 1.2 | |
| Light oil, B10 heating oil/ biofuel mix (as per the definition in DIN V51603-6) | 3–5 | ≈12,5 | 15,4 |

4.10 Setting values for nozzle and air damper



4.11 Insert control movable brake disc

Insert control is used to achieve a pressure drop over the brake disc as favourable as possible in the various power stages.

3- nozzles

The insert control sets the brake disc mode between Step 2 and Step 3 using a hydraulic piston. There are two adjustments to be made on the insert a low load adjustment and a high load adjustment.

Low load

The low load adjustment takes place by changing the guide rail's mounting to the hydraulic piston. This takes place using a locking screw located through an oval hole. In the default setting, the value that is read in the table, is used for the setting values for the chosen power for step 2. During operation, the insert is adjusted in order to achieve the best function.

Undo the locking screw (C).

Set the desired position on the scale (A) by pushing the disc in the desired position.


Tighten the screw (C).

High load

The high load setting takes place by adjusting the hydraulic piston's length of stroke using set screw (D). Loosening the set screw increases the length of stroke while tightening it reduces the length of stroke

Set the desired position on the scale (A) using the set screw (D) (left turn reduces pressure loss, the brake disc is moved outward).

If pulsation occurs, the changed pressure drop over the brake disc may result in the pulsation stopping



4.12 Air setting

When the burner's power stage has been selected, check the setting values for air dampers in table. Read the damper angle for each of the power stages. This must then be used when the settings are made in the burner's control system.

Check the air settings by conducting a flue gas analysis.

5. Burner servicing

5.1 Servicing the combustion device

Removal and installation

1. Switch off the main power.



If the burner is directly connected, ensure that all components on the burner are without power.

2. Remove the nuts (H) and pull the burner body out of the guides from the burner flange.
3. Remove the brake plate from the oil pipe and clean the brake plate.
4. Unscrew the nozzle/nozzles.
5. Fit the nozzles
6. Install the brake plate. (See technical data)
7. Check the ignition electrodes. (See technical data)
8. If necessary, replace the ignition electrodes.
9. Fit the burner body and the burner flange together and secure with the nut (H).
10. Open the boiler/spectacle flange to access the burner pipe.
11. Remove and clean the burner pipe.
12. Install the burner pipe, make sure you install the drainage hole (not on all burner pipes) facing downwards so that any spilled oil can drain out.
13. Close the boiler / spectacle flange.
14. Turn on the mains power.
15. Check combustion.



Use caution when operating the burner, surfaces may be hot.



When soiled, always replace nozzles with new nozzles.



When servicing/replacing components that affect combustion, an analysis and soot test must be carried out on the installation

165 305 01


5.2 Servicing air dampers

Removal and installation

1. Break the main current and disconnect the Euro plugs from the burner.

! If the burner is directly connected, ensure that all components on the burner are without power.

2. Loosen the nuts (H) and pull the burner body out of the guides.
3. Remove the intake grille at the air intake.
4. Disconnect the damper motor.
5. Clean the air damper (F) and the intake.
6. Reconnect the damper motor.
7. Install the intake grille for the air intake.
8. Press the burner together and lock using the nuts (E).
9. Fit the Euro plugs and turn on the mains power.
10. Check combustion.



! When servicing/replacing components that affect combustion, an analysis and soot test must be carried out on the installation

5.3 Replacement of damper motor, air

Removal and installation

1. Break the main current and disconnect the Euro plugs from the burner.




If the burner is directly connected, ensure that all components on the burner are without power.

2. Note the position of the cables and loosen the wires in the damper motor.
3. Disengage the damper motor and set it at 30°.
4. Loosen the screws (G) to the damper motor mounting plate.
5. Lift the damper motor carefully so that the air damper remains in the air intake.
6. Loosen (L) the control arm from the motor shaft.
7. Remove the damper motor from the mounting plate (I).
8. Reinstall the damper motor on the mounting plate.
9. Fit the control arm on the damper motor shaft. It is important that the screw is perpendicular to the plane of the shaft.
10. Disengage the damper motor and set it at 30°.
11. Install the mounting plate by guiding the control arm into the bracket on the air damper and the air damper shaft in the mounting plate (make sure the bushings between the mounting plate and the damper shaft are in place).
12. Disengage the damper motor, feel that the damper moves easily. Close the damper and reset the protractor on the damper motor.
13. Connect the damper motor electrically.
14. Set the damper motor notches.
15. Fit the Euro plugs and turn on the mains power.
16. Check combustion.



When resetting dampers, ensure that they do not engage in the close damper position. If dampers do engage, the automatic control unit will report an error message.



When servicing/replacing components that affect combustion, an analysis and soot test must be carried out on the installation


5.5 Replacing the oil pump

Removal and installation

1. Switch off the mains power.

! If the burner is directly connected, ensure that all components on the burner are without power.

2. Remove the oil hoses from the pump.
3. Loosen the screws (J) and pull out the oil pump
4. Measure the distance from the pump mount to the pump coupling (K).
5. Move the pump coupling to the new pump and set the same distance between the pump and the pump coupling as before (K) in order to avoid pressure on the pump seal.
6. Install the oil pump on the burner and tighten the screws (J). (It is important that the pump shaft splines align correctly in the pump coupling).
7. Fit the oil hoses
8. Turn on the mains power.
9. Bleed the pump, start the burner and set the correct oil pressure (refer to technical data for correct output).
10. Check combustion.



! Use caution when operating the burner, surfaces may be hot.

! When servicing oil bearing components, check the oil leaks when the burner is commissioned after servicing.

! When servicing/replacing components that affect combustion, an analysis and soot test must be carried out on the installation

5.6 Replacement of electrical components

1. Switch off the mains power.



If the burner is directly connected, ensure that all components on the burner are without power.




Lift the relay carefully to avoid stretching the earth cable when dismantling

2. Note the connection of the existing component.
3. Remove the existing component.
4. Install the new component using the same wiring as the existing component or the specified alternative arrangement.
5. Make sure the relay's earth cable is in place.
6. Turn on the mains power.
7. Check the function of the new component.
8. Start the burner and check the combustion.



Use caution when operating the burner, surfaces may be hot.



When servicing/replacing components that affect combustion, an analysis and soot test must be carried out on the installation

5.7 Vibration

Maximum vibration level are 5,0 mm/s

- Check all bolts and nuts for correct torque
- Check fan wheel for damage and contamination. Change when dirty/unbalanced
- Check motor bearings. If worn change motor/bearings



Use lid screw
hole for sensor
mounting


6. Instructions Pump RSA95, RSA125

6.1 Technical data

| | RSA 95 | RSA 125 |
|--|-----------------------------|-----------------------------|
| Viscosity range:: | 1,3-18,0 mm ² /s | 1,3-18,0 mm ² /s |
| Pressure range at viscosity 1,3-1,8: | 5,5-12,0 bar | 5,5-12,0 bar |
| Pressure range at viscosity 1,8-18,0: | 2,5-21,0 bar | 2,5-21,0 bar |
| Oil temperature: | -10 till +70°C | -10 till +70°C |
| Nozzle capacity at viscosity 4,3: | 150-190 l/h | 215-260 l/h |
| Gear capacity: | 225 l/h | 294 l/h |
| Max pressure on the suction and return side: | 4 bar | 4 bar |

6.2 Components

1. Pressure gauge port G 1/8"
2. Nozzle outlet G 1/4"
3. Suction line G 1/4"
4. Suction line G 1/4"
5. Return line G 1/4"
6. Return line G 1/4"
7. Return plug
8. Pressure regulation 4 mm Allen key



6.3 Mounting/dismounting by-pass plug

In a 2-pipe-system excess oil is led back direct to the oil tank. In a 1-pipe-system the by-pass plug must be removed so that there is a free passage back to the suction side through the return line with the return port closed. (Pos.7).

6.4 Purging

On 1-pipe systems it is necessary to purge the pump. On 2-pipe systems purging is automatic through the return line.

6.5 Replacing the filter

Replace the oil filter on the oil pump as follows..

- Close the oil valves.
- Unscrew the cover (4 x 5 mm Allen screws).
- Replace the oil filter.
- Replace the cover gasket.
- Refit the cover.
- Open the oil valves.



165 105 54

6.6 Function Danfoss RSA 95 - 125

When the pump is started oil is drawn through the suction port "S" via filter "H" to the suction side of the gearwheel set "C". From here the gearwheel set pumps the oil to the pressure side and at the same time the oil becomes pressurized. The oil is led to cut-off and regulating valve "V" which opens when the set pressure is reached.

The pressure is controlled and kept constant by regulating valve "V". At the same time the gearwheel set "C" distributes the oil through nozzle port "P" and pump return side "R" via the shaft seal "F".

The quantity of oil supplied to nozzle port "P" is determined by the pressure set on regulating valve "V" and the nozzle/resistance in the nozzle line.

In 2-pipe-systems excess oil is led back to the oil tank. In 1-pipe-systems the by-pass plug "A" must be removed to give free flow back to the suction side via return line "G" with return port "R" closed.

When the pump is stopped, the pump output drops and produces a drop in the oil pressure. The spring in the regulating valve presses the regulating piston forward until it seals in port "P". This cuts off the oil flow to the nozzle and ensures that the nozzle line is effectively shut off.

If the pump is overloaded, i.e. more oil is demanded than the gearwheel is able to pump under the given conditions, the oil pressure falls below the set value because the piston of the regulating valve moves towards its closed position and partially or wholly cuts off the return oil via port "O".



This can be remedied by

- reducing the pump pressure
- reducing the capacity, i.e. smaller nozzle or greater resistance
- changing to a pump with higher capacity


Schematic diagram

- | | | |
|----|-------------------------------|---|
| 1. | Nozzle | Stage 1 |
| 2. | Nozzle | Stage 2 |
| 3. | Nozzle | Stage 3 |
| 4. | Solenoid valve | Stage 1 (Y1) |
| 5. | Solenoid valve | Stage 2 (Y2) |
| 6. | Solenoid valve | Stage 3 (Y3) |
| 7. | Safety valve for nozzle (Y1S) | Only for capacities over 100 kg/h or on special request by customer |
| 8. | Hydraulic control device | Only on burners with hydraulic air control or nozzle assembly optimisation. |
| 9. | Oil pump | |


Items 3 and 6 are not fitted to two-stage burners. Item 8 is connected after solenoid valve nozzle 2 (Y2).



6.7 Suction line tables



| 1-pipe system | | Pipe diameter | | |
|---------------|-------|---------------|-------|--|
| Höjd | | | | |
| H | ø12mm | ø15mm | ø20mm | |
| m | m | m | m | |



| 1-pipe system | | Pipe diameter | | |
|---------------|-------|---------------|-------|--|
| Height | | | | |
| H | ø12mm | ø15mm | ø20mm | |
| m | m | m | m | |

| Two-pipe system | | | | |
|-----------------|-------|---------------|-------|--|
| Height | | Pipe diameter | | |
| H | ø12mm | ø15mm | ø20mm | |
| m | m | m | m | |
| 4,0 | 81 | 100 | 100 | |
| 3,5 | 76 | 100 | 100 | |
| 3,0 | 71 | 100 | 100 | |
| 2,5 | 66 | 100 | 100 | |
| 2,0 | 61 | 100 | 100 | |
| 1,5 | 56 | 100 | 100 | |
| 1,0 | 51 | 100 | 100 | |
| 0,5 | 46 | 100 | 100 | |

With an underlying tank a 1-pipe-system is not recommended.

| Two-pipe system | | | | |
|-----------------|-------|---------------|-------|--|
| Height | | Pipe diameter | | |
| H | ø12mm | ø15mm | ø20mm | |
| m | m | m | m | |
| 0,0 | 41 | 100 | 100 | |
| -0,5 | 36 | 89 | 100 | |
| -1,0 | 31 | 77 | 100 | |
| -1,5 | 26 | 65 | 100 | |
| -2,0 | 22 | 53 | 100 | |
| -2,5 | 17 | 41 | 100 | |
| -3,0 | 12 | 29 | 91 | |
| -3,5 | 7 | 17 | 53 | |
| -4,0 | 2 | 5 | 15 | |

The suction line tables consist of theoretically calculated values where the pipe dimensions and oil velocity have been matched so that turbulences will not occur. Such turbulences will result in increased pressure losses and in acoustic noise in the pipe system.


In addition to drawn copper piping a pipe system usually comprises 4 elbows, a non-return valve, a cut-off valve and an external oil filter. The sum of these individual resistances is so insignificant that they can be disregarded.

The tables do not include any lengths exceeding 100 m as experience shows that longer lengths are not needed. The tables apply to a standard fuel oil of normal commercial quality according to current standards. On commissioning with an empty tube system the oil pump should not be run without oil for more than 5 min. (a condition is that the pump is being lubricated during operation).

The tables state the total suction line length in metres at a viscosity of 6,0 mm²/s.

7. Electrical equipment

7.1 Wiring diagram



7.2 Component list

| | | | |
|----|------------------------------|-----|---------------------------|
| A1 | Burner control | S30 | External reset |
| F1 | Fuse | T1 | Ignition transformer |
| M1 | Burner motor | X1 | Connection block |
| R1 | UV-detector | X20 | Connection terminal board |
| S1 | Operating switch | Y1 | Solenoid valve 1 |
| S3 | Rules/Operating thermostat | Y1S | Safety solenoid valve |
| S4 | Temperature/pressure limiter | | |
| S7 | Main switch | | |
| S8 | Air pressure switch | | |

8. Control








8.1 Technical data

| | BP230UVFR-S2 | BP230UVFR-S3 |
|---------------------------------|---------------|---------------|
| Pre-purge time (t1) | 30.7 s | 37.2 s |
| Pre-ignition time (t3) | 6 s | 2.5 s |
| Safety time (TSA) | 3 s | 5 s |
| Post-purge time (t6) | 16.8 s | 14.9 s |
| Reaction time for low interrupt | 1 s | 1 s |
| Ambient temperature BP | -40 to +60 °C | -40 to +60 °C |
| Ambient temperature UV5 | -20 to +60 °C | -20 to +60 °C |
| Max. current, terminals 6-7 | 2 A | 2 A |
| Max. current, other terminals | 1 A | 1 A |
| Ionisation current | 3-10 µA | – |

8.2 LED indicator lamps

BurnerPRO's burner control has seven LEDs which indicate the operating status of the control unit and the cause of the lockouts.

Each LED has an icon describing its function.

| | | |
|---|-------------------|---|
|  | FAN | Lights up when voltage is supplied to the fan motor (terminal 6) |
|  | OPEN DAMPER 6 | Flashes when the damper motor runs to maximum position. When the switch for the maximum damper motor position closes, this LED will light continuously. |
|  | CLOSE DAMPER 5 | Flashes when the damper motor runs to minimum position. When the switch for the minimum damper motor position closes, this LED will light continuously. |
|  | AUTO 4 | Lights up when the Burner control is in normal operating mode. |
|  | IGNITION 3 | Indicates ignition |
|  | FLAME 2 | Lights up when a flame is detected by the flame detector. |
|  | ALARM/STATUS | In lockout mode, the Alarm lamp lights up and the other LEDs light up to indicate lockout. Refer to "Fault codes". |

The LEDs can show the flame strength in Control mode by pressing the reset button for 3 seconds when the Flame LED flashes during start-up. In Control mode, the Status LED shines yellow, the Fan LED flashes, and LEDs 2-6 show the flame signal strength. Each LED corresponds to 20% of the total flame signal. 5 lit LEDs correspond to 100% and 2 LEDs correspond to 40%.








8.3 Explanation of the different sequence modes

1. **Operation**
This is the control unit voltage supply.
2. **System test**
In this status mode, the control unit undergoes an internal test to verify correct functionality of the hardware and software.
3. **Preconditions for burner start-up**
The control unit verifies that the air pressure switch is in the depressurised position and a test of the fuel cut-off valve is carried out.
4. **Heating requirement**
The operating thermostat closes and voltage is supplied to connection 5 so that the control unit can start the burner.
5. **Pre-purge begins**
The control unit starts the fan. Connections 6 and 7.
6. **Damper motor opens**
Control unit connection 9 sends a command to the damper motor to run at Max. mode. The control unit detects that the damper motor's end position switch indicates successful transition to the Max. load mode by supplying voltage to the connection 8 input. The control unit also performs a test to ensure that the air sensor detects airflow by monitoring connection 14.
7. **Pre-purge**
The combustion chamber is ventilated.
8. **Damper motor closes**
Following pre-purge, the control unit closes connection 10. The control unit detects that the damper motor is in the Low Load mode by supplying voltage to connection 8 on the control unit.
9. **Ignition on**
The control unit supplies voltage to the ignition transformer by activating connection 16.
10. **Fuel on** The control unit activates the fuel valve by supplying voltage to connections 17 and 18 as well as to direct ignition systems.
11. **Flame indication**
Ignition transformer turns off. The flame signal is tested during this stage. If no flame is detected, the burner enters Lockout mode.
12. **Operating mode**
Once a flame is stable, the control unit transitions to Operating mode. There must be a flame signal. Voltage is supplied to connection 20.
13. **Shutdown**
Shutdown occurs when the heating requirement is met and power is cut off to the operating thermostat connection 5. The control unit closes the fuel valves by cutting off power to outputs 18 and 20. The fan post-purges the combustion chamber.
14. **Lockout**
The control unit enters lockout mode when an internal or external fault is detected. The reset button and the remote-reset connection can be used to disable Lock mode. However, the control unit will revert to lockout mode if the fault is not rectified.

BURNER LOCKOUT

When lockout occurs, the LEDs indicate the cause. The control unit status is saved in the memory, even in the event of a power outage. By pressing the manual reset button on the control unit or remote reset.

8.4 BurnerPro LED fault/lock code table

| NO. | FAULT | LED 1 | LED 2 | LED 3 | LED 4 | LED 5 | LED 6 | LED 7 | POSSIBLE SOLUTION |
|-----|----------------------------------|---|---|---|---|---|---|---|---|
| | OPERATION LED ● = ON | | | | | | | Status | |
| | ICON |  |  |  |  |  |  |  | |
| 1 | DIAGNOSTIC ERROR, MAIN MCU INLET | ● | | | | | | RED | Initial diagnostic error. Ensure correct status of inputs and outputs when the unit is turned on. |
| 2 | LOCAL RESET | | ● | | | | | RED | User-initiated manual reset/lockout or defective reset switch. |
| 3 | AIR SENSOR | ● | ● | | | | | RED | Air sensor signal [connection 14] could not be detected by the end of the safety time, or loss of the air sensor signal during burner operation |
| 4 | DIAGNOSTIC ERROR | | | ● | | | | RED | "The system detected voltage at terminal 16, 17, 18, or 19 at the incorrect time, or no voltage detected when necessary. Check cabling and makes sure the system is running on a single line phase (50/60Hz)" |
| 5 | IONISATION FLAME LOSS | ● | | ● | | | | RED | Flame loss. Inspect the system, check the gas pressure, flame detector, cabling, etc. |
| 6 | IONISATION CIRCUIT FAULT | | ● | ● | | | | RED | Replace the control unit. Contact reseller/distributor. |
| 7 | INTERNAL COMMUNICATION ERROR | ● | ● | ● | | | | RED | Reset the system to continue normal operation. Contact reseller/distributor if the fault persists. |
| 8 | REMOTE RESET | | | | ● | | | RED | The user has pressed Remote Reset or the remote controller has short-circuited. |
| 9 | IONISATION FAULT | ● | | | ● | | | RED | Replace the control unit. Contact reseller/distributor. |
| 10 | MAIN PROGRAM SEQUENCE ERROR | | ● | | ● | | | RED | Replace the control unit. Contact reseller/distributor. |
| 11 | RAM TEST | ● | ● | | ● | | | RED | Replace the control unit. Contact reseller/distributor. |
| 12 | PROGRAM SEQUENCE ERROR | | | ● | ● | | | RED | Replace the control unit. Contact reseller/distributor. |
| 13 | READING ERROR INPUT | ● | | ● | ● | | | RED | Check cabling and makes sure the system is running on a single phase (50/60Hz) |
| 14 | TIMER2 ERROR | | ● | ● | ● | | | RED | Replace the control unit. Contact reseller/distributor. |
| 15 | CPU TEST FAILED | ● | ● | ● | ● | | | RED | Replace the control unit. Contact reseller/distributor. |
| 16 | FLAME LOSS | ● | | | | ● | | RED | Visually inspect the flame detector and confirm that the pilot light was lit during start-up. Check the fuel supply system. |

| NO. | FAULT | LED 1 | LED 2 | LED 3 | LED 4 | LED 5 | LED 6 | LED 7 | POSSIBLE SOLUTION |
|-----|--------------------------------------|-------|-------|-------|-------|-------|-------|-------|--|
| 17 | CABLE FAULT | | ● | | | ● | | RED | The system detected voltage at terminal 16, 17, 18, or 19 at the incorrect time, or no voltage detected when necessary. Check cabling and makes sure the system is running on a single phase (50/60Hz) |
| 18 | SAFETY RELAY FAULT | ● | ● | | | | | RED | Replace the control unit. Contact reseller/distributor |
| 19 | FUEL VALVE OPEN | | | ● | | ● | | RED | Check fuel valve cabling. The valves may not be fully closed. |
| 20 | FLAME LOSS | ● | | ● | | ● | | RED | Visually inspect the flame detector and confirm that the main flame was lit during start-up. Check the fuel supply system. |
| 21 | WELDED SAFETY RELAY | | ● | ● | | ● | | RED | Replace the control unit. Contact reseller/distributor. |
| 22 | SELF TEST | ● | ● | ● | | | | RED | Replace the control unit. Contact reseller/distributor. |
| 23 | ROM ERROR | | | | ● | ● | | RED | Replace the control unit. Contact reseller/distributor. |
| 24 | FLAME LOSS DURING OPERATION | ● | | | ● | ● | | RED | Check the cabling. Check the flame detector. Check the fuel supply system. |
| 25 | RAM ERROR | | ● | | ● | ● | | RED | Replace the control unit. Contact reseller/distributor. |
| 26 | INTERNAL FAULT | ● | ● | | ● | ● | | RED | Replace the control unit. Contact reseller/distributor. |
| 27 | NOT USED | | | | | | | | |
| 28 | NOT USED | | | | | | | | |
| 29 | AMBIENT TEMPERATURE | | ● | ● | ● | ● | | RED | Ambient temperature below -40 °C or above 70 °C |
| 30 | ROM ERROR | ● | ● | ● | ● | ● | | RED | Replace the control unit. Contact reseller/distributor. |
| 31 | IONISATION SHORT-CIRCUIT | | | | | | ● | RED | Possible external short-circuit between terminals 23 and 24. Contact reseller/distributor if the fault persists. |
| 32 | TIME LIMIT EXCEEDED FOR CONTROL MODE | ● | | | | | ● | RED | 30-minute activation time passed. |
| 33 | STANDBY FALSE FLAME | | ● | | | | | RED | False flame detected in Standby mode. |
| 34 | NOT USED | | | | | | | RED | |
| 35 | INTERNAL RESET | | | ● | | | ● | RED | Internal software reset of control unit. Contact reseller/distributor if the fault persists. |
| 36 | SOFTWARE RESET | ● | | ● | | | ● | RED | Internal software reset of control unit. Contact reseller/distributor if the fault persists. |
| 37 | WAITING TIME INPUTS | | ● | ● | | | ● | RED | The system was unable to perform airflow sensor test and/or valve closure test. Check the cabling. Check the air sensor and/or fuel valve switch. |
| 38 | INTERNAL RESET | ● | ● | ● | | | ● | RED | Internal software reset of control unit. Contact reseller/distributor if the fault persists. |

| NO. | FAULT | LED 1 | LED 2 | LED 3 | LED 4 | LED 5 | LED 6 | LED 7 | POSSIBLE SOLUTION |
|-----|--------------------------------------|-------|-------|-------|-------|-------|-------|-------|--|
| 39 | SOFTWARE RESET | | | | ● | | ● | RED | Internal software reset of control unit. Contact reseller/distributor if the fault persists. |
| 40 | HARDWARE RESET | ● | | | ● | | ● | RED | Replace the control unit. Contact reseller/distributor if the fault persists. |
| 41 | HARDWARE RESET | | ● | | ● | | ● | RED | Replace the control unit. Contact reseller/distributor if the fault persists. |
| 42 | CONTROL PROGRAM FROZEN | ● | ● | | ● | | ● | RED | Replace the control unit. Contact the distributor/factory. |
| 43 | CONTROL PROGRAM FROZEN | | | ● | ● | | ● | RED | Replace the control unit. Contact reseller/distributor. |
| 44 | TIMER2 ERROR | ● | | ● | ● | | ● | RED | Replace the control unit. Contact reseller/distributor. |
| 45 | LOW VOLTAGE ERROR | | ● | ● | ● | | ● | RED | Check mains power. Contact reseller/distributor if the fault persists. |
| 46 | LOW VOLTAGE ERROR | ● | ● | ● | ● | | ● | RED | Check mains power. Contact reseller/distributor if the fault persists. |
| 47 | UV DETECTION FAULTY | | | | | ● | ● | RED | Replace the control unit. Contact reseller/distributor. |
| 48 | INTERNAL FAULT | ● | | | | ● | ● | RED | Replace the control unit. Contact reseller/distributor. |
| 49 | INTERNAL FAULT | | ● | | | ● | ● | RED | Replace the control unit. Contact reseller/distributor. |
| 50 | IGNITION FEEDBACK | ● | ● | | | ● | ● | RED | The system detected voltage at terminal 16 at the incorrect time, or no voltage. Check cabling and ensure sufficient earthing. |
| 51 | PILOT FEEDBACK | | | ● | | ● | ● | RED | The system detected voltage at terminal 17 at the incorrect time, or no voltage. Check cabling and ensure sufficient earthing. |
| 52 | MAINP FEEDBACK | ● | | ● | | ● | ● | RED | The system detected voltage at terminal 19 at the incorrect time, or no voltage. Check cabling and ensure sufficient earthing. |
| 53 | WAITING TIME FEEDBACK LIMIT EXCEEDED | | ● | ● | | ● | ● | RED | Loss of feedback from the damper motor for more than 10 minutes. Check the cabling. Check the damper motor. |
| 54 | MAIND FEEDBACK | ● | ● | ● | | ● | ● | RED | The system detected voltage at terminal 18 at the incorrect time, or no voltage. Check cabling and ensure sufficient earthing. |
| 55 | DIAGNOSTICS INTERRUPTED | | | | ● | ● | ● | RED | Replace the control unit. Contact reseller/distributor. |
| 56 | UV FALSE FLAME | | | ● | ● | ● | ● | RED | False flame detected prior to ignition. Check the cabling. Check the flame detector. Ensure sufficient earthing. |
| 57 | IONISATION FALSE FLAME | | | ● | ● | ● | ● | RED | False flame detected prior to ignition. Check the cabling. Check the flame detector. Ensure sufficient earthing. |
| 58 | OPEN FEEDBACK READING | | ● | ● | ● | ● | ● | RED | The system detected voltage at terminal 8 at the incorrect time, or no voltage. Check cabling and ensure sufficient earthing. |

| NO. | FAULT | LED 1 | LED 2 | LED 3 | LED 4 | LED 5 | LED 6 | LED 7 | POSSIBLE SOLUTION |
|-----|-----------------------------|-------|-------|-------|-------|-------|-------|-------|--|
| 59 | ADJACENT POLE SHORT-CIRCUIT | ● | | | ● | ● | ● | RED | Replace the control unit. Contact reseller/distributor. |
| 60 | LOCAL RESET | ● | ● | ● | ● | ● | ● | RED | The local reset button has been pressed in for more than 10 seconds, or the reset button is stuck. |
| 61 | FUEL VALVE OPEN | | ● | | ● | ● | ● | RED | Fuel valve open at incorrect time. |
| 62 | STRONG UV FLAME | ● | ● | | ● | ● | ● | RED | Flame detector too close to the flame. Increase the distance between the flame detector and the flame. |
| 63 | INTERNAL FAULT | | | | | ● | | RED | Replace the control unit. Contact reseller/distributor. |

9. Fault Location

9.1 Burner will not start

| Symptom | Causes | Remedies |
|-----------------------|---|--|
| Motor starts | Unstable flame | Adjust the damper |
| Burner pre-ventilates | Excess air | Check the oil pressure |
| | Low oil pressure | Check the nozzle in relation to the combustion apparatus dimensions and the ignition electrode position |
| Flame formed | Incorrect combustion apparatus settings | Check the flame monitor is clean and can register light |
| Burner trips | Flame monitor does not register light | Check with using new photocell |
| | Defective flame monitor | Check using new oil burner control (Note: replacement of photocell recommended if oil burner control replaced) |
| Motor starts | Defective oil burner control | Check the oil supply to the burner and that there are no air bubbles in the pump |
| Burner pre-ventilates | | Check function of solenoid |
| No flame formed | No oil | Check flame monitor does not register ambient light |
| Burner trips | False light | Check high voltage wiring and ignition electrodes |
| | No spark | Check preheater function |
| Motor does not start | Preheater does not get up to temperature. | |

9.2 Burner will not start after normal use

| Symptom | Causes | Remedies |
|-----------------------|---|---|
| Burner does not start | Fuse blown | Check and replace fuse as necessary. Investigate cause of fault |
| | Boiler thermostat has not reset | Adjust thermostat |
| | Preheater does not get up to temperature | Check preheater function |
| Burner pre-ventilates | Overheating protection has deployed | Reset the overheating protection. Investigate the cause of its deploying. Remedy fault |
| | Defective preheater | Check by replacing with new |
| | Defective oil burner control or flame monitor | Check that tank, oil lines, solenoid valves, pump and nozzle are in good condition |
| Burner stops | No oil supply | Adjust the burner |
| | Too great a pressure drop at brake plate | Correct the boiler draught |
| | Too strong draught prevents flame forming | Check the ignition transformer. Check the ignition electrode settings and ceramics |
| | No spark | Check preheater function |
| | Preheater temperature too low | Adjust the preheater's set operating temperature |
| | New oil type | Check that the oil used has the physical parameters that the burner is rated for. If not, change the oil. |

9.3 Delayed ignition

| Symptom | Causes | Remedies |
|--|--|---|
| Burner pulsates at start with hot flue gases | Excessively strong draught | Correct boiler draught |
| | Excessive pressure drop across the brake plate | Adjust the burner |
| | Preheater temperature too low | Check preheater function |
| | New oil type | Adjust the preheater's set operating temperature |
| | | Ensure that the new oil's physical parameters are within the limits for which the burner is designed. If not, change the oil. |
| Burner pulsates at start | Nozzle partially blocked | Replace nozzle |
| | Oil pressure too low | Check and adjust |
| | Flue is blocked or damaged | Check and correct |
| | The fan wheel is slipping on the shaft | Check and tighten |
| | Pump coupling loose or worn | Replace |
| | Preheater blocked | Check the ignition electrode setting, (see technical data) |
| | Delayed ignition | Check that the ignition electrodes are not damaged |
| | Excessively strong draught | Check high voltage cables |
| | | Check position of nozzle assembly setting |
| | | Correct boiler draught |
| | Excessive pressure drop across the brake plate | Adjust the burner |
| | Preheater temperature too low | Check preheater function |
| | New oil type | Adjust the preheater's set operating temperature |
| | | Ensure that the new oil's physical parameters are within the limits for which the burner is designed. If not, change the oil. |

9.4 Noise in pump

| Symptom | Causes | Remedies |
|--|---|---|
| The burner pump emits noise during start | Insufficient negative pressure on the suction side pump | Check the oil system in order to reduce pressure drop |
| | | Rebuild the oil system to form a solution with a transport oil pump |
| | | Check that the oil used has the physical parameters that the burner is rated for. If not, change the oil. |
| | | Temperature of the oil from the tank is too low, increase the temperature of oil from tank |
| | | Clean the pump filter |
| The burner pump emits noise during operation | | |

9.5 Pump pressure

| Symptom | Causes | Remedies |
|---|--|--|
| The burner pump can not build up pressure | No oil | Check that there is oil and that it reaches the pump |
| | Oil viscosity too low | Check that the oil reaching the pump has the physical parameters that the pump can handle. Change the oil or the pump's oil parameters |
| | Pump worn | Replace the pump |
| | Pump run using impure oil that has worn the pump out prematurely | Replace pump and install self-cleaning filter in the oil system |
| | Blocked pump filter | Check, clean pump filter |

10. Log of flue gas analysis

| | | |
|--------------|---------|----------|
| Owner | Adresss | Tel. no: |
| | | |
| Installation | | Tel. no: |

Boiler

| | | |
|------|------|----------|
| Type | Make | Power kW |
|------|------|----------|

Bentone Burner

| | | | |
|------|-------|------------|------|
| Type | Model | Serial no. | Fuel |
|------|-------|------------|------|

| | Step 1 | Step 2 | Step 3 |
|----------------------|--------|--------|--------|
| Draught in fireplace | | | |
| Fan Press mbar | | | |
| Filter smoke number | | | |
| CO ₂ | | | |
| O ₂ | | | |
| NOx | | | |
| CO | | | |
| Flue gas temp. °C | | | |
| Setting brake disc | | | |
| Setting Air damper | | | |
| Pump pressure bar | | | |
| Nozzle | | | |

| | |
|---------------------|----------------|
| Test performed / 20 | Address |
| Test performed by: | Postal address |
| Company name: | Tel. no: |

11. Oil burners maintenance instructions

General information

Keep the boiler room clean. Ensure that the boiler room has permanent fresh air intake. Switch off before dismantling the oil burner.

At hinged mounting, make sure that an automatic safety switch is fitted, so that the burner cannot start when the swing door is open.

Don't use the oil fired boiler to burn paper or rubbish, unless the boiler is especially fitted with a hinged door to make this possible.

Don't fill tank while burner is working.

Starting precautions

Make sure that the oil tank is not empty

Make sure that the valves on oil and water supply pipes are open.

Make sure that the boiler flue damper is open.

Make sure that the boiler thermostat is set at the correct temperature.

Switch on the current. Most relay systems have a delayed action so that the burner will not start for perhaps 20 seconds.

With heavy oil the delay will be longer as the burner will not start until the oil in the preheater reaches the required temperature.

If the burner will not start

Press the reset button on the relay. Check that the thermostats are correctly adjusted.

Don't forget the room thermostat, check that any fuses are intact and main switch is on.

If the burner starts but does not ignite

Make an attempt to start the burner.

Never make close repeated start attempts.

Don't restart the burner until the boiler is free from oil gases.

If the burner still does not ignite send for the service engineer.

When switching off during summer

Always use the main switch to cut out the burner even when adjusting the burner or cutting off the heating for a short time. For longer periods of shut down, close all valves and the oil supply stopcock.

Clean the filter and nozzle by washing in petrol or paraffin.

Make sure the filter medium is not damaged or defective.

Protect electrical gear from damp.

Warning

Never stand too near or put your face to the inspection or fire door, when the burner is about to start.

Never use a naked flame to ignite oil if the electrical ignition fails.

Always wait for about 10 minutes for the unburnt gases to disperse before restarting the oil burner if it has failed to ignite previously.

Installed by:

.....

Tel:

EU Declaration of conformity



Bentone Oil Burners

Type

| | | | |
|---------------|---------------|-------------|-------------|
| BF 1 | ST 146 | B 45 | B 80 |
| ST 108 | B 2 | B 55 | |
| ST 120 | B 30 | B 65 | |
| ST 133 | B 40 | B 70 | |

This declaration of conformity is issued under the sole responsibility of the manufacturer. The object of the declaration described above is in conformity with:

Machinery Directive 2006/42/EC

EMC 2014/30/EU

Restriction of the use of certain hazardous substances (RoHS) Directive 2011/65/EU

References to the relevant harmonised standards used or references
to the other technical specifications in relation to which conformity is declared:

EN 267:2009+A1:2011 Excluded Annex J/K. Automatic forced draught burners for liquid fuels.

Additional information can be downloaded at:
www.bentone.com

Enertech AB
Box 309
S-341 26 LJUNGBY

Ljungby, January 26th 2021

Helene Richmond
Managing Director
Enertech AB

