

Providing sustainable energy solutions worldwide

Installation- and maintenance instruction

BF 1 KSV RME

LMO14.113C2E

ANV47C



-sv

1. Manualer på övriga språk

2. [www.bentone.com\download](http://www.bentone.com/download) eller scanna QR-koden.

3. Skriv in brännarens artikelnummer som finns på din typskylt (se bild) och välj ditt språk.

Detaljerad ecodesign information kan laddas ner på:
www.bentone.com/ecodesign.

-fr

1. Manuels dans d'autres langues

2. [www.bentone.com\download](http://www.bentone.com/download) ou scannez le code QR.

3. Saisir le numéro d'article du brûleur sur votre plaque signalétique (consultez l'illustration) et sélectionnez la langue.

Des informations détaillées sur l'ecodesign peuvent être téléchargées à l'adresse:
www.bentone.com/ecodesign.



-en

1. Manuals in other languages

2. [www.bentone.com\download](http://www.bentone.com/download) or scan QR-code.

3. Enter the burner's article number on your data plate (see picture) and select language.

Detailed ecodesign information can be downloaded at:
www.bentone.com/ecodesign.

-de

1. Gebrauchsanweisungen in anderen Sprachen

2. [www.bentone.com\download](http://www.bentone.com/download) oder scannen Sie den QR-Code.

3. Geben Sie die Artikelnummer des Brenners auf Ihrem Typenschild ein, (siehe Bild) und wählen Sie die Sprache aus.

Detaillierte Informationen zum Ecodesign können unter www.bentone.com/ecodesign heruntergeladen werden.

3. exempel example Beispiel

352011030141	Serial no. 1234567	Man.Year 2019
Designation	BF 1 KS 76-24	
Type	BF 1	
Model	BF 1 KS 76-24	
Cap. Min-Max	LIGHT OIL 35-90KW 1,25-6,0 cSt 7-14bar	
Main supply	1-230V 1,0A 50Hz IP 20	
Motor supply		
MADE IN SWEDEN BY		

-da

1. Manualer på andre sprog

2. [www.bentone.com\download](http://www.bentone.com/download) eller scan QR-koden.

3. Indtast brænderens artikelnummer, der findes på typeskiltet (se billede), og vælg dit sprog.

Detaljerede oplysninger om ecodesign kan downloades på:
www.bentone.com/ecodesign.

Table of contents

1. Safety Information	4
2. Technical data	8
2.1 Model BF 1 KS/KSV 76-24	9
2.2 Recommended nozzles and pressures	10
2.3 Description	11
3. Installation	13
3.1 Delivery checks	13
3.2 Preparations for installation	13
3.3 Oil supply	13
3.4 Electrical connection	13
3.5 Choice of nozzle	13
3.6 Brake plate and airflow setting	13
3.7 Burner installation	14
4. Basic settings	15
4.1 Example of basic setting	15
5. Burner servicing	18
5.1 Warning	18
6. Pump Instructions	27
6.1 Suntec ANV47C	27
7. Preheater	31
8. Oil Burner Control	32
8.1 Wiring diagram	32
8.2 Function LMO14/24	33
8.3 Colour codes LMO14/24	34
8.4 Fault codes LMO14/24	34
9. Fault Location	35
9.1 Burner will not start	35
9.2 Burner will not start after normal use	35
9.3 Delayed ignition	36
9.4 Noise in pump	36
9.5 Pump pressure	37
10. Log of flue gas analysis	38
11. Oil burners maintenance instructions	39

1. Safety Information

This Installation and Maintenance manual:

- is to be regarded as part of the burner and must always be kept near the installation site
- is intended for use by authorised personnel
- must be read prior to installation
- must be observed by all who work with the burner and associated system components
- work with the burner may only be carried out by certified installers/ personnel
- Enertech AB is not liable for any typographical errors and reserves the right to make design changes without prior notice.
- The burner may only be used for its intended purpose in accordance with the product's technical data.
- The burner may only be installed and operated by authorised personnel.
- The product is packaged to prevent damage from occurring during handling. Handle the product with care. Lifting equipment must be used to lift larger packages.
- The products must be transported/stored on a level surface in a dry environment, max. 80% relative humidity, no condensation. Temperature -20 to +60 °C.
- Check that the burner is compatible with the boiler's output range.
- The label information on the rating plate refers to the burner's minimum and maximum power.
- All components must be installed without being bent, twisted or subjected to mechanical or thermal forces which can affect the components.
- The burner must be installed so that it complies with local regulations for fire safety, electrical safety, and fuel distribution.
- Make sure when installing the equipment that there is enough space to service the burner.
- Permitted ambient temperature during operation 0 to +60 °C. Max 80% relative humidity, no condensation.
- The installer must ensure that the room has adequate air supply.
- The room must comply with local regulations pertaining to its intended use.
- The installation site must be free of chemicals.
- Burner tubes, fan wheels and air dampers may contain sharp edges.
- The surface temperature of the burner's components can exceed 60 °C.
- Caution: The burner has moving parts, and there is risk of crushing injuries.
- The electrical installation must be professionally carried out in accordance with applicable high voltage regulations, as per Enertech's recommendations.



- Before service, shut off the fuel supply and turn off the power to the burner.
- Leak checks must be performed during installation and service to prevent fuel leakage.
- Care should be taken by the installer to ensure that no electrical cables or fuel lines are crushed or otherwise damaged during installation or service.
- If the boiler is equipped with an access hatch, this must be equipped with a hatch opening switch connected to the burner's safety system.
- When in operation, the burner's noise level can exceed 85 dBA. Use hearing protection.
- The burner must not be put into operation without proper safety and protection devices.
- Fire extinguisher with Class BE recommended.
- Modifying the design or using accessories that have not been approved by Enertech in writing is strictly prohibited.
- Prior to operation, the following points must be checked:
 - fitting and installation work has been completed and approved
 - electrical installation has been correctly performed
 - flue gas ducts and combustion air ducts are not blocked
 - all actuators and control and safety devices are in working order and correctly set
- After commissioning
 - If the gas burner control has a solid red light, contact your installer.



General requirements RME

This is a burner designed for FAME, B-100 (RME) fuel. The fuel must meet the requirements of standard EN 14214 for FAME.

The fuel must be stored and used according to the manufacturer's instructions. It should typically be used within 6 months of manufacture. Fuel that is allowed to age loses its oxidation stability and produces aggressive constituents. These cause oxidation damage to components in the oil system. The fuel should be stored in a cool area to minimise these problems.

The RME cistern must be made of metal or dark coloured plastics approved for the fuel.

The design of the equipment on the burner permits the use of EO1 type oil without modification, although with appropriate adjustments to the combustion after changing the fuel type.

Oil burners must be installed in accordance with local regulations. The installer must therefore be knowledgeable of the regulations pertaining to oil and combustion.

Installation should be carried out as a one-pipe system and used together with the bleeder to vent the system, and an appropriate filter must also be in place. Copper should be avoided in RME fuel systems since the fuel and copper have an oxidising effect on each other.

Only oil suitable for the burner must be used and then in combination with a suitable oil filter designed for FAME, B-100 (RME) and installed before the burner's oil pump.

The tank should be cleaned and the water should be checked regularly to prevent problems related to corrosion and microorganisms. This should be done once a year.

If the burner is replacing an existing burner, ensure that the oil filter is changed to a filter designed for FAME, B-100 (RME). Installation may only be performed by qualified personnel.

Care should be taken by the installer to ensure that no electrical cables or oil/gas pipelines are crushed or damaged during installation or service.

Burners that run on FAME, B-100 (RME) fuel are and must be equipped with parts designed for this fuel. This applies in particular to oil-related parts such as the pump, solenoid valve, oil filter and hoses with fire-retardant sleeves. It is very important when carrying out a service to replace old parts with new parts of the same quality.

Maintenance

The boiler/burner must be checked regularly for faults or leakage. Any boiler/burner that uses FAME (RME) fuel must be serviced at least twice a year. It is very important that worn parts are replaced at the time of servicing with new parts of the same quality.

Oil hoses must be of high-quality fluoride rubber or PTFE intended for FAME, B-100 (RME).

The hoses must be fitted with fire-retardant sleeves in order to satisfy requirements according to EN-ISO 6806.

Burner service schedule

Servicing must be carried out twice a year or after 3,000 hours of operation.

Burner	Twice a year	3,000 h
Filter	Twice yearly replacement	3,000 h replacement
Oil hose	Once yearly replacement	
Nozzle	Twice yearly replacement	3,000 h replacement
Electrodes	Replace/Clean twice a year	Replace/Clean 3,000 h
Brake disc	Replace/Clean twice a year	Replace/Clean 3,000 h
Motor	Twice a year	3,000 h
Drive shaft	Check/replace in the event of damage	Check/replace in the event of damage
Fan wheel	Twice a year Replace if need for cleaning/imbalance	3,000 h Replace if need for cleaning/imbalance
Tank	Check for water once a year Clean tank once a year	
Oil filter	Twice a year	3,000 h replacement
Oil valve	Tightness check twice a year	Replace if leaky

Component replacement intervals

Components	Service life – Recommended replacement	Service life – Recommended replacement Operating cycles
Control system	10 years	250,000 cycles
Pressure switch	10 years	250,000 cycles
Ignition system with flame guard	10 years	250,000 cycles
UV flame sensor	10,000 h	N/A
Damper motor		500,000 cycles
Contactator	10 years	500,000 cycles



The burner and its components must be recycled according to applicable regulations.

Delivery check

- Make sure everything is delivered and the goods have not been damaged during transit.
- If something is wrong with a delivery, report it to the supplier.
- Transport damage must be reported to the shipping company.

2. Technical data


The burner is intended for:

- Light oil, B10 heating oil/biofuel blend, FAME, B-100 (RME) (as defined in DIN V51603-6).

and is used for:


- Water heating generators.
- Hot air generators (these require LMO 24 255 C2E).

Dimensions BF 1




Dimensions, flanges

Flange 1



Flange 2



Electrical specification EN 60335-2-102

Type	BF 1
Electrical data, Control power	230V 1~ 1,1/1,5A 50/60Hz IP20
Electrical data, Motor	-
Max fuse rating	10A
Noise level	70 dBA

Max operating current, see data plate.

165 305 56

2.1 Model BF 1 KS/KSV 76-24




Length of blast tube	Protrusion from flange, measurement B	
	Flange 1	Flange 2
147	130	114
224	207	191

Working area/Basic settings


3.0-7.6 kg/h
35-90 kW

mbar



! Do not exceed the working area.

Scale
 - - - - - Air settings
 ————— Nozzle assembly



! Scale value applies to 0 mbar furnace pressure.

2.2 Recommended nozzles and pressures

Because of the different types of boiler in existence, with varying furnace geometries and furnace loads, it is not possible to commit to any given spray angle or spray pattern. Note that spray angles and spray patterns change with pump pressures.

Nozzle	60° Solid/Hollow cone
	80° Solid/Hollow cone
Pump pressure	10 bar (8–14 bar) Fuel oil 1
	10 bar (7–12 bar) Kerosene

Nozzle table, 8-15 bar

Gph	Pump pressure, bar															
	8		9		10		11		12		13		14		15	
	kg/h	kW	kg/h	kW	kg/h	kW	kg/h	kW	kg/h	kW	kg/h	kW	kg/h	kW	kg/h	kW
0,40	1,33	16	1,41	17	1,49	18	1,56	18	1,63	19	1,70	20	1,76	21	1,82	21
0,50	1,66	20	1,76	21	1,86	22	1,95	23	2,04	24	2,12	25	2,20	26	2,28	27
0,60	2,00	24	2,12	25	2,23	26	2,34	28	2,45	29	2,55	30	2,64	31	2,73	32
0,65	2,16	26	2,29	27	2,42	29	2,54	30	2,65	31	2,75	33	2,86	34	2,96	35
0,75	2,49	29	2,65	31	2,79	33	2,93	35	3,08	36	3,18	38	3,30	39	3,42	40
0,85	2,83	33	3,00	36	3,16	37	3,32	39	3,47	41	3,61	43	3,74	44	3,87	46
1,00	3,33	39	3,53	42	3,72	44	3,90	46	4,08	48	4,24	50	4,40	52	4,56	54
1,10	3,66	43	3,88	46	4,09	48	4,29	51	4,48	53	4,67	55	4,84	57	5,01	59
1,20	3,99	47	4,24	50	4,47	53	4,68	55	4,89	58	5,09	60	5,29	63	5,47	65
1,25	4,16	49	4,40	52	4,65	55	4,88	58	5,10	60	5,30	63	5,51	65	5,70	68
1,35	4,49	53	4,76	56	5,02	59	5,27	62	5,50	65	5,73	68	5,95	70	6,15	73
1,50	4,98	59	5,29	63	5,58	66	5,85	69	6,11	72	6,36	75	6,60	78	6,83	81
1,65	5,49	65	5,82	69	6,14	73	6,44	76	6,73	80	7,00	83	7,27	86	7,52	89
1,75	5,82	69	6,18	73	6,51	77	6,83	81	7,14	85	7,42	88	7,71	91	7,97	94
2,00	6,65	79	7,06	84	7,45	88	7,81	93	8,18	97	8,49	101	8,81	104	9,12	108
2,25	7,49	89	7,94	94	8,38	99	8,78	104	9,18	109	9,55	113	9,91	117	10,26	122


The table applies to oils with a viscosity of 4.4 mm²/s (cSt) at a density of 830 kg/m³.

Burner with preheater

Allow for a reduction in oil quantity of 5–20% with preheating owing to:



- Temperature increases at the nozzle.
- Nozzle design.
- Capacity (the higher the capacity the lower the difference).

2.3 Description



Components

- | | |
|--|--------------------------------|
| 1. Brake plate | 13. Photoresistor |
| 2. Nozzle | 14. Inspection glass |
| 3. Fan housing, front | 15. Nozzle assembly adjustment |
| 4. Ignition transformer | 16. Cover plate |
| 5. Separating screw | 17. Blast tube |
| 6. Oil burner control | 18. Grid |
| 7. Electrical contact X1 (refer to wiring diagram) | 19. Solenoid valve |
| 8. Motor | 20. Oil pump |
| 9. Capacitor | 21. Air regulator |
| 10. Preheater, where fitted | 22. Air intake |
| 11. Ignition electrode | 23. Air flow indicator |
| 12. Ignition cable | 24. Fan housing, rear |



3. Installation

3.1 Delivery checks

Check that everything has been delivered and that the goods are not transport damaged. Any delivery faults must be reported to the supplier. Transport damage must be reported to the forwarder.

3.2 Preparations for installation

Check that the burner's measurements and capacity range is suitable for the boiler in question. The power information on the data plate refers to the burner's max. and min. power.

3.3 Oil supply

In order to achieve good operational reliability it is important that the oil supply system is laid out correctly.

Observe the following:

- Choice of pipe diameters, pipe lengths and height differences (refer to pump instructions).
- Piping should be run with a minimum of joints/compression fittings.
- Pipework must be laid out so that oil hoses are not subjected to tension or overbending when the burner is swung out or removed for service.
- The oil filter should be installed so that the filter cartridge can easily be replaced

3.4 Electrical connection

Before electrical installation is begun, electricity must be switched off at the main switch. If the boiler has a 7-pole or a 4-pole Eurostecker (only on 2-stage burners), these often fit directly to the burner. Otherwise use the connectors supplied. The operating thermostat, the max. thermostat and the inspection hatch (where fitted) interlock can then be wired in series on the incoming phase connected to L1 or connected between T1 and T2. In the first mentioned case a jumper is installed between T1 and T2. (Refer to connection in the section Electrical equipment).



If any electrical connection is used other than that recommended by Enertech, there may be a risk of equipment damage and personal injury.

3.5 Choice of nozzle

(Technical data): Recommended nozzle and nozzle table.

3.6 Brake plate and airflow setting

Before operations basic burner setting may be made according to the diagram. (Refer to basic settings). Note that this only refers to the basic setting; the setting must be adjusted after the burner has been started. At this time flue gas analysis and soot measurement must be carried out.


3.7 Burner installation

3.7.1 Hole pattern

Check that the hole pattern matches the flange supplied.
(Refer to Technical data.)


3.7.2 Burner installation

1. Install the flange and the gasket on the boiler.
2. Attach the front piece to the flange.
3. Insulate between the burner register and the boiler cover for reduced heat radiation.
4. Install the selected nozzle. (Refer to Technical data.)
5. Install the brake plate and check the ignition electrodes (refer to Burner service.).
6. Install the burner body to the front piece and lock with screw (E).



3.7.3 Oil pipes


1. Check the oil pipe dimensions. (Refer to Pump Instructions.)
2. The oil filter should be installed in the oil supply line. If an air separator is fitted, the oil filter should be installed before the air filter to increase the life span of the filter.
3. For one-pipe systems the return plug must be removed. (Refer to Pump Instructions.)
4. When installing oil hoses, check that the supply and return hoses are connected to the correct connections on the oil pump. The hoses must be run so that they are not bent or tensioned.
5. Purge the oil system. The oil pump will be damaged if it is run dry.
6. The vacuum should not be lower than 0.3 bar depression in the suction line at start up.



3.7.4 Electrical connection

If the boiler lacks ready-connected plugs, connect using the supplied plug, X2 in accordance with the wiring diagram.

1. Disconnect the power at the main switch.
2. Wire the Eurostecker X2 as in alt. 1–3 (refer to Electrical equipment).
3. Connect the Eurostecker X2 to the burner.
4. Switch on the power at the main switch.



4. Basic settings

4.1 Example of basic setting

4.1.1 Choice of nozzle

BF1 FU 63-16

Burner output	30 kW
Estimated nozzle output:	$30 / 11,86^* = 2,53 \text{ kg/h}$

Choice of nozzle according to table. (Refer to Technical data.)

According to the nozzle table, the following nozzle is indicated:

Nozzle:	0,65 Gph
Pump pressure:	11,0 bar

BF1 FU 63-16/FUV 63-16

Burner output	30 kW
---------------	-------

Because of preheater, output is adjusted upward for choice of nozzle according to table.

Estimated nozzle output:	$30 \times 1,06 = 31,8 \text{ kW}$
	$31,8 / 11,86^* = 2,68 \text{ kg/h}$

Choice of nozzle according to table. (Refer to Technical data.)

According to the nozzle table, the following nozzle is indicate

Nozzle:	0,75 Gph
Pump pressure:	9,5 bar
* Calorific value Light oil	$= 11,86 \text{ kWh/kg}$

4.1.2 Basic setting

Setting values for 30 kW according to basic settings tables.
(Refer to Technical data FU 63-16).

Air setting	=	11,0
Insert setting	=	4,0

4.1.3 Nozzle assembly adjustment

The burner is fitted with a regulator which changes the brake plate position in the blast tube. This is used to set the correct pressure drop across the combustion assembly and thereby achieve good combustion without pulsation.

The setting to be chosen is dependent among other things on set output and furnace pressure.

Brake plate setting


- Less diffusion: turn screw to left.
- More diffusion: turn to right.

Setting brake plate position affects air flow. It is therefore always necessary to adjust the air with the burner air regulator afterwards.





4.1.4 Air intake adjustment

Air settings are very important for achieving good combustion with neither too much, nor too little, air. Adjustment of combustion airflow is carried out by turning the air regulator with an Allen key. How far open the air regulator must be is determined by output, furnace pressure and other burner settings such as blast tube position.




4.1.5 Method of adjusting air quantity

Setting the air regulator is dependent on how the screw (with which air regulation is adjusted) is installed. If the air intake is installed underneath as shown in illustration I, turning the screw clockwise will reduce airflow, and anticlockwise increase it. If the air intake is installed on top as shown in illustration II, clockwise adjustment increases airflow, and anticlockwise reduces it.



4.1.6 Inlet cone, air adjustment

Airflow is also affected by the position of the inlet cone. However, it is extremely rare that this needs to be adjusted; it should be left in the standard STD position to achieve good starts and operations. (A cast-in arrow on the fan housing indicates the position of the inlet cone. In addition to the scale on the inlet cone casting, there is also a mark (M) indicating the factory setting.)




4.1.7 Air intake rotation

It is possible to rotate the air intake to adapt the burner to different surroundings. It is possible to rotate the air intake to a number of positions, not just the positions shown to the left.

To rotate the air intake, undo the three screws that fasten the air intake and the two screws which retain the pump. Then rotate the air intake to the desired position and tighten the screws. The position of the air intake affects the airflow through the burner somewhat.

The position which provides best airflow is with the air intake pointing downwards.



4.1.8 Air duct

A hose connection air duct is available in three different dimensions: 48, 68, and 78 mm outer diameter (D). The air duct is installed on the air intake at the place where the grille is attached in the standard model



5. Burner servicing

5.1 Warning

Service must be carried out after 3,000 operating hours, or at least once per year.

Only authorized personnel may perform service.

Before any type of service work is begun, switch of the power at the main switch and shut off the oil.


Exercise caution as parts which are exposed when the burner is taken apart can be hotter than 60°C. The installation engineer must be especially careful to ensure that no electrical wiring or oil lines are pinched or damaged during installation or service.



5.1.1 Service position


5.1.1.1 Service position 1

1. Switch off the power at the main switch and disconnect the Eurostecker from the burner.
2. Undo the screw which fastens the burner front piece to the fan housing, but only so much as to allow the fan housing to be removed from the burner front piece.
3. Remove the fan housing from the burner front piece and pull it backwards until the combustion assembly is free of the burner front piece.
4. Suspend the fan housing by the fan housing attachment point (for joining the front piece to the fan housing) on the screw (for joining the front piece to the fan housing) as illustrated to the left. If necessary, tighten the screw somewhat to ensure that the burner is suspended safely. något för att få brännaren att hänga säkrare.



5.1.1.2 Service position 2


1. Switch off the power at the main switch and disconnect the Eurostecker from the burner.
2. Undo the screw which fastens the burner front piece to the fan housing, but only so much as to allow the fan housing to be removed from the burner front piece.
3. Remove the fan housing from the burner front piece and pull it backwards until the combustion assembly is free of the burner front piece.
4. Turn the screw into the front piece until there is a gap of approx. 5 mm between the metal and the screw head.
5. Suspend the fan housing by the fan housing service attachment on the screw used for joining the front piece to the fan housing, with the motor upwards, as shown in the illustration to the left.



When servicing or replacing components that affect combustion, analyses and soot tests must be carried out on the installation.


5.1.1.3 Service position 3

1. Switch off the power at the main switch and disconnect the Eurostecker from the burner.
2. Undo the screw which fastens the burner front piece to the fan housing, but only so much as to allow the fan housing to be removed from the burner front piece.
3. Remove the fan housing from the burner front piece and pull it backwards until the combustion assembly is free of the burner front piece.
4. Turn the screw into the front piece until there is a gap of approx. 5 mm between the metal and the screw head.
5. Suspend the fan housing by the fan housing service attachment on the screw used for joining the front piece to the fan housing, with the air intake upwards, as shown in the illustration to the left.



5.1.2 Combustion assembly service


1. Switch off the power at the main switch and disconnect the Eurostecker from the burner.
2. If so desired, service position 1 may be used.
3. Carry out a visual inspection of the combustion assembly and check the various parts for defects.
4. Undo and remove the brake plate and the electrode package from the oil pipe. Clean the brake plate as necessary.
5. Screw off the nozzle.
6. Install the nozzle. The nozzle may not be cleaned; it must be replaced with a new nozzle if the existing one is considered defective.
7. Check the ignition electrodes. Replace as necessary (refer to Technical data for electrode settings).
8. Install the brake plate and electrode package. Check that the distance between the nozzle and brake plate is correct (refer to Technical data).
9. Undo the screw that the fan housing is suspended from. Reassemble the front piece and the fan housing and fasten them together.
10. Connect the Eurostecker and switch on the power at the main switch.
11. Start the burner and check the combustion.



When servicing or replacing components that affect combustion, analyses and soot tests must be carried out on the installation.

5.1.3 Preheater replacement

1. Switch off the power at the main switch and disconnect the Eurostecker from the burner.
2. If so desired, service position 1 may be used.
3. Remove the brake plate and electrode package.
4. Disconnect the preheater cable from the preheater.
5. Screw off the nozzle.
6. Undo the nut that connects the oil pipe to the preheater.
7. Install the new preheater. Check the condition of the O-ring; replace as necessary.
8. Connect the preheater cable.
9. Install the nozzle.
10. Install the brake plate and electrode package. Check that the distance between the nozzle and brake plate is correct (refer to Technical data).
11. Re-assemble the burner.
12. Connect the Eurostecker and switch on the power at the main switch.
13. Start the burner and check the combustion.



When servicing or replacing components that affect combustion, analyses and soot tests must be carried out on the installation.

5.1.4 Replacing the oil pump

1. Break the main current and disconnect the Euro plug from the burner.
2. Disconnect the electrical plug from the oil valve (1).
3. Detach the oil hoses from the pump.
4. Detach the solenoid valve housing from the valve (2). Remove the entire solenoid valve housing.
5. Disconnect the oil connection pipes from the solenoid valve (3).
6. Loosen the screws (4) and pull out the oil pump and solenoid valve as one assembly.
7. Turn the valve forward and detach it from the pump.
8. Reassemble in reverse order.

! Do not forget thread sealer between the pump and the elbow.
(t.ex Loctite 5188, 5400)






fig 1



! When servicing or replacing components that affect combustion, analyses and soot tests must be carried out on the installation.

5.1.5 Fan motor replacement


1. Switch off the power at the main switch and disconnect the Eurostecker from the burner.
2. If so desired, service position 2 may be used.
3. Remove the electrical connection from the motor.
4. Remove the electrical box retaining screw.
5. Remove the cable conduit entry to the ignition electrodes and the preheater (where fitted) and remove the photocell cable from the motor flange.
6. Undo the screws (H) to the motor flange, 5 pcs.
7. Lift away the motor.
8. Remove the drive coupling end from the motor shaft, loosen and remove the fan wheel.
9. Install the fan wheel on the new motor, tighten the locking screw. The fan wheel must be installed in the bottom position toward the motor shaft. Install the drive coupling end.
10. Align and fit the motor flange to the fan housing. Pay attention to the drive coupling so that it does not fall out, and also that it aligns correctly in the drive coupling end of the motor and pump.
11. Bolt the motor flange and fan housing together. Tighten the screws diagonally, and do not tighten hard one at a time. This is in order to ensure the fan housing and the motor flange assume the correct relative positions.
12. Place the cable conduit entry and the photocell cable in position.
13. Screw the electrical console in place.
14. Connect the motor wiring.
15. Join together the fan housing and the burner front piece.
16. Connect the Eurostecker and switch on the power at the main switch.
17. Start the burner and check the combustion.



When servicing or replacing components that affect combustion, analyses and soot tests must be carried out on the installation.

5.1.6 Air intake and intake cone service


1. Switch off the power at the main switch and disconnect the Eurostecker from the burner.
2. If so desired, service position 3 may be used.
3. Remove the solenoid cable from the pump.
4. Remove the connecting pipe from the pump.
5. Undo the air intake retaining screws (I).
6. Remove the air intake.
7. Undo the inlet cone retaining screw; make note of the inlet cone position.
8. Remove the inlet cone from the fan housing.
9. Check the function and visual condition of the various air regulator components. Clean and replace components as necessary.
10. Re-assemble the burner. Be especially careful when installing the inlet cone; install it in the same position it had at removal.
11. Fit the O-ring in the groove between the fan housing and inlet cone. Ensure that it is properly located in the groove and is not damaged when the air intake is fitted.
12. Connect the Eurostecker and switch on the power at the main switch.
13. Start the burner and check the combustion.



5.1.7 Fan wheel checks

5.1.7.1 Inspection


1. Switch off the power at the main switch and disconnect the Eurostecker from the burner.
2. If so desired, service position 1 may be used.
3. Perform a visual inspection of the fan wheel. Spin the fan wheel with your finger, or carefully using a tool.
4. If the fan wheel is not very dirty, clean it carefully where possible.
5. If thorough cleaning is required, refer to point 5.1.7.2 or alternatively 5.1.7.3.
6. If cleaning is not necessary, re-assemble the burner.
7. Connect the Eurostecker and switch on the power at the main switch.
8. Start the burner and check the combustion.



When servicing or replacing components that affect combustion, analyses and soot tests must be carried out on the installation.

5.1.7.2 Cleaning, alternative 1


1. Switch off the power at the main switch and disconnect the Eurostecker from the burner.
2. If so desired, service position 3 may be used.
3. Remove the solenoid cable from the pump.
4. Remove the connector pipe from the pump.
5. Undo the air intake retaining screws (I).
6. Remove the air intake.
7. Undo the inlet cone retaining screw; make note of the inlet cone position.
8. Remove the inlet cone from the fan housing.
9. Clean the fan wheel. Undo and if necessary remove the fan wheel for more thorough cleaning of the fan and fan housing.
10. Install the fan wheel; tighten the retaining screw. The fan wheel must be installed in the bottom position toward the motor shaft. Install the drive coupling end.
11. Re-assemble the burner. Pay attention to the drive coupling so that it does not fall out, and also that it aligns correctly in the drive coupling end of the motor and pump.
12. Fit the inlet cone in the same position as before disassembly
13. Fit the O-ring in the groove between the fan housing and inlet cone. Ensure that it is properly located in the groove and is not damaged when the air intake is fitted.
14. Connect the Eurostecker and switch on the power at the main switch.
15. Start the burner and check the combustion.



When servicing or replacing components that affect combustion, analyses and soot tests must be carried out on the installation.

5.1.7.3 Cleaning, alternative 2

1. Switch off the power at the main switch and disconnect the Eurostecker from the burner.
2. If so desired, service position 2 may be used.
3. Remove the electrical connection from the motor.
4. Remove the electrical box retaining screw.
5. Remove the cable conduit entry to the ignition electrodes and the preheater (where fitted) and remove the photocell cable from the motor flange.
6. Undo the motor flange retaining screws (H), 5 pcs.
7. Lift away the motor.
8. Clean the fan wheel and the fan housing. For more thorough cleaning remove the drive coupling from the motor shaft and loosen and remove the fan wheel.
9. Install the fan wheel on the motor and tighten the locking screw. The fan wheel must be installed in the bottom position toward the motor shaft. Install the drive coupling end.
10. Align and fit the motor flange to the fan housing. Pay attention to the drive coupling so that it does not fall out, and also that it aligns correctly in the drive coupling end of the motor and pump.
11. Screw the motor flange and the fan housing together. Tighten the screws diagonally, and do not tighten hard one at a time. This is in order to ensure the fan housing and the motor flange assume the correct relative positions.
12. Place the cable conduit entry and the photocell cable in position.
13. Screw the electrical box in place.
14. Connect the motor wiring.
15. Join together the fan housing and the burner front piece.
16. Connect the Eurostecker and switch on the power at the main switch.
17. Start the burner and check the combustion.



5.1.8 Electrical module


Check that the electrical console retaining screw is tight so that good contact to earth is established between the console and the burner body. Only use electrical components recommended by Enertech.



When servicing or replacing components that affect combustion, analyses and soot tests must be carried out on the installation.

5.1.8.1 Replacement of complete electrical package

1. Switch off the power at the main switch and disconnect the Eurostecker from the burner.
2. If so desired, service position 2 may be used.
3. Remove the electrical connection from the motor.
4. Remove the electrical box retaining screw.
5. Remove the cable conduit entry to the ignition electrodes and the preheater (where fitted) and remove the photocell cable from the motor flange.
6. Install the new electrical package.
7. Place the cable conduit entry and the photocell cable in position.
8. Screw the electrical box in place.
9. Connect the motor wiring.
10. Assemble the fan housing and burner front piece.
11. Connect the Eurostecker and switch on the power at the main switch.
12. Start the burner and check the combustion.



5.1.8.2 Replacement of individual electrical components

1. Switch off the power at the main switch and disconnect the Eurostecker from the burner.
2. If so desired, service position 2 may be used.
3. Remove the oil burner control.
4. Disconnect the wires to the components that are to be replaced.
5. Insert the new wires.
6. Install the oil burner control.
7. Assemble the fan housing and burner front piece.
8. Connect the Eurostecker and switch on the power at the main switch.
9. Start the burner and check the combustion.

When replacing the electrical components transformer and control box included in the electrical package, the junction box lid need not be removed.



When servicing or replacing components that affect combustion, analyses and soot tests must be carried out on the installation.

6. Pump Instructions

6.1 Suntec ANV47C

6.1.1 Technical data

Viscosity range:	2,0–75,0 mm ² /s (cSt)
Pressure range:	7–14 bar
Oil temperature:	max. 60°C

6.1.2 Components

1. Nozzle connection G 1/8"
2. Vacuum manometer connection G 1/8"
3. Manometer connection G 1/8"
4. Filter
5. Suction line G 1/4"
6. Metal plug G 1/4"
7. Return plug
8. Return line G 1/4"
9. Pressure regulation

6.1.3 Filter replacement

Cut off the power and shut off the oil.

Remove the pump cover with the aid of a 4 mm Allen key. If necessary a screwdriver may be used between the cover and the housing to carefully pry the cover loose. Replace the old filter by a new one. Replace the cover, tighten lightly.

Do not forget to replace the gasket.

Open the oil supply and switch on the power.

6.1.4 One-pipe system

Conversion to one-pipe system


Remove the return plug (8), plug the return line (9) with the metal plug (7) G 1/4".

6.1.5 Two-pipe system

Conversion to two-pipe system

Remove the metal plug (7) G 1/4", fit the return plug (8) in the return line (9).


Return plug are not included in products with one-pipe system, separately sold.



6.1.6 Solenoid valve



6.1.7 Function ANV47C



Pump working method

The oil pump is combined with an external solenoid valve that regulates oil flow and providing a precise pressure within a large speed range.

The pump's gear wheels draw oil from the tank through the integral filter and conveys the oil to the regulator valve which pressurizes the nozzle connection.

The quantity of oil that does not go to the nozzle connection is led through the valve back to the return line, or in the case of a one-pipe installation, back to the suction connection in the gear wheel pump.

- Two-pipe system

When the solenoid valve is not activated, the return plug channel between the pressure side and the return side of the pressure valve is open. No pressure will be built up to open the pressure valve, regardless of gear wheel pump rpm. When the solenoid valve is activated, the return plug channel is shut. The gear wheel pump's rotation at full rpm quickly builds up the pressure necessary for opening the valve and provides a sharp opening action.

- One-pipe system

Purging of the oil line system is not automatic in the one-pipe system; open the manometer connection for purging.

Shut-down


When the burner stops, the solenoid valve opens the return plug channel and drains oil to the return line. At that same moment the nozzle line is closed. This provides a sharp cut-off. The on and off functions can be controlled independent of motor rpm, and react very quickly. When the solenoid valve is not activated torque is low up to full motor rpm.

6.1.8 Suction pipe tables ANV47C

6.1.8.1 Overhead Tank

One-pipe system

Height m	4,0	3,0	2,0	1,0	0,5	0,0
Line diameters						
ø 4 mm	100	100	100	91	82	74



The table applies to Fuel oil 1 **Two-pipe system**

Height m	4,0	3,0	2,0	1,0	0,5	0,0
Line diameters						
ø 6 mm	29	25	22	18	16	14

The table applies to Fuel oil 1


6.1.8.2 Underlying Tank

One-pipe system

For reliable operations, use of a Tigerloop is recommended in underlying tanks.

Two-pipe system

Height m	0,0	-0,5	-1,0	-2,0	-3,0	-4,0
Line diameters						
ø 6 mm	14	12	10	7	3	0



The table applies to Fuel oil 1

The suction line tables comprise theoretically calculated values where pipe dimensions and oil flow are adapted to prevent turbulent flows from occurring.

Turbulent flows can result in pressure losses and noise in the pipework. A typical pipe system usually comprises pipe runs with 4 bends, a non return valve, a shut-off valve and a pre-filter.

The total resistance of these items is such that it can be disregarded. In the tables no run longer than 100 m is listed, as experience shows this not to be required.

The tables apply to standard heating oil of normal grade merchantable according to existing norms. When starting operations with an empty pipe system, the pump should not be run without oil for more than 5 min.

The tables give the total suction line length in meters with a nozzle capacity of 2.1 kg/h. Max. permissible pressure on the suction and return lines is 2.0 bar. For a two-pipe system the Q_{max} 46 l/h pump capacity at 0 bar applies.

7. Preheater

Function FPHB 5

When the boiler thermostat closes it supplies power to the preheater PTC element in order to preheat the oil. When the oil reaches the right temperature the preheater thermostat closes, sending the start signal to the burner.

During operation the output of the PTC element is adjusted automatically so that the temperature does not rise too high. If the oil temperature is low and the oil flow is high, the preheater thermostat may cut out.

Because of this it is important that the burner control system has a circuit that maintains preheat.



8.1.1 List of components

A1 Oil burner control	U2 UV-cell QRC
E1 Preheater	S3 Control thermostat
E2 Burner without preheater	S4 Temperature limiter
F1 Fuse max. 10 A	S7 Main switch
H1 Lamp, low capacity	T1 Ignition transformer
M1 Burner motor	Y1 Solenoid valve
P1 Time meter, low capacity (optinal)	X3 Plug-in contact, burner
R1 Flame detector QRB	X4 Plug-in contact, boiler

 Mains connection and fuse in accordance with local regulations.

Preheater cable color: A Blue B Brown C Black

8.2 Function LMO14/24

- 1 **Switch on operating switch and twin thermostat**
A spark is formed. The air damper motor opens the damper to low load position. The burner motor starts, the prepurge goes on till the prepurge period expires and the solenoid valve 1 opens (2).
2. **Solenoid valve 1 opens**
Oil mist is formed and ignited. The photocell indicates a flame. The ignition spark goes out after flame indication (See Technical data oil burner control).
3. **The safety time expires**
 - a If no flame is established before this time limit the control cuts out.
 - b If for some reasons the flame disappears after this time limit, the burner will make an attempt to re-start.
- 4 **High/Low thermostat ON**
The burner is in operating position and can now change between full load and low load.
- 4-5 **Operating position**
If the burner operation is interrupted by means of the main switch or the thermostat, a new start takes place when the conditions in accordance with point 1 are fulfilled.
The oil burner control cuts out
A red lamp in the control is lit. Press the reset button and the burner re-starts.

8.2.1 Technical data oil burner control

	LMO14.113...	LMO24.255...
Preignition time	15 s	25 s
Prepurge time	16 s	26 s
Postignition time	3 s	5 s
Safety lockout time	< 10 s	< 5 s
Reset time after lockout	< 1 s	< 1 s
Reaction time on flame failure	< 1 s	< 1 s
Ambient temperature	-5 - +60°C	-20 - +60°C
Min detector current required (with flame)	45 µA dc	45 µA dc
Max perm. detector current (without flame)	5.5 µA dc	5.5 µA dc

160303-333

8.3 Colour codes LMO14/24

When the burner starts, the light in the reset switch indicates the normal sequence, and also indicates whether something abnormal is happening as per the following table:

Preheater in operation	Solid yellow
Ignition switched on	Flashing yellow
Normal operation	Solid green
Operation, poor flame signal	Flashing green
Undervoltage	Flashing yellow-red
Fault, alarm	Solid red
False light	Flashing red-green
Communication mode	Fluttering red

8.4 Fault codes LMO14/24

When the red light for a blocked relay box comes on, you can get information about what has caused the problem by pressing and holding the reset button for 3 seconds.

The number of flashes below is repeated with a pause in between.

2 flashes	No flame signal when safety time expires
4 flashes	False light during start
7 flashes	3 x Losses of flame during operation
8 flashes	Time-out for preheater *
10 flashes	Incorrect wiring, internal fault or simultaneous occurrence of two faults

* In order for this fault code to occur, the preheater shall not reach its cut-off temperature within 10 mins. from switch on.


To return to normal operation: Press the reset button for 1 second.

If the reset button is instead kept pressed a second time for at least 3 seconds, you can, via an interface, obtain the corresponding information on a computer or flue gas analyser.


To return to normal operation: Press the reset button for 1 second.

9. Fault Location


9.1 Burner will not start




9.2 Burner will not start after normal use




9.3 Delayed ignition



9.4 Noise in pump



9.5 Pump pressure



10. Log of flue gas analysis

Owner	Adresss	Tel. no:
Installation		Tel. no:

Boiler

Type	Make	Power kW
------	------	----------

Bentone Burner

Type	Model	Serial no.	Fuel
------	-------	------------	------

	Step 1	Step 2	Step 3
Draught in fireplace			
Fan Press mbar			
Filter smoke number			
CO ₂			
O ₂			
NOx			
CO			
Flue gas temp. °C			
Setting brake disc			
Setting Air damper			
Pump pressure bar			
Nozzle			

Test performed / 20	Address
Test performed by:	Postal address
Company name:	Tel. no:

11. Oil burners maintenance instructions

General information

Keep the boiler room clean. Ensure that the boiler room has permanent fresh air intake. Switch off before dismantling the oil burner.

At hinged mounting, make sure that an automatic safety switch is fitted, so that the burner cannot start when the swing door is open.

Don't use the oil fired boiler to burn paper or rubbish, unless the boiler is especially fitted with a hinged door to make this possible.

Don't fill tank while burner is working.

Starting precautions

Make sure that the oil tank is not empty

Make sure that the valves on oil and water supply pipes are open.

Make sure that the boiler flue damper is open.

Make sure that the boiler thermostat is set at the correct temperature.

Switch on the current. Most relay systems have a delayed action so that the burner will not start for perhaps 20 seconds.

With heavy oil the delay will be longer as the burner will not start until the oil in the preheater reaches the required temperature.

If the burner will not start

Press the reset button on the relay. Check that the thermostats are correctly adjusted.

Don't forget the room thermostat, check that any fuses are intact and main switch is on.

If the burner starts but does not ignite

Make an attempt to start the burner.

Never make close repeated start attempts.

Don't restart the burner until the boiler is free from oil gases.

If the burner still does not ignite send for the service engineer.

When switching off during summer

Always use the main switch to cut out the burner even when adjusting the burner or cutting off the heating for a short time. For longer periods of shut down, close all valves and the oil supply stopcock.

Clean the filter and nozzle by washing in petrol or paraffin.

Make sure the filter medium is not damaged or defective.

Protect electrical gear from damp.

Warning

Never stand too near or put your face to the inspection or fire door, when the burner is about to start.

Never use a naked flame to ignite oil if the electrical ignition fails.

Always wait for about 10 minutes for the unburnt gases to disperse before restarting the oil burner if it has failed to ignite previously.

Installed by:

.....

Tel:

EU Declaration of conformity



Bentone Oil Burners

Type

BF 1	ST 146	B 45	B 80
ST 108	B 2	B 55	
ST 120	B 30	B 65	
ST 133	B 40	B 70	

This declaration of conformity is issued under the sole responsibility of the manufacturer. The object of the declaration described above is in conformity with:

Machinery Directive 2006/42/EC

EMC 2014/30/EU

Restriction of the use of certain hazardous substances (RoHS) Directive 2011/65/EU

References to the relevant harmonised standards used or references to the other technical specifications in relation to which conformity is declared:

EN 267:2009+A1:2011 Excluded Annex J/K. Automatic forced draught burners for liquid fuels.

Additional information can be downloaded at:

www.bentone.com

Enertech AB
Box 309
S-341 26 LJUNGBY

Ljungby, January 26th 2021

Helene Richmond

Managing Director

Enertech AB

