



Providing sustainable energy solutions worldwide

Installation- and maintenance instruction


**B 55-2/-2H**

**B 65-2/-2H**

LMO24.255C2E

RSA 95/125

60 Hz



## -sv

### 1. Manualer på övriga språk

2. [www.bentone.com\download](http://www.bentone.com/download)  
nedladdning  
eller scanna QR-koden.

3. Skriv in brännarens  
artikelnummer som finns på din  
typeskylt (se bild) och välj ditt  
språk.

Detaljerad ecodesign information  
kan laddas ner på:  
[www.bentone.com/ecodesign](http://www.bentone.com/ecodesign).

## -en

### 1. Manuals in other languages

2. [www.bentone.com\download](http://www.bentone.com/download)  
or scan QR-code.

3. Enter the burner's article  
number on your data plate (see  
picture) and select language.

Detailed ecodesign information  
can be downloaded at:  
[www.bentone.com/ecodesign](http://www.bentone.com/ecodesign).

## -da

### 1. Manualer på andre sprog

2. [www.bentone.com\download](http://www.bentone.com/download)  
eller scan QR-koden.

3. Indtast brænderens  
artikelnummer, der findes på  
typeskiltet (se billede), og vælg  
dit sprog.

Detaljerede oplysninger om  
ecodesign kan downloades på:  
[www.bentone.com/ecodesign](http://www.bentone.com/ecodesign).

## -fr

### 1. Manuels dans d'autres langues

2. [www.bentone.com\download](http://www.bentone.com/download)  
ou scannez le code QR.

3. Saisir le numéro d'article  
du brûleur sur votre plaque  
signalétique (consultez  
l'illustration) et sélectionnez la  
langue.

Des informations détaillées  
sur l'écodesign peuvent être  
téléchargées à l'adresse:  
[www.bentone.com/ecodesign](http://www.bentone.com/ecodesign).

## -de

### 1. Gebrauchsanweisungen in anderen Sprachen

2. [www.bentone.com\download](http://www.bentone.com/download)  
oder scannen Sie den QR-Code.

3. Geben Sie die Artikelnummer  
des Brenners auf Ihrem  
Typenschild ein, (siehe Bild) und  
wählen Sie die Sprache aus.

Detaillierte Informationen zum  
Ecodesign können unter  
[www.bentone.com/ecodesign](http://www.bentone.com/ecodesign)  
heruntergeladen werden.

## Table of contents

<b>1. Safety Information</b>	<b>4</b>	<b>7. Instructions Pump RSA 95/125</b>	<b>30</b>
<b>2. Technical data</b>	<b>7</b>	7.1 Technical data	30
2.1 Dimensions B 55/B 65	7	7.2 Components	30
2.2 Electric Specification	7	7.3 Mounting/dismounting by-pass plug	30
2.3 Working field B 55-2, B 55-2H	8	7.4 Purging	30
2.4 Working field B 65-2, B 65-2H	8	7.5 Replacing the filter	30
2.5 Adjusting the ignition electrodes and brake plate	9	7.6 Function Danfoss RSA 95/125	31
2.6 Recommended nozzle and pressure	9	7.7 Suction line tables	32
2.7 Burner installation	9	<b>8. Oil Burner Control</b>	<b>33</b>
2.8 Nozzle table	10	8.1 Wiring diagram LMO24.255... (B 55-2H & B 65-2H)	33
2.9 Description	12	8.2 Wiring diagram LMO24.255... (B 55-2/-2R & B 65-2/-2R)	34
<b>3. General instructions</b>	<b>14</b>	8.3 Function LMO24	35
3.1 General rules	14	8.4 Colour codes LMO24	36
<b>4. Installation</b>	<b>15</b>	8.5 Fault codes LMO24	36
4.1 Handling and lifting instruktion	15	<b>9. Fault Location</b>	<b>37</b>
4.2 Acceptance inspection	16	9.1 Burner will not start	37
4.3 Preparations for installation	16	9.2 Burner will not start after normal use	37
4.4 Distribution of oil	16	9.3 Delayed ignition	38
4.5 Electrical connection	16	9.4 Noise in pump	38
4.6 Mount the burner on the boiler	17	9.5 Pump pressure	39
4.7 Check oil line seals	17	<b>10. Log of flue gas analysis</b>	<b>40</b>
<b>5. Basic settings</b>	<b>18</b>	<b>11. Oil burners maintenance instructions</b>	<b>41</b>
5.1 Typical basic settings	18		
5.2 Setting values for nozzle assembly and air damper B 55-2/-2H/-2R/-3R	20		
5.3 Setting values for nozzle assembly and air damper B 65-2/-2H/-2R/-3R	20		
5.4 Nozzle assembly regulation – fixed brake plate	21		
5.5 Nozzle assembly regulation – adjustable brake plate	21		
5.6 Hydraulic air adjustment	22		
5.7 Air setting	22		
<b>6. Maintenance</b>	<b>23</b>		
6.1 Servicing the burner device	23		
6.2 Servicing air dampers	24		
6.3 Replacing the damper motor	25		
6.4 Replacement of oil pump	26		
6.5 Check oil line seals	27		
6.6 Replacement of electrical components	27		
6.10 Vibration	28		
6.11 Setting Damper motor 2-stage	29		

# 1. Safety Information

This Installation and Maintenance manual:

- is to be regarded as part of the burner and must always be kept near the installation site.
- is intended for use by authorised personnel.
- must be read prior to installation.
- must be observed by all who work with the burner and associated system components.
- work with the burner may only be carried out by certified installers/ personnel.
- Enertech AB is not liable for any typographical errors and reserves the right to make design changes without prior notice.
- The burner may only be used for its intended purpose in accordance with the product's technical data.
- The burner may only be installed and operated by authorised personnel.
- The product is packaged to prevent damage from occurring during handling. Handle the product with care. Lifting equipment must be used to lift larger packages.
- The products must be transported/stored on a level surface in a dry environment, max. 80% relative humidity, no condensation. Temperature -20 to +60 °C.
- Check that the burner is compatible with the boiler's output range.
- The label information on the rating plate refers to the burner's minimum and maximum power.
- The power data on the type sign refers to the burner's min. and max. power.
- All components must be installed without being bent, twisted or subjected to mechanical or thermal forces which can affect the components.
- The burner must be installed so that it complies with local regulations for fire safety, electrical safety, and fuel distribution.
- Make sure when installing the equipment that there is enough space to service the burner.
- Permitted ambient temperature during operation -0 to +60 °C. Max 80% relative humidity, no condensation.
- The installer must ensure that the room has adequate air supply.
- The room must comply with local regulations pertaining to its intended use.
- The installation site must be free of chemicals.
- Burner pipes, fan wheels and air dampers may contain sharp edges.
- The surface temperature of the burner's components can exceed 60 °C.
- Caution: The burner has moving parts, and there is risk of crushing injuries.



165 105 01



- The electrical installation must be professionally carried out in accordance with applicable high voltage regulations, as per Enertech's recommendations.
- Before servicing, shut off the fuel supply and turn off the power to the burner.
- Leak checks must be performed during installation and servicing to prevent fuel leakage.
- Care should be taken by the installer to ensure that no electrical cables or fuel lines are crushed or otherwise damaged during installation or servicing.
- If the boiler is equipped with an access hatch, this must be equipped with a hatch opening switch connected to the burner's safety system.
- When in operation, the burner's noise level can exceed 85 dBA. Use hearing protection.
- The burner must not be put into operation without proper safety and protection devices.
- A Class BE fire extinguisher is recommended.
- It is forbidden to alter the design or use accessories which have not been approved by Enertech in writing.
- Prior to operation, the following points must be checked:
  - fitting and installation work has been completed and approved.
  - electrical installation has been correctly performed.
  - flue gas ducts and combustion air ducts are not blocked.
  - all actuators and control and safety devices are in working order and correctly set.
- After commissioning, if a steady red light on the burner control is displayed, contact your installation technician.



## Burner servicing schedule

Servicing must be carried out once a year or after 3000 hours of operation.

Burner	1 year	3000 hrs
Filter	1 year	3000 hrs Change
Oilhose	1 year Control/change	
Nozzle	1 year Change	3000 hrs Change
Electrods	1 year Change/cleaning	3000 hrs Change/cleaning
Brake plate	1 year Change/cleaning	3000 hrs Change/cleaning
Motor	1 year	3000 hrs
Cuppling chaft	1 year Control/change	3000 hrs Control/change
Fan wheel	"1 year Change when dirty / unbalance"	"3000 hrs Change when dirty / unbalance"
Oil filter	1 year	3000 hrs Change
Oil valve	Tightness check 1 year	Replacement in case of leakage

## Component replacement intervals

Components	Service life – Recommended replacement	Service life – Recommended replacement Operating cycles
Control system	10 years	250 000 cycles
Pressure switch	10 years	250 000 cycles
Flame guard	10 years	250 000 cycles
UV flame sensor	10 000 hrs	N/A
Damper motor		500 000 cycles
Contaktor	10 years	500 000 cycles



The burner and its components must be recycled according to applicable regulations.

## Delivery check

- Make sure everything is delivered and the goods have not been damaged during transit.
- If something is wrong with a delivery, report it to the supplier.
- Transport damage must be reported to the shipping company.

## 2. Technical data


The burner is intended for:

- Light oil, B10 heating oil/biofuel blend (as defined in DIN V51603-6).

and is used for:

- Water heating generators.
- Hot air generators (these require LMO 24 255 C2E).

### 2.1 Dimensions B 55/B 65



Ø B	Ø C	D	E	F	G	H	I	* J
160	155	610	321	400	405	304	609	200

\* Min. recommended distance to floor.

Burner tube length, measurement A			
B 55	274	374	474
B 65	258	358	458

### 2.2 Electric Specification


Burner correspond to IP 20

Type	Motor supply	Main supply	Sound
B 55	230/400V 5,8/3,3A	230V 0,38A 60Hz	89 dBA ± 0,5 dBA
B 65	230/400V 5,8/3,3A	230V 0,38A 60Hz	89 dBA ± 0,5 dBA

Max operating current, see data plate.

## 2.3 Working field B 55-2, B 55-2H

13.0-67.5 kg/h  
155-800 kW




## 2.4 Working field B 65-2, B 65-2H

22.0-99.5 kg/h  
260-1180 kW



## 2.5 Adjusting the ignition electrodes and brake plate



Burner, type	a	b	c	d	e
B 55-2	2,5-3,0	2,0	6,5-7,0	2,0	6,0-7,0
B 55-3	2,5-3,0	0,0	6,5-7,0	2,0	6,0-7,0
B 65-2	2,5-3,0	2,0	6,5-7,0	2,0	10,0-12,0
B 65-3	2,5-3,0	0,0	6,5-7,0	2,0	10,0-12,0

**!** \*NB It is important that the spark does not strike against the brake plate or nozzle.

## 2.6 Recommended nozzle and pressure

Because of the various boiler types with varying furnace geometries and furnace loads, it is impossible to commit to a certain scattering angle or a specific distribution pattern.

It should be noted that the scattering angle and distribution pattern changes with pump pressure.


Nozzle:	45° Solid/semisolid
	60° Solid/semisolid
	80° Solid/semisolid
Pump pressure	10 bar (8-25 bar) depending on pump model

## 2.7 Burner installation

### 2.7.1 Hole patten

Make sure the hole pattern on the boiler is designed for burner flange.

Combustion device	d <sub>1</sub>	d <sub>2</sub>	d <sub>3</sub>
B 55	ø (155) 165	M14	ø (226) 254-300
B 65	ø (155) 205	M14	ø (226) 254-300





## 2.8 Nozzle table


Pump pressure bar 10				11			12			13		
Gph	kg/h	kW	Mcal/h	kg/h	kW	Mcal/h	kg/h	kW	Mcal/h	kg/h	kW	Mcal/h
1,00	3,72	44	38	3,90	46	40	4,08	48	42	4,24	50	43
1,10	4,09	48	42	4,29	51	44	4,48	53	46	4,67	55	48
1,20	4,47	53	46	4,68	55	48	4,89	58	50	5,09	60	52
1,25	4,65	55	47	4,88	58	50	5,10	60	52	5,30	63	54
1,35	5,02	59	51	5,27	62	54	5,50	65	56	5,73	68	58
1,50	5,58	66	57	5,85	69	60	6,11	72	62	6,36	75	65
1,65	6,14	73	63	6,44	76	66	6,73	80	69	7,00	83	71
1,75	6,51	77	66	6,83	81	70	7,14	85	73	7,42	88	76
2,00	7,45	88	76	7,81	93	80	8,16	97	83	8,49	101	87
2,25	8,38	99	85	8,78	104	90	9,18	109	94	9,55	113	97
2,50	9,31	110	95	9,76	116	100	10,19	121	104	10,61	126	108
2,75	10,24	121	104	10,73	127	109	11,21	133	114	11,67	138	119
3,00	11,16	132	114	11,71	139	119	12,23	145	125	12,73	151	130
3,50	13,03	154	133	13,66	162	139	14,27	169	146	14,85	176	151
4,00	14,89	176	152	15,62	185	159	16,31	193	166	16,97	201	173
4,50	16,75	199	171	17,57	208	179	18,35	218	187	19,10	226	195
5,00	18,62	220	190	19,52	231	199	20,39	242	208	21,22	252	216
5,50	20,48	243	209	21,47	255	219	22,43	266	229	23,34	277	238
6,00	22,34	265	228	23,42	278	239	24,47	290	250	24,46	302	260
6,50	24,20	287	247	25,37	301	259	26,51	314	270	27,58	327	281
7,00	26,06	309	266	27,33	324	279	28,55	339	291	29,70	352	303
7,50	27,92	331	285	29,28	347	299	30,59	363	312	31,83	377	325
8,00	29,79	353	304	31,23	370	318	32,63	387	333	33,95	403	346
8,50	31,65	375	323	33,18	393	338	34,66	411	353	36,07	428	368
9,00	33,59	398	343	35,14	417	358	36,71	435	374	38,19	453	389
9,50	35,37	419	361	37,09	440	378	38,74	459	395	40,31	478	411
10,00	37,23	441	380	39,04	463	398	40,78	484	416	42,44	503	433
11,00	40,96	486	418	42,94	509	438	44,86	532	457	46,68	554	476
12,00	44,68	530	456	46,85	556	478	48,94	580	499	50,92	604	519
14,00	52,12	618	531	54,65	648	557	57,10	677	582	59,41	705	606
16,00	59,57	706	607	62,46	741	637	65,26	774	666	67,90	805	692
18,00	67,02	795	683	70,27	833	717	73,41	871	749	76,39	906	779
20,00	74,47	883	759	78,08	926	796	81,57	967	832	84,87	1007	865
22,00	81,91	971	835	85,89	1019	876	89,73	1064	915	93,36	1107	952
24,00	89,36	1060	911	93,70	1111	956	97,88	1161	998	101,85	1208	1039
26,00	96,81	1148	987	101,50	1204	1035	106,04	1258	1081	110,33	1308	1168

The table applies to oil with a viscosity of 4.4 mm<sup>2</sup>/s at a density of 830 kg/m<sup>3</sup>.




Pump pressure bar 14				15			16			17		
Gph	kg/h	kW	Mcal/h	kg/h	kW	Mcal/h	kg/h	kW	Mcal/h	kg/h	kW	Mcal/h
1,00	4,40	52	45	4,56	54	46	4,71	56	48	4,85	57	49
1,10	4,84	57	49	5,01	59	51	5,18	61	53	5,34	63	54
1,20	5,29	63	54	5,47	65	56	5,65	67	58	5,82	69	59
1,25	5,51	65	56	5,70	68	58	5,89	70	60	6,07	72	62
1,35	5,95	70	61	6,15	73	63	6,36	75	65	6,55	78	67
1,50	6,60	78	67	6,83	81	70	7,06	84	72	7,27	86	74
1,65	7,27	86	74	7,52	89	77	7,77	92	79	8,01	95	82
1,75	7,71	91	79	7,97	95	81	8,24	98	84	8,49	101	87
2,00	8,81	104	90	9,12	108	93	9,42	112	96	9,71	115	99
2,25	9,91	118	101	10,26	122	105	10,60	126	108	10,92	130	111
2,50	11,01	131	112	11,39	135	116	11,77	140	120	12,13	144	124
2,75	12,11	144	123	12,53	149	128	12,95	154	132	13,35	158	136
3,00	13,21	157	135	13,67	162	139	14,13	168	144	14,56	173	148
3,50	15,42	183	157	15,95	189	163	16,49	196	168	16,99	201	173
4,00	17,62	209	180	18,23	216	186	18,84	223	192	19,42	230	198
4,50	19,82	235	202	20,51	243	209	21,20	251	216	21,84	259	223
5,00	22,03	261	225	22,79	270	232	23,55	279	240	24,27	288	247
5,50	24,23	287	247	25,07	297	256	25,91	307	264	26,70	317	272
6,00	26,43	313	270	27,49	326	280	28,27	335	288	29,13	345	297
6,50	28,63	340	292	29,63	351	302	30,62	363	312	31,55	374	322
7,00	30,84	366	314	31,91	378	325	32,98	391	336	33,98	403	374
7,50	33,04	392	337	34,19	405	349	35,33	419	360	36,41	432	371
8,00	35,25	418	359	36,47	433	372	37,69	447	384	38,80	460	396
8,50	37,45	444	382	38,74	459	395	40,04	475	408	41,26	489	421
9,00	39,65	470	404	41,02	486	418	42,40	503	432	43,69	518	446
9,50	41,85	496	427	43,30	514	442	44,75	531	456	46,11	547	470
10,00	44,06	523	449	45,58	541	465	47,11	559	480	47,11	559	480
11,00	48,46	575	494	50,14	595	511	51,82	615	528	53,40	633	545
12,00	52,87	627	539	54,70	648	558	56,53	670	576	58,25	691	594
14,00	62,68	732	629	63,81	757	651	65,95	778	669	67,96	806	693
16,00	70,49	836	719	72,93	865	744	75,38	894	769	77,67	921	792
18,00	79,30	940	809	82,05	973	837	84,80	1006	865	87,38	1036	891
20,00	88,11	1045	899	91,17	1081	930	94,22	1117	961	97,09	1151	990
22,00	96,92	1149	988	100	1189	1023	104	1229	1057	107	1267	1089
24,00	106	1254	1078	109	1297	1116	113	1341	1153	116	1382	1188
26,00	115	1359	1168	119	1406	1209	122	1453	1249	126	1497	1287

The table applies to oil with a viscosity of 4.4 mm<sup>2</sup>/s at a density of 830 kg/m<sup>3</sup>.

## 2.9 Description



- |     |                         |     |                                  |     |                                     |
|-----|-------------------------|-----|----------------------------------|-----|-------------------------------------|
| 1.  | Blast tube              | 11. | Indicating lamp Stage 3          | 20. | Nozzle assembly<br>adjustment fixed |
| 2.  | Locking device, flange  | 12. | Switch II-III                    | 21. | Scale, nozzle assembly              |
| 3.  | Brake plate             | 13. | Indicating lamp Stage 2          | 22. | Solenoid valve bloc Stage 2         |
| 4.  | Nozzle                  | 14. | Switch I-II                      | 23. | Solenoid valves                     |
| 5.  | Nozzle assembly         | 15. | Indicating lamp Stage 1          | 24. | Connecting pipe                     |
| 6.  | Ignition electrodes     | 16. | Switch 0-I                       |     |                                     |
| 7.  | Electric panel          | 17. | Motor                            |     |                                     |
| 8.  | Damper motor            | 18. | Adjustment device,<br>air damper |     |                                     |
| 9.  | Cover, inspection glass | 19. | Scale, air regulation            |     |                                     |
| 10. | Fuse                    |     |                                  |     |                                     |



- 25. Pump
- 26. Scale, air regulation
- 27. Nozzle assembly adjustment fixed
- 28. Damper motor
- 29. Fan wheel
- 30. Thermal overload protection
- 31. Contactor
- 32. Control box
- 33. Front plate, relay base

- 34. Ignition transformer
- 35. Photocell
- 36. Ignition wires
- 37. Air damper
- 38. Air intake
- 39. Solenoid valve bloc Stage 2
- 40. Connecting pipe
- 41. Solenoid valve
- 42. Adjustment device, Nozzle assembly

- 43. Nozzle assembly adjustment hydraul
- 44. Damper motor
- 45. Solenoid valve
- 46. Scale, Nozzle assembly
- 47. Solenoid valve bloc Stage 3
- 48. Hydraulic hose

## 3. General instructions

### 3.1 General rules

The installation of an oil burner should be carried out in accordance with local regulations. The installer of the burner must therefore be aware of all regulations relating to oil and combustion.

Only oil suitable for the burner should be used and then in combination with a suitable oil filter before the oil pump of the burner.

If the burner is replacing an existing burner make sure that the oil filter is replaced or cleaned. The installation must only be undertaken by experienced personnel. Care should be taken by the installer to ensure that no electrical cables or fuel/gas pipes are trapped or damaged during installation or service/maintenance.

#### 3.1.1 Installation and maintenance instructions

The maintenance instructions supplied with the burner must be kept at an easily accessible location in the boiler room.

#### 3.1.2 Instructions

The user must be receive detailed instructions concerning the functionality of the oil burner and entire system. It is the responsibility of the supplier to provide the user with instructions.

#### 3.1.3 Inspection and maintenance

The boiler/burner should be examined regularly for any signs of malfunction or oil leakage. (See service schedule)

#### 3.1.4 Start up

In order to obtain the correct setting, a flue gas analysis and temperature measurement must be carried out. Otherwise, there is a risk of soot build up, poor efficiency or condensation precipitation in the chimney. The system must be fine-tuned at start-up. The temperature in the chimney must be at least 60 °C at 0.5 m down in the chimney to prevent condensation.



## 4. Installation

### 4.1 Handling and lifting instruktion



The lifting aid we used here are available as spare parts.



## 4.2 Acceptance inspection

Make sure everything is delivered and the goods have not been damaged during transit. If something is wrong with the delivery, report it to the supplier. Transport damage must be reported to the shipping company.

## 4.3 Preparations for installation


Check that the burner's dimensions and capacity range are suitable for the boiler in question. The power data on the type sign refers to the burner's min. and max. power.


## 4.4 Distribution of oil

In order to achieve good reliability, it is important that the oil distribution system is designed correctly.

Take the following into account:

- Selection of pipe diameter, pipe length and height difference; see Pump instruction.
- Pipelines are to be laid with a minimal number of glands.
- The pipes are to be laid so that the oil supply hoses are not subjected to tensile stresses or are excessively bent when the burner is swung out or removed for service.
- The oil filter should be installed so that the filter cartridge can easily be replaced or cleaned. Self-cleaning filters are recommended for oils of a higher viscosity or oils that contain significant impurities.
- Oil-affected parts shall be selected in materials that are capable of withstanding the medium's physical properties.
- When installing oil hoses, check that the inlet and return hoses are fitted to the appropriate connection on the oil pump. The hoses shall be located so that they do not bend or become subject to tensile load.
- Bleed the oil system. The oil pump/oil preheater may be damaged if run dry. The vacuum should not fall below 0.3 bar in the suction line during start-up.

 The oil filter must be installed before the burner's oil pump.

 Be sure to fill the burner oil system before starting it for the first time.

## 4.5 Electrical connection



- Before work on the electrical connection, the current should be disconnected so that the installation is isolated.
- Electrical connection must be done in accordance with the applicable regulations.
- Burners should be connected to an isolator switch.
- The connection should be made in accordance with the wiring diagram.
- Fuse rating is as required.



If any electrical connection is used other than that recommended by Bentone, there may be a danger of damage to property and personal injury.

## 4.6 Mount the burner on the boiler

1. Separate the burner body and the flange.
2. Remove the brake disc from the oil pipe.
3. Install the selected nozzle. (See Technical data)
4. Install the brake disc on the oil pipe
5. Remove the burner pipe from the flange.
6. Install the flange with gasket on the boiler.
7. Install the burner pipe on the flange. Make sure that the holes in the front edge of the burner pipe are pointing down (not on all burner pipes). This allows any drops of oil to run out.
8. Insulate between the burner and boiler door to reduce radiated heat.
9. Install the burner body on the flange.
10. Lock the burner body using with the nut/nuts.
11. Connect the oil pipes to the pump, refer to the chapter - servicing of burners.
12. Connect the burner electrically, refer to the chapter - servicing of burners.



**!** If the burner tube must be installed from the inside of the boiler, this means that the boiler must be opened or have a spectacle flange that is designed so that it can be reconnected with the burner tube mounted.

## 4.7 Check oil line seals

Once the burner has been installed and commissioned, the seals of the various coupling elements should be checked.

When a leak is detected, it is usually sufficient to tighten the coupling element that is leaking.

## 5. Basic settings

### 5.1 Typical basic settings

#### Choice of nozzle B 65-2H / B 65-2 / B 65-2R

Burner output	770 kW
Nozzle Stage 1	$770 \times 0,6 = 460 \text{ kW}$ $460 / 11,86 = 38,8 \text{ kg/h}$
Nozzle Stage 2	$770 \times 0,4 = 310 \text{ kW}$ $310 / 11,86 = 26,1 \text{ kg/h}$

According to the table of nozzles this gives the following nozzles.

Stage 1	8,50 Gph
Stage 2	6,00 Gph

Pump pressure : 14 bar

#### Basic settings B 65-2H

Nozzle assembly	Stage 2 = 15
Air adjustment	Stage 1 = 25° Stage 2 = 65°

Each graduation on the scale corresponds to 10°

#### Basic settings B 65-2

Power outputs and nozzle choice from example.

Nozzle assembly	Steg 2 = 15
Damper motor	Closed = 0° Blue cam Stage 1 = 25° Orange cam MV 2 = 50° Black cam Stage 2 = 65° Red cam

The black cam for Stage 2 (MV 2) must be placed between the cams for Stage 1 and Stage 2. The positions of MV 2 are determined by the boiler characteristics when switching between stages, but for a basic setting the black cam should be placed in the middle.

#### Basic settings B 65-2R

Power outputs and nozzle choice from example

Nozzle assembly	Stage 1 = 0 Stage 2 = 15
Damper motor	Closed = 0° Blue cam Stage 1 = 25° Orange cam MV 2 = 40° Black cam Stage 2 = 50° Red cam

The black cam for Stage 2 (MV 2) must be placed between the cams for Stage 1 and Stage 2. The positions of MV 2 are determined by the boiler characteristics when switching between stages, but for a basic setting the black cam should be placed in the middle.

#### Choice of nozzle B 65-3R

Burner output	880 kW
Nozzle	$880 / 3 = 293 \text{ kW}$ $293 / 11,86 = 24,7 \text{ kg/h}$

According to the table of nozzles this gives the following nozzles:

Stage 1	5,50 Gph
Stage 2	5,50 Gph
Stage 3	5,50 Gph

#### Basic settings B 65-3R

Power outputs and nozzle choice from example

Nozzle assembly	Stage 1/2 = 5 Stage 3 = 20
Damper motor	Stage 1 = 10° Blue cam MV 2 = 30° Black cam Stage 2 = 44° Orange cam MV 3 = 60° Green cam Stage 3 = 80° Red cam

The cams for Stage 2 (MV 2) and Stage 3 (MV 3) must be placed between the cams for Stage 1 and Stage 2, and between Stage 2 and Stage 3, respectively. The positions of MV 2 and MV 3 are determined by the boiler characteristics when switching between stages, but for a basic setting the cams (MV2 and MV3) should be placed in the middle.

## Recommended excess air

Grade of Oil	Excess air flue gases		Max. % CO <sub>2</sub>
	% O <sub>2</sub>	% CO <sub>2</sub> Lambda 1.2	
Light oil, B10 heating oil/ biofuel blend (as defined in DIN V51603-6)	3-5	≈12,5	15,4

Prior to commissioning, the basic settings of the burner can be set in accordance with the diagram. See under Basic settings **Note that it is simply a matter of a basic setting that should be adjusted retrospectively once the burner has started.** A flue gas analysis and soot quantity measurement must be carried out when fine-tuning the burner.



B 55-2/-2H/-2R/-3R



B 65-2/-2H/-2R/-3R



## 5.4 Nozzle assembly regulation – fixed brake plate


Nozzle assembly regulation is used to achieve the most favourable pressure drop possible across the brake plate.

Nozzle assembly regulation should be adjusted for Stage 2 output

### Adjustment

Adjust to the desired position on the scale (A) using the set screw (B) (turning anti-clockwise reduces the pressure drop and moves the brake plate outwards).

If pulsation occurs, the pressure drop across the brake plate can be altered until pulsation stops.



## 5.5 Nozzle assembly regulation – adjustable brake plate

Nozzle assembly regulation is used to achieve the most favourable pressure drop possible across the brake plate for each output stage.

### 2 nozzles

Nozzle assembly regulation adjusts the position of the brake plate between Stage 1 and Stage 2 by means of a hydraulic piston.

### 3 nozzles

Nozzle assembly regulation adjusts the position of the brake plate between Stage 2 and Stage 3 by means of a hydraulic piston.

### Low load


The low load adjustment takes place by changing the guide rail's mounting to the hydraulic piston.

This takes place using a locking screw located through an oval hole. In the default setting, the value that is read in the table (3.4 & 3.5) is used for the setting values for the chosen power for step 2. During operation, the insert is adjusted in order to achieve the best function.

Undo the locking screw (C).

Set the desired position on the scale (A) by pushing the disc in the desired position.

Tighten the screw (C).



### High load

Adjust to the desired position on the scale (A) using the set screw (D) (turning anti-clockwise reduces the pressure drop and moves the brake plate outwards). If pulsation occurs, the pressure drop across the brake plate can be altered until pulsation stops.


## 5.6 Hydraulic air adjustment

### Stage 1

Set the control switch (S2) to low load (I). Undo the screw (E), turn the damper to the desired position and retighten the screw (E).

### Stage 2

Set the control switch (S2) to high load (I). Use the adjuster pin to screw the sleeve (F) in (to reduce) or out (to increase). The position of the damper can be read from the damper scale (G). Carry out flue gas analysis to check the air settings



## 5.7 Air setting

When the burner's power stage has been selected, check the setting values for air dampers in table (3.6, 3.7). Read the damper angle for each of the power stages. This must then be used when the settings are made in the burner's control system (see punkt 3.3)

Check the air settings by conducting a flue gas analysis.

## 6. Maintenance

### 6.1 Servicing the burner device

#### Removal and fitting

1. Switch off the mains power.




If the burner is directly connected, ensure that all components on the burner are without power.

2. Remove the nuts (H) and pull the burner body out of the guides from the burner flange.
3. Remove the brake plate from the oil pipe and clean the brake plate.
4. Unscrew the nozzle.
5. Fit the nozzle.
6. Install the brake plate. (refer to Technical data)
7. Check the ignition electrodes. (refer to Technical data)
8. If necessary, replace the ignition electrodes.
9. Fit the burner body and the burner flange together and secure with the nuts (H).
10. Open the boiler/spectacle flange to access the burner pipe.
11. Remove and clean the burner pipe.
12. Install the burner pipe, make sure you install the drainage hole (not on all burner pipes) facing downwards so that any spilled oil can drain out.
13. Close the boiler / spectacle flange.
14. Turn on the mains power.
15. Check combustion.



Use caution when operating the burner, surfaces may be hot.



When soiled, always replace nozzles with new nozzles.



When servicing/replacing components that affect combustion, an analysis and soot test must be carried out on the installation.

## 6.2 Servicing air dampers


### Removal and installation

1. Break the main current and disconnect the Euro plugs from the burner.



If the burner is directly connected, ensure that all components on the burner are without power.

2. Undo the nuts (H) and pull out the burner body on its guides.
3. Remove the intake grille from the air intake.
4. Release the damper motor.
5. Clean the air damper (F) and the intake. Lubricate the damper shaft if applicable.
6. Re-engage the damper motor.
7. Fit the intake grille over the air intake.
8. Slide the burner together and secure it with the nuts (H).
9. Connect the Eurostecker connectors and turn on the main power switch.
10. Check combustion.



When servicing/replacing components that affect combustion, an analysis and soot test must be carried out on the installation.




## 6.3 Replacing the damper motor

### Removal and fitting

1. Turn off the main power switch and disconnect the Eurostecker connectors from the burner.
2. Note the positions of the cables and then disconnect the cables from the damper motor.
3. Release the damper motor and lock it at 30°.
4. Undo the screws (G) that secure the mounting plate for the damper motor.
5. Raise it carefully so that the air damper stays in the air intake.
6. Disconnect the (E) link arm from the motor shaft.
7. Separate the damper motor from the mounting plate (I).
8. Refit the damper motor on the mounting plate.
9. Connect the link arm to the damper motor shaft. It is important that the screw is at right angles to the plane of the shaft.
10. Release the damper motor and lock it at 30°.
11. Fit the mounting plate by guiding the link arm into the attachment point on the air damper and the air damper shaft into the mounting plate (make sure that the bushings are fitted between the mounting plate and damper shaft).
12. Release the damper motor and check that the damper moves freely. Close the damper and zero the graduated scale on the damper motor.
13. Make the electrical connections to the damper motor.
14. Reset the damper motor cams.
15. Connect the Eurostecker connectors and turn on the main power switch.
16. Check combustion.

**!** When resetting dampers, ensure that they do not engage in the close damper position. If dampers do engage, the automatic control unit will report an error message.



When servicing/replacing components that affect combustion, an analysis and soot test must be carried out on the installation.

## 6.4 Replacement of oil pump


### Removal and installation

1. Turn off the main power switch and disconnect the Eurostecker connectors from the burner.



If the burner is directly connected, ensure that all components on the burner are without power.

2. Disconnect the oil hoses from the pump.
3. Undo the screws (J) and pull out the oil pump.
4. Measure the distance between the pump mounting and the pump coupling (K).
5. Transfer the pump coupling to the new pump and adjust to give the same spacing between the pump and pump coupling as before (K).
6. Fit the oil pump on the burner and tighten the screws (J). (It is important that splines on the pump shaft align correctly with the pump coupling.)
7. Fit the oil hoses.
8. Connect the Eurostecker connectors and turn on the main power switch.
9. Bleed the pump, start the burner and adjust to the correct oil pressure.
10. Check combustion.



Use caution when operating the burner, surfaces may be hot.



When servicing oil bearing components, check the oil density when the burner is commissioned after servicing.



When servicing/replacing components that affect combustion, an analysis and soot test must be carried out on the installation.

## 6.5 Check oil line seals

Once the burner has been installed and commissioned, the seals of the various coupling elements should be checked.

When a leak is detected, it is usually sufficient to tighten the coupling element that is leaking.



Use Loctite 5188 on threaded oil lines.

## 6.6 Replacement of electrical components

1. Switch off the mains power.



If the burner is directly connected, ensure that all components on the burner are without power.

2. Note the connection of the existing component.
3. Remove the existing component.
4. Install the new component using the same wiring as the existing component or the specified alternative arrangement.
5. Turn on the mains power.
6. Check the function of the new component.
7. Start the burner and check the combustion.



Use caution when operating the burner, surfaces may be hot.




When servicing/replacing components that affect combustion, an analysis and soot test must be carried out on the installation.

## 6.10 Vibration

Maximum vibration level are 5,0 mm/s.

- Check all bolts and nuts for correct torque.
- Check fan wheel for damage and contamination. Change when dirty/unbalanced.
- Check motor bearings. If worn change motor/bearings.

Use lid screw  
hole for sensor  
mounting.



## 6.11 Setting Damper motor 2-stage

### Air adjustment

The damper motor rotates the air damper between three preset positions: completely closed, low load and high load. These positions are controlled in the motor by colored cam discs, the black cam disc controls the switching on/off of the solenoid valve. Adjust the amount of air by changing the position of the cam discs.

Blue cam disc is the limit position for closed air dampers and does not normally need to be changed.

### Low load


- Set control switch for load position to position II (high load).
- Turn orange cam disc to 0° to reduce airflow and to 90° to increase airflow.
- Return the control switch to position I (low load) and check the combustion values.

### High load

- Set control switch for load position to position I (low load).
- Turn red cam disc to 0° to reduce airflow and to 90° to increase airflow.
- Place black cam disc in a position between red and orange cam discs and adjust to obtain a good load change.
- Return the control switch to position II (high load) and check the combustion values.

### Release

By pressing the button, the motor is disengaged and the air damper can be turned. The function is used when servicing air dampers.




## 7. Instructions Pump RSA 95/125

### 7.1 Technical data

	RSA 95	RSA 125
Viscosity range::	1,3-18,0 mm <sup>2</sup> /s	1,3-18,0 mm <sup>2</sup> /s
Pressure range at viscosity 1,3-1,8:	5,5-12,0 bar	5,5-12,0 bar
Pressure range at viscosity 1,8-18,0:	2,5-21,0 bar	2,5-21,0 bar
Oil temperature:	-10 till +70°C	-10 till +70°C
Nozzle capacity at viscosity 4,3:	150-190 l/h	215-260 l/h
Gear capacity:	225 l/h	294 l/h
Max pressure on the suction and return side:	4 bar	4 bar

### 7.2 Components

1. Pressure gauge port G 1/8"
2. Nozzle outlet G 1/4"
3. Suction line G 1/4"
4. Suction line G 1/4"
5. Return line G 1/4"
6. Return line G 1/4"
7. Return plug
8. Pressure regulation 4 mm Allen key



### 7.3 Mounting/dismounting by-pass plug

In a 2-pipe-system excess oil is led back direct to the oil tank. In a 1-pipe-system the by-pass plug must be removed so that there is a free passage back to the suction side through the return line with the return port closed. (Pos.7).

### 7.4 Purging

On 1-pipe systems it is necessary to purge the pump. On 2-pipe systems purging is automatic through the return line.

### 7.5 Replacing the filter

Replace the oil filter on the oil pump as follows..

- Close the oil valves.
- Unscrew the cover (4 x 5 mm Allen screws).
- Replace the oil filter.
- Replace the cover gasket.
- Refit the cover.
- Open the oil valves.




165 105 54






## 7.7 Suction line tables



1-pipe system		Pipe diameter		
Höjd				
H	ø12mm	ø15mm	ø20mm	
m	m	m	m	



1-pipe system		Pipe diameter		
Height				
H	ø12mm	ø15mm	ø20mm	
m	m	m	m	

Two-pipe system				
Height		Pipe diameter		
H	ø12mm	ø15mm	ø20mm	
m	m	m	m	
4,0	81	100	100	
3,5	76	100	100	
3,0	71	100	100	
2,5	66	100	100	
2,0	61	100	100	
1,5	56	100	100	
1,0	51	100	100	
0,5	46	100	100	

With an underlying tank a 1-pipe-system is not recommended.

Two-pipe system				
Height		Pipe diameter		
H	ø12mm	ø15mm	ø20mm	
m	m	m	m	
0,0	41	100	100	
-0,5	36	89	100	
-1,0	31	77	100	
-1,5	26	65	100	
-2,0	22	53	100	
-2,5	17	41	100	
-3,0	12	29	91	
-3,5	7	17	53	
-4,0	2	5	15	

The suction line tables consist of theoretically calculated values where the pipe dimensions and oil velocity have been matched so that turbulences will not occur. Such turbulences will result in increased pressure losses and in acoustic noise in the pipe system.


In addition to drawn copper piping a pipe system usually comprises 4 elbows, a non-return valve, a cut-off valve and an external oil filter. The sum of these individual resistances is so insignificant that they can be disregarded.

The tables do not include any lengths exceeding 100 m as experience shows that longer lengths are not needed. The tables apply to a standard fuel oil of normal commercial quality according to current standards. On commissioning with an empty tube system the oil pump should not be run without oil for more than 5 min. (a condition is that the pump is being lubricated during operation).


The tables state the total suction line length in metres at a viscosity of 6,0 mm<sup>2</sup>/s.

## 8. Oil Burner Control

### 8.1 Wiring diagram LMO24.255... (B 55-2H & B 65-2H)



## 8.2 Wiring diagram LMO24.255... (B 55-2/-2R & B 65-2/-2R)



## 8.2.1 List of components

A1	Burner control	P2	Time meter, high capacity (optional)	X2	Earth terminal
B1	Photoresistor	S1	Operating switch	X3	Plug-in contact "Euro" burner
F1	Operating fuse	S2	Operating switch, high/low capacity	X4	Plug-in contact "Euro", boiler
F2	Operating fuse	S3	Operation thermostat	X5	Plug-in contact "Euro" high/low burner
F3	Operating fuse	S4	Temperature limiter	X6	Plug-in contact "Euro", high/low boiler
H1	Alarm lamp	S5	Micro switch for hinged door	X7	Plug-in contact "Euro" 3-phase, burner
H2	Signal lamp (optional)	S6	Control thermostat, high/low	X8	Plug-in contact "Euro", 3-phase, boiler
H5	Alarm signal 230V	S7	Main switch 3-phase	Y1	Solenoid valve 1
K1	Thermal overload protection	S20	Main switch 1-phase	Y2	Solenoid valve 2
M1	Burner motor	T1	Ignition transformer		
M2	Damper motor	X1	Connection terminal board		
P1	Time meter, low capacity (optional)				

## 8.3 Function LMO24

### 1 Switch on operating switch and twin thermostat

A spark is formed. The air damper motor opens the damper to low load position. The burner motor starts, the prepurge goes on till the prepurge period expires and the solenoid valve 1 opens (2).

### 2. Solenoid valve 1 opens

Oil mist is formed and ignited. The photocell indicates a flame. The ignition spark goes out after flame indication (See Technical data oil burner control).

### 3. The safety time expires

- a If no flame is established before this time limit the control cuts out.
- If for some reasons the flame disappears after this time limit, the burner will make an attempt to re-start.

### 4 High/Low thermostat ON


The burner is in operating position and can now change between full load and low load.


### 4-5 Operating position

If the burner operation is interrupted by means of the main switch or the thermostat, a new start takes place when the conditions in accordance with point 1 are fulfilled.

### The oil burner control cuts out

A red lamp in the control is lit. Press the reset button and the burner re-starts.

 If S6 is missing, connect between T6 and T8.

 Mains connection and fuse in accordance with local regulations.

## 8.3.1 Technical data

	LMO14.113...	LMO24.255...
Preignition time	15 s	25 s
Prepurge time	16 s	26 s
Postignition time	3 s	5 s
Safety lockout time	< 10 s	< 5 s
Reset time after lockout	< 1 s	< 1 s
Reaction time on flame failure	< 1 s	< 1 s
Ambient temperature	-5 - +60°C	-20 - +60°C
Min detector current required (with flame)	45 µA dc	45 µA dc
Max perm. detector current (without flame)	5.5 µA dc	5.5 µA dc

160303-333

## 8.4 Colour codes LMO24

When the burner starts, the light in the reset switch indicates the normal sequence, and also indicates whether something abnormal is happening as per the following table:

Preheater in operation	Solid yellow
Ignition switched on	Flashing yellow
Normal operation	Solid green
Operation, poor flame signal	Flashing green
Undervoltage	Flashing yellow-red
Fault, alarm	Solid red
False light	Flashing red-green
Communication mode	Fluttering red

## 8.5 Fault codes LMO24

When the red light for a blocked relay box comes on, you can get information about what has caused the problem by pressing and holding the reset button for 3 seconds.

The number of flashes below is repeated with a pause in between.

2 flashes	No flame signal when safety time expires
4 flashes	False light during start
7 flashes	3 x Losses of flame during operation
8 flashes	Time-out for preheater *
10 flashes	Incorrect wiring, internal fault or simultaneous occurrence of two faults

\* In order for this fault code to occur, the preheater shall not reach its cut-off temperature within 10 mins. from switch on.

To return to normal operation: Press the reset button for 1 second.

If the reset button is instead kept pressed a second time for at least 3 seconds, you can, via an interface, obtain the corresponding information on a computer or flue gas analyser.

To return to normal operation: Press the reset button for 1 second.

## 9. Fault Location

### 9.1 Burner will not start

Symptom	Causes	Remedies
Motor starts	Unstable flame	Adjust the damper
Burner pre-ventilates	Excess air	Check the oil pressure
	Low oil pressure	Check the nozzle in relation to the combustion apparatus dimensions and the ignition electrode position
Flame formed	Incorrect combustion apparatus settings	Check the flame monitor is clean and can register light
Burner trips	Flame monitor does not register light	Check with using new photocell
	Defective flame monitor	Check using new oil burner control (Note: replacement of photocell recommended if oil burner control replaced)
Motor starts	Defective oil burner control	Check the oil supply to the burner and that there are no air bubbles in the pump
Burner pre-ventilates		Check function of solenoid
No flame formed	No oil	Check flame monitor does not register ambient light
Burner trips	False light	Check high voltage wiring and ignition electrodes
	No spark	Check preheater function
Motor does not start	Preheater does not get up to temperature.	

### 9.2 Burner will not start after normal use

Symptom	Causes	Remedies
Burner does not start	Fuse blown	Check and replace fuse as necessary. Investigate cause of fault
	Boiler thermostat has not reset	Adjust thermostat
	Preheater does not get up to temperature	Check preheater function
Burner pre-ventilates	Overheating protection has deployed	Reset the overheating protection. Investigate the cause of its deploying. Remedy fault
	Defective preheater	Check by replacing with new
	Defective oil burner control or flame monitor	Check that tank, oil lines, solenoid valves, pump and nozzle are in good condition
Burner stops	No oil supply	Adjust the burner
	Too great a pressure drop at brake plate	Correct the boiler draught
	Too strong draught prevents flame forming	Check the ignition transformer. Check the ignition electrode settings and ceramics
	No spark	Check preheater function
	Preheater temperature too low	Adjust the preheater's set operating temperature
	New oil type	Check that the oil used has the physical parameters that the burner is rated for. If not, change the oil.

## 9.3 Delayed ignition

Symptom	Causes	Remedies
Burner pulsates at start with hot flue gases	Excessively strong draught	Correct boiler draught
	Excessive pressure drop across the brake plate	Adjust the burner
	Preheater temperature too low	Check preheater function
	New oil type	Adjust the preheater's set operating temperature
		Ensure that the new oil's physical parameters are within the limits for which the burner is designed. If not, change the oil.
Burner pulsates at start	Nozzle partially blocked	Replace nozzle
	Oil pressure too low	Check and adjust
	Flue is blocked or damaged	Check and correct
	The fan wheel is slipping on the shaft	Check and tighten
	Pump coupling loose or worn	Replace
	Preheater blocked	Check the ignition electrode setting, (see technical data)
	Delayed ignition	Check that the ignition electrodes are not damaged
	Excessively strong draught	Check high voltage cables
		Check position of nozzle assembly setting
		Correct boiler draught
	Excessive pressure drop across the brake plate	Adjust the burner
	Preheater temperature too low	Check preheater function
	New oil type	Adjust the preheater's set operating temperature
		Ensure that the new oil's physical parameters are within the limits for which the burner is designed. If not, change the oil.

## 9.4 Noise in pump

Symptom	Causes	Remedies
The burner pump emits noise during start	Insufficient negative pressure on the suction side pump	Check the oil system in order to reduce pressure drop
		Rebuild the oil system to form a solution with a transport oil pump
		Check that the oil used has the physical parameters that the burner is rated for. If not, change the oil.
		Temperature of the oil from the tank is too low, increase the temperature of oil from tank
		Clean the pump filter
The burner pump emits noise during operation		



## 9.5 Pump pressure

Symptom	Causes	Remedies
The burner pump can not build up pressure	No oil	Check that there is oil and that it reaches the pump
	Oil viscosity too low	Check that the oil reaching the pump has the physical parameters that the pump can handle. Change the oil or the pump's oil parameters
	Pump worn	Replace the pump
	Pump run using impure oil that has worn the pump out prematurely	Replace pump and install self-cleaning filter in the oil system
	Blocked pump filter	Check, clean pump filter

## 10. Log of flue gas analysis

Owner	Adresss	Tel. no:
Installation		Tel. no:

### Boiler

Type	Make	Power kW
------	------	----------

### Bentone Burner

Type	Model	Serial no.	Fuel
------	-------	------------	------

	Step 1	Step 2	Step 3
Draught in fireplace			
Fan Press mbar			
Filter smoke number			
CO <sub>2</sub>			
O <sub>2</sub>			
NOx			
CO			
Flue gas temp. °C			
Setting brake disc			
Setting Air damper			
Pump pressure bar			
Nozzle			

Test performed / 20	Address
Test performed by:	Postal address
Company name:	Tel. no:

# 11. Oil burners maintenance instructions

## General information

Keep the boiler room clean. Ensure that the boiler room has permanent fresh air intake. Switch off before dismantling the oil burner.

At hinged mounting, make sure that an automatic safety switch is fitted, so that the burner cannot start when the swing door is open.

Don't use the oil fired boiler to burn paper or rubbish, unless the boiler is especially fitted with a hinged door to make this possible.

Don't fill tank while burner is working.

## Starting precautions

Make sure that the oil tank is not empty

Make sure that the valves on oil and water supply pipes are open.

Make sure that the boiler flue damper is open.

Make sure that the boiler thermostat is set at the correct temperature.

Switch on the current. Most relay systems have a delayed action so that the burner will not start for perhaps 20 seconds.

With heavy oil the delay will be longer as the burner will not start until the oil in the preheater reaches the required temperature.

## If the burner will not start

Press the reset button on the relay. Check that the thermostats are correctly adjusted.

Don't forget the room thermostat, check that any fuses are intact and main switch is on.

## If the burner starts but does not ignite

Make an attempt to start the burner.

Never make close repeated start attempts.

Don't restart the burner until the boiler is free from oil gases.

If the burner still does not ignite send for the service engineer.

## When switching off during summer

Always use the main switch to cut out the burner even when adjusting the burner or cutting off the heating for a short time. For longer periods of shut down, close all valves and the oil supply stopcock.

Clean the filter and nozzle by washing in petrol or paraffin.

Make sure the filter medium is not damaged or defective.

Protect electrical gear from damp.

## Warning

Never stand too near or put your face to the inspection or fire door, when the burner is about to start.

Never use a naked flame to ignite oil if the electrical ignition fails.

Always wait for about 10 minutes for the unburnt gases to disperse before restarting the oil burner if it has failed to ignite previously.

## Installed by:

.....

Tel:.....

# EU Declaration of conformity



## Bentone Oil Burners

---

### Type

<b>BF 1</b>	<b>ST 146</b>	<b>B 45</b>	<b>B 80</b>
<b>ST 108</b>	<b>B 2</b>	<b>B 55</b>	
<b>ST 120</b>	<b>B 30</b>	<b>B 65</b>	
<b>ST 133</b>	<b>B 40</b>	<b>B 70</b>	

---

This declaration of conformity is issued under the sole responsibility of the manufacturer. The object of the declaration described above is in conformity with:

**Machinery Directive 2006/42/EC**

**EMC 2014/30/EU**

**Restriction of the use of certain hazardous substances (RoHS) Directive 2011/65/EU**

---

References to the relevant harmonised standards used or references  
to the other technical specifications in relation to which conformity is declared:

EN 267:2009+A1:2011      Excluded Annex J/K. Automatic forced draught burners for liquid fuels.

---

Additional information can be downloaded at:

**[www.bentone.com](http://www.bentone.com)**

**Enertech AB**  
**Box 309**  
**S-341 26 LJUNGBY**

Ljungby, January 26<sup>th</sup> 2021

Helene Richmond  
Managing Director  
Enertech AB



