



Providing sustainable energy solutions worldwide

Installation- and maintenance instruction  
**BG 700-2**



## Table of contents

<b>1. General Information</b>	<b>4</b>
<b>2. Technical data BG700</b>	<b>7</b>
2.1 Burners are intended for use at:	7
2.2 Dimensions	7
2.3 Description BG700 M	10
2.4 Description BG700-2	11
<b>3. General instructions</b>	<b>12</b>
3.1 General instructions	12
3.2 Installation and maintenance instructions	12
3.3 Instructions	12
3.4 Inspection and maintenance	12
3.5 Start up	12
3.6 Commissioning of installation	12
<b>4. Installation</b>	<b>13</b>
4.1 Delivery check	13
4.2 Preparations for installation	13
4.3 Gas supply	13
4.4 Electric connection	13
4.5 Skeleton diagrams	14
4.6 Skeleton diagram, biogas 2-stage burner	15
4.7 Handling and lifting instruction	16
4.8 Mounting on the boiler	17
4.9 Inspection of gas nozzle before commissioning	18
4.10 Leakage control	19
4.11 Gas nozzle	20
4.12 Setting Air damper	21
4.13 Air adjustment	21
4.14 Low load:	21
4.15 Full load	21
<b>5. Setting the burner</b>	<b>22</b>
5.1 Setting the air pressure switch	22
5.2 Setting the min. gas pressure switch	23
<b>6. Gas pressure regulator Type FRS</b>	<b>24</b>
6.1 Double solenoid valve Type DMV-D.../11 Type DMV-DLE.../11	27
6.2 Adjustment of gas solenoid valve dungs MVD	30
6.3 Recommended excess air when using default setting	31
6.4 Determining the gas quantity for the system	31
6.5 Calculating the quantity of gas supplied	33
<b>7. Service</b>	<b>34</b>
7.1 Servicing the combustion assembly	34
7.2 Servicing air dampers	35
7.3 Replacement of damper motor, air	36
7.4 Vibration	37
7.5 Flame monitoring and ionisation current check	38
7.6 UV detector	38
<b>8. Handing over of the installation</b>	<b>39</b>
<b>9. Fault location, functional troubles</b>	<b>39</b>
<b>10. Electric equipment</b>	<b>40</b>
10.1 Safety system	40
10.2 Wiring diagram LFL1....	41
10.3 List of components	42
10.4 Leakage control Dungs VPS 504	44
<b>11. Troubleshooting</b>	<b>46</b>
<b>12. EU Declaration of conformity</b>	<b>49</b>
<b>14. General instructions for gasburners</b>	<b>50</b>

# 1. General Information

This Installation and Maintenance manual:

- is to be regarded as part of the burner and must always be kept near the installation site
- is intended for use by authorised personnel
- must be read prior to installation
- must be observed by all who work with the burner and associated system components
- work with the burner may only be carried out by certified installers/ personnel

Enertech AB is not liable for any typographical errors and reserves the right to make design changes without prior notice.

## Safety instructions

- The burner may only be used for its intended purpose in accordance with the product's technical data.
- The burner may only be installed and operated by authorised personnel.
- The product is packaged to prevent damage from occurring during handling. Handle the product with care. Lifting equipment must be used to lift larger packages.
- The products must be transported/stored on a level surface in a dry environment, max. 80% relative humidity, no condensation. Temperature -20 to +60 °C.
- Check that the burner is compatible with the boiler's output range.
- All components must be installed without being bent, twisted or subjected to mechanical or thermal forces which can affect the components.
- The burner must be installed so that it complies with local regulations for fire safety, electrical safety, and fuel distribution.
- The gas outlet from the pressure regulator shall be configured in accordance with applicable regulations and lead to a safe area.
- Make sure when installing the equipment that there is enough space to service the burner.
- Permitted temperature during operation -10 to +60 °C. Max 80% relative humidity, no condensation.
- The installer must ensure that the room has adequate air supply.
- The room must comply with local regulations pertaining to its intended use.
- The installation site must be free of chemicals.
- Burner pipes, fan wheels and air dampers may contain sharp edges.
- The surface temperature of the burner's components can exceed 60 °C.
- Caution: The burner has moving parts, and there is risk of crushing injuries.



- The electrical installation must be professionally carried out in accordance with applicable high voltage regulations, as per Enertech's recommendations.
- Before servicing, shut off the fuel supply and turn off the power to the burner.
- Seal inspections must be performed during installation and servicing to prevent gas leakage.
- Care should be taken by the installer to ensure that no electrical cables or fuel lines are crushed or otherwise damaged during installation or servicing.
- If the boiler is equipped with an access hatch, this must be equipped with a hatch opening switch connected to the burner's safety system.
- When in operation, the burner's noise level can exceed 85 dBA. Use hearing protection.
- The burner must not be put into operation without proper safety and protection devices.
- A Class BE fire extinguisher is recommended.
- It is forbidden to alter the design or use accessories which have not been approved by Enertech in writing.
- Prior to operation, the following points must be checked:
  - fitting and installation work has been completed and approved
  - electrical installation has been correctly performed
  - flue gas ducts and combustion air ducts are not blocked
  - all actuators and control and safety devices are in working order and correctly set



## Actions to take if you smell gas

Turn off the equipment and the boiler. Open windows and doors. Prevent open flames or sparking, e.g. do not turn lights on or off, do not use any electrical appliances, do not use mobile phones. Open windows and doors. Close the gas ball valve. Warn residents; do not use doorbells. Evacuate the building. Notify the installer or gas supplier once the building has been evacuated.

## Burner servicing schedule

Servicing must be carried out once a year or after 3000 hours of operation

Burner	1 year	3000 hrs
Inspection of electrical installation	1 year	3000 hrs
Leakage check	1 year	3000 hrs
Filter	1 year replacement at $\Delta p > 10$ mbar	3000 hrs replacement at $\Delta p > 10$ mbar
Electrodes	Replacement/Cleaning 1 year	Replacement/Cleaning 3000 hrs
Brake disc	Replacement/Cleaning 1 year	Replacement/Cleaning 3000 hrs
Motor	1 year	3000 hrs
Fan wheel	1 Year Replacement when cleaning needed/ imbalance	3000 h Replacement when cleaning needed/ imbalance

## Component replacement intervals

Control system	10 years	250,000 starts
Valve control system	10 years	250,000 starts
Pressure switch	10 years	250,000 starts
Ignition system with flame guard	10 years	250,000 starts
UV flame sensor	10000 hrs	N/A
Gas pressure regulators	15 years	N/A
Gas valve without seal testing	10 years	250,000 starts
Gas valve with seal testing	Replacement upon fault detection	N/A
Gas pressure switch	10 years	250,000 starts
Safety blow-off system	10 years	N/A
Damper motor	N/A	500,000 starts
Contactors	10 years	500,000 starts



The burner and its components must be recycled according to applicable regulations.

## Delivery check

- Make sure everything is delivered and the goods have not been damaged during transit.
- If something is wrong with a delivery, report it to the supplier.
- Transport damage must be reported to the shipping company.

## 2. Technical data BG700


### 2.1 Burners are intended for use at:

- Water heating generators

### 2.2 Dimensions

- Connection 1½-3"

Dimensions stated in mm



Type		Length of burner tube	Flange measure A	Burner tube measure B	Burner tube measure C
<b>BG 700</b>	Standard 1	363	328	220	205
	Standard 2	663	628		


	D	E	F	G	H	I
<b>BG 700</b>	820	410	510	*730	*970	420

\* The above dimensions are max. measurements. Depending on the components used, the measurements may vary.

#### 2.2.1 Heat generator connection dimensions

	K	L	M
<b>BG 700</b>	M14	(Ø 280) Ø320-380	*** (Ø 210) Ø 230

\*\*\*Dimensions when installing blast tubes from the inside of the heat generator



## 2.2.2 Capacity range

Capacity kW	Gas quantity at min. power Nm <sup>3</sup> /h <sup>1)</sup>	Gas quantity at max. power Nm <sup>3</sup> /h <sup>1)</sup>	Max. connection pressure mbar	Min connection pressure mbar
<b>BG 700</b>				
G20 300-1500	31.2	157.1	360	see data plate
G25 300-1500	36.2	183		
G31 380-1650	15,4	67.1		

Lower heat value Hu at normal state 15°C and 1013.25 mbar EN676				
Grade of gas		kWh/Nm <sup>3</sup>	MJ/Nm <sup>3</sup>	kcal/Nm <sup>3</sup>
Natural gas	G20	9.5	34.02	8126
Natural gas	G25	8.2	29.25	6986
Butane	G30	32.5	116.09	27728
Propane	G31	24.6	88.00	21019

Gas quantity and capacity vary according to grade of gas and connection pressure.

## 2.2.3 Appliance categories

Only dry gas is permitted for use


Gerätekatategorien Appliance categories	Versorgungsdrücke Supply pressures	Bestimmungsländer Countries of destination
II <sub>2R/3R</sub>	40-360mBar	"BG, CZ, DE, EE, ES, FR, GR, HU, IS, IT, LU, LV, NO, PT, SI, All countries"
II <sub>2H3P</sub>	40-360mBar	"AT, CH, CY, DK, FI, LT, RO, SE, SK"
II <sub>2H3P</sub>	40-360mBar	GB, IE,
II <sub>2L3P</sub>	40-360mBar	NL, RO
II <sub>2E3P</sub>	40-360mBar	PL
I <sub>2E@</sub>	40-360mBar	BE
I <sub>3P</sub>	40-360mBar	BE



## BG 700

G20, G21 300-1500 kW

G31 380-1650



Do not exceed working field

### 2.2.4 Electric Specification

Burner correspond to IP20





Type	BG 700
Motor	230/400V 10,4/5,4A 50Hz
The recommended main fuse motor	C16A
Control power	1~230V 2,5A 50Hz
Sound	93 dBA ± 0,5 dBA

Measurements according to EN 3746: 2010

Alt.1 The sound level of the burner can be reduced by equipping the burner with silencer. Installation must be done so it does not prevent air supply to the burner.

Alt.2 The burner's noise level can be reduced by connecting the burner's air intake to the air duct that opens into an appropriate location. Installation must be done so it does not prevent air supply to the burner.






## 2.3 Description BG700 M



### Components

- |                         |   |  |
|-------------------------|---|--|
| 1. Flame cone           | 11. Connection gas fittings                   | 19. Indicating lamp                            |
| 2. Flange               | 12. Ignition transformer                      | 20. Switch 0-1                                 |
| 3. Guide bar            | 13. Air damper                                | 21. Time meter (option)                        |
| 4. Fan wheel            | 14. Air damper motor                          | 22. Contactor with thermal overload protection |
| 5. Fan house            | 15. Air pressure switch                       | 23. Control box                                |
| 6. Shrouded disc        | 16. Fuse holder                               | 24. Gas train                                  |
| 7. Ignition electrode   | 17. Change-over switch increase-decrease      | 25. MultiBloc                                  |
| 8. Nozzle               | 18. Change-over switch manually-automatically |  |
| 9. Ionisation electrode |   |  |
| 10. Motor               |   |  |

## 2.4 Description BG700-2



### Components

- |                         |                             |  |
|-------------------------|-----------------------------|--|
| 1. Flame cone           | 10. Motor                   | 19. Indicating lamp Stage I                    |
| 2. Guide bar            | 11. Connection gas fittings | 20. Switch I-II                                |
| 3. Electric panel       | 12. Ignition transformer    | 21. Time meter, stage 1                        |
| 4. Fan wheel            | 13. Air damper              | 22. Time meter, stage 2                        |
| 5. Fan house            | 14. Air damper motor        | 23. Contactor with thermal overload protection |
| 6. Shrouded disc        | 15. Air pressure switch     | 24. Control box                                |
| 7. Ignition electrode   | 16. Fuse holder             | 25. Gas train                                  |
| 8. Nozzle               | 17. Indicating lamp Stage 2 | 26. MultiBloc                                  |
| 9. Ionisation electrode | 18. Switch I-II             |  |

## 3. General instructions

### 3.1 General instructions

The installation of the gas burner must be carried out in accordance with current regulations and standards. The installers of gas burners should therefore be acquainted with all regulations and ensure that the installation complies with the requirements. The installation, mounting and adjustment should be made with the greatest care and only the correct gas should be used.

### 3.2 Installation and maintenance instructions

The maintenance instructions supplied with the burner must be kept at an easily accessible location in the boiler room.

### 3.3 Instructions

The user should be thoroughly instructed in the function of the gas burner and the whole installation. The supplier must instruct the user.

### 3.4 Inspection and maintenance

See service schedule.

### 3.5 Start up

After the burner has been fitted to the boiler and the electric connection, the leakage control, the venting and the electric function test have been carried out, the burner will be ready for start-up.

However, study the sections dealing with adjustments of multi-bloc, combustion air and combustion head. Open the ball valve and switch on the main switch. If the burner starts the actual adjustment can be made.

### 3.6 Commissioning of installation

Control of the combustion. The combustion quality is checked by means of a flue gas analysis device. Adjust the burner to appr. 20%

excess air in accordance with the table. Check the flue gas temperature. Calculate the efficiency. Check also the actual gas volume on the gas meter so that the correct input is achieved.

## 4. Installation

### 4.1 Delivery check

Check that all has been delivered and that the goods have not been damaged during transport. If that is not the case, please notify the delivery company. Transport damages should be reported to the forwarding agency.

### 4.2 Preparations for installation

Check that the measurements and capacity range of the burner are compatible with the boiler. The power ratings on the type plate refer to the min. and max. power of the burner.

### 4.3 Gas supply

For good operating safety, it is important that the gas supply system is installed correctly.

Consider the following:

1. Check that the burner is approved for the gas quality of the installation. If not, please contact the supplier.
2. Check that the gas components of the burner are approved for indicated gas pressure.
3. The gas supply system should be installed in accordance with current standards.
4. Pipe lines should be run so that service on boiler and burner is facilitated.
5. Pipe lines should be run so that eventual contaminants cannot come into contact with the gas components.
6. Gas discharge system must be installed prior to local regulations.


### 4.4 Electric connection

Before starting the electric installation, the main switch must be turned off. If the boiler has a 7-pole and a 4-pole Eurostecker connector, these usually fit directly to the burner. If not, use the connectors included.  
(Refer to connection under Electric equipment)



If an electric connection other than the one recommended by Enertech is used, a risk of damage and injury can arise.

## 4.5 Skeleton diagrams




- 1. Ball valve
- 2. Filter
- 3. Governor
- 4. Pressure gauge with shut-off cock
- 5a. Gas pressure switch, mini
- 5b. Gas pressure switch, maxi
- 6a. Main valve, 2 -stage. When modulating operation is required this valve is equipped with controls for variable opening.
- 6b. Safety valve
- 1)7. Valve proving system
- 9. Air pressure switch
- 10. Gas burner control

Pos. 5b, 7: Components not required according to EN 676.

- 1) Required over 1200 kW according to EN 676.hhh

## 4.6 Skeleton diagram, biogas 2-stage burner



1. Safety valve on-off
2. Gas pressure switch
3. Governor FRS shall be fitted with separate filter
4. Twin solenoid valve
5. Governor pressure
6. Valve proving system (VPS)

Pe Pressure before valve  
Pa Pressure between valves



Adjusting points

- a. Main flow restrictor stage 2 (max load)
- b. Gas pressure adjustment
- c. Main flow restrictor stage 1 (min load)
- d. Hydraulic brake stage 1 to 2

VPS: Standard on burners with an output  $\geq 1200$  kW. Optional on burners with an output  $< 1200$  kW.



## 4.6 Handling and lifting instruction



### Option

The lifting aids we use here are available as accessory, Figure 1



bild 1



## 4.7 Mounting on the boiler

Mount the burner to the boiler using 4 bolts. See technical data for the hole pattern.

To make the fitting process easier, it is possible to separate the burner body from the gas flange with the combustion head and valve assembly in place.

Proceed as follows:


1. Ensure that no power is going to the burner. Break the main current and disconnect the Euro plugs from the burner. NB: If the burner is directly connected, ensure that all components on the burner are without power.
2. Remove the cover plate from the fan housing.
3. Disconnect the electrical cables to the valve assembly and gas damper motor.
4. Undo the screws (B) on both sides.
5. Undo the end stops (C) on the guides.
6. **Disconnect the ignition cable and ionisation cable from the gas nozzle.**
7. Pull out the burner body from the guides and put it in a suitable place.

After separating the burner body and the gas flange, it is easier to mount the gas flange with the burner head and valve assembly to the boiler (loosen the valve assembly if required). Once the gas flange is fitted to the boiler, it is easy to lift the burner body up onto the guides. Assemble the burner in reverse order to its disassembly.



Check the gas tightness.

Service position



For maintenance of the brake plate, nozzles, electrodes etc, when using a long design of the burner tube, you have to remove the nozzle assembly from the connecting pipe and move the assembly backwards in the fan housing (from the boiler).

## 4.8 Inspection of gas nozzle before commissioning

The gas nozzle can easily be inspected by using the guides on the burner.

Proceed as follows:


1. Ensure that no power is going to the burner. Switch off the main power supply and disconnect the Euro plugs from the burner.



If the burner is directly connected, ensure that all components on the burner are without power.

2. Remove the cover plate from the fan housing.
3. Disconnect the ignition cable and ionisation cable for the gas nozzle.
4. Ensure there is enough slack in the electrical cables to the valve assembly and gas damper motor to pull out the burner body in the rear position on the guides. If there is not enough slack the cables can be disconnected.
5. Undo the screw (B) on both sides.
6. Pull out the burner on the guides.
7. Undo the screw(s) (A) on the gas flange.
8. Take out the gas nozzle.
9. See section Gas nozzle

Re-assemble the burner in reverse order to that described above. When re-assembling, make sure that the O-ring located between the gas nozzle and the gas flange is in the correct position when the nozzle is re-fitted.





## 4.9 Leakage control

When making a leakage control of the gas supply system the solenoid valve should be closed. Connect a pressure gauge to the test nipple Pa, see fig. The test pressure in the system should be 1,5x max. inlet pressure or min. 150 mbar. If any leakage, locate the source by means of soapy water or a leak location spray. After tightening repeat the test.


### Electric function test:

Ensure that phase and neutral are not reversed. The gas shut-off cock should be closed. To prevent the gas pressure switch from locking out it should be linked temporarily.

After the main switch has been switched on and the thermostats have been adjusted the pre-purging period begins (30-35sec.). At the end of this period the pre-ignition period starts (0,5-2,5 sec. dependent on the design of the gas control). The gas valve is energized and opens and flame is established. At the end of the safety time (2-3 sec.) the gas control locks out. The solenoid valve and the motor will be "dead". Remove the link from the gas pressure switch after the test is finished.



## 4.10 Gas nozzle



## 4.11 Setting Air damper

### 4.12 Air adjustment

The damper motor turns the damper between three pre-set positions: fully closed, low load, full load. These positions are controlled in the motor by cams of different colours. The black cam controls the gas valve for full load. If the air volume needs changing: Remove the cover of the damper motor and change the position of the cams by turning them with the tools accompanying the burner.

### 4.13 Low load:

Adjust the operating switch to full load (II).

- \* Reduce the air volume: Turn orange cam towards 0°
- \* Increase the air volume: Turn orange cam towards 90°

Adjust the operating switch back to low load and check the air volume.

### 4.14 Full load

Adjust the operating switch to low load.


- Reduce the air volume: Turn red cam towards 0°
- Increase the air volume: Turn red cam towards 90°

If the red cam is moved, change the black cam as much. Adjust the operating switch to low load and check that the correct air volume has been obtained.

Note! The blue cam is the limit position for fully closed damper and it is normally not necessary to change it.

### Releasing button

By pressing the button and snapping it down, the motor will be released and the damper can easily be turned. This function facilitates an exchange of damper motor.



## 5. Setting the burner

### 5.1 Setting the air pressure switch

The air pressure switch should block the burner if the air quantity supplied for combustion is insufficient. The air pressure switch must be set so that, if there is a defective air supply at the burner's max. or min. capacity, it reacts before the monitored pressure falls so much that it results in poor combustion.

Inställningsområde ca:

LGW 10	1-10	mbar
LGW 50	2,5-50	mbar



Be careful when adjusting the air pressure switch; it contains a live component.

Setting for air pressure switch

1. Remove the protective cover, screw (Y).
2. Start the burner.
3. Carefully turn the scale on the air pressure switch clockwise until the air pressure switch stops the burner. **Is the tolerance on the scale for the min. air pressure switch approx.  $\pm 15\%$ ?**
4. Try to find the pressure at which the burner stops for both the minimum and maximum input power by turning the scale. Make a note of the values and then set the air pressure switch on the basis of the highest pressure noted at which the burner stopped.
5. The air pressure switch should be set to a pressure approx. 10–15% lower than the highest noted pressure at which the burner stopped.
6. After setting the air pressure switch, perform repeated starts and run through the burner's set output range several times. This is to ensure the reliable function of the burner. If breakdowns or interruptions occur, the air pressure switch is probably set to a too narrow position.
7. Fit the protective cover, screw (Y).



## 5.2 Setting the min. gas pressure switch

The min. gas pressure switch should react to a burner connection pressure that is too low and in such cases prevent the burner from starting. If the connection pressure to the burner is too low during operation, the min. gas pressure switch should stop the burner. The burner can start again once the connection pressure has risen above the pressure set for the min. gas pressure switch.

Setting for min. gas pressure switch

1. Remove the protective cover, screw (Y).
2. Open the pressure outlet (X) and connect a manometer to measure the connection pressure.
3. Start the burner.
4. Measure and make a note of the connection pressure to the burner during normal operation at the highest input power.
5. Based on the desired connection pressure set, determine the connection pressure at which the gas pressure switch should stop the burner. Set the connection pressure at which the burner is stopped at a level where the burner is stopped before poor combustion occurs.
6. Set the min. gas pressure switch to this value by turning the scale.
7. Check the setting by carefully closing the ball valve while measuring the connection pressure.
8. When the min. gas pressure switch stops the burner, the value measured should then approximately correspond to the setting on the min. gas pressure switch. The tolerance on the scale for the min. gas pressure switch is approx.  $\pm 15\%$ .
9. Open the ball valve.
10. Remove the pressure gauge and close the pressure outlet (X).



Check the gas tightness.

11. Fit the protective cover, screw (Y).



## 6. Gas pressure regulator Type FRS

Nominal diameters

Rp 3/8 - Rp 2 1/2



DN 40 - DN 150



**Never close vent nozzle!**

### Pressure taps


1. Vent plug
2. Connection for external pulse  
G 1/4 screw plug ISO 228, on  
both sides, optional.
3. G 1/4 screw plug ISO 228, in  
inlet pressure range, on both  
sides



Max. operating pressure	500 mbar
Pressure regulator	Class A
Ambient temperature	-15 °C ... +70 °C
Inlet pressure range	5 - 500 mbar
Family	1 + 2 + 3
Outlet pressure range	2,5 - 200 mbar




Dimensions [ mm]



Type	Order	P <sub>max.</sub>	Rp/DN	Dimensions mm								
Weight		Number	mbar	a	b	c	d	e	f	g	h	kg
FRS 507	070 391	500	Rp ¾	100	130	28	165	G¼	G¼	G1/8	245	1,00
FRS 510	070 409	500	Rp 1	110	145	33	190	G¼	G¼	G1/8	310	1,20
FRS 515	058 446	500	Rp 1½	150	195	40	250	G½	G¼	G¼	365	2,50
FRS 520	058 628	500	Rp 2	170	250	47	310	G½	G¼	G¼	450	3,50
FRS 525	083 303	500	Rp 2½	230	285	60	365	G½	G¼	G¼	550	6,00
FRS 5065	058 792	500	DN65	290	285	95	405	G½	G¼	G¼	590	7,50
FRS 5080	079 681	500	DN80	310	285	95	405	G½	G¼	G¼	590	10,00

Do not use unit as lever.



DN						40	50	65	80	100	125	150
Rp		3/8	1/2	3/4	1 1/2	1 1/2	2	2 1/2	--	--	--	--
M <sub>max</sub>		70	105	225	340	610	1100	1600	2400	5000	6000	7600
(Nm)	<	10s										
T <sub>max</sub>		35	50	85	125	200	250	325	400	--	--	--
(Nm)	<	10s										

Adjustment of outlet pressure  
(setpoint adjustment)

Factory setting: Standard spring p 2  
10-30 mbar

#### 1.

1. Unscrew protective cap A.
2. Adjustment (+) Setting spindle B "Turn counter-clockwise" = Increasing outlet pressure (setpoint)

or

#### 2.


Adjustment (-) Setting spindle B  
"Turn clockwise" = Reducing outlet pressure (setpoint)

4. Check setpoint


5. Screw on protective cap A.

6. Attach lead seal (Page 5).

#### 1.




#### 2.




Replace setting spring 3-4

1. Remove protective cap. A. Release spring by turning adjustment spindle B counter clockwise. Turn spindle to stop.
2. Unscrew complete adjustment device B and remove spring C.
3. Insert new spring D.
4. Assemble complete adjustment device and adjust desired off-set.
5. Screw on protective cap A. Stick adhesive label E onto typeplate.
6. Attach lead seal.

#### 3.



#### 4.




## 5.4 Double solenoid valve Type DMV-D.../11 Type DMV-DLE.../11

Nominal widths

Rp 1/2 - Rp 2


Electrical connection IEC 730-1  
(VDE 0631 T1)



Volt	U <sub>n</sub> ~ (AC) 230 V
Valve	2 x Class A
Ambient temperature	-15 °C ... +60 °C
IP	54
Family	1 + 2 + 3
Max. operating pressure	500 mbar

### DMV 505-520/11


Pressure taps 1, 2, 3, 4 Sealing plug



Screw plugs 1,2,3 may also be replaced by a measuring socket

G 1/8 DIN ISO 228.

Concealed connecting bore for system accessories.




## DMV 525/11

Pressure taps 1, 2, 3, 5 Sealing plug

Screw plugs 1,2,3 and 5 may also be replaced by a measuring socket


G 1/8 DIN ISO 228.




1.

2.

1. Loosen screws A and B do not remove. Figs 1 and 2
2. Remove screws C and D. Figs 1 and 2




3.




4.

3. Remove double solenoid valve between the threaded flanges. Figs 3 and
4. After mounting, perform leakage and functional tests.




5.




5. Lead seal Lead seal eye 2 in 1.5 mm dia. sealing valve. Lead seal eye 3 in 1.5mm cap stand headed screw. After setting the requested pressure setpoint:

1. Close protective valve 1.
2. Route wire through 2 and 3, Fig. 2.
3. Press lead around wire ends, keep wire loop short.




$$V_{min. / mini.} > 0.1 \times V_{max. / maxi.}$$

6.




6. DMV - D 507/11 - 525/11 DMV-DLE 507/11 - 525/11 Main flow setting only possible at V1! Set main volume on open valve. Set valve V1 during operation. Check setting values continuously. Smallest setting volume flow:



9. Replacing the solenoid Versions with adjusting plate DMV-D 5.../11 or hydraulic brake DMV-DLE 5.../11

1. Remove hydraulic brake or adjusting plate as described on page 6: "Replacing the hydraulic brake or adjusting disk", steps 1 - 5.
2. Replace solenoid  
Important: Make sure that the solenoid no. and voltage are correct!
3. Remount hydraulic brake or adjusting plate as described on page 6. "Replacing the hydraulic brake or adjusting plate", steps 7 - 11.


7.



7. DMV-DLE Rapid stroke adjustment V start Factory setting DMV-DLE: Rapid stroke not adjusted

1. Unscrew the adjustment cap E from the hydraulic brake.
2. Turn the adjustment cap and use as a tool.
3. Turn a-clockwise = increase rapid stroke (+).


8.



8. Replacing hydraulic brake unit or adjustment plate

1. Switch off firing system.
2. Remove locking varnish from countersunk screw A.
3. Unscrew countersunk screw A.
4. Unscrew socket head screw B.
5. Raise adjustment plate C or hydraulic brake D.
6. Remove sealing plug E
7. Exchange adjustment plate C or hydraulic brake D
8. Screw in countersunk and socket head screw. Only tighten socket head screw so that hydraulic brake can just be turned.
9. Coat countersunk screw A with locking varnish.
10. Leakage test: Pressure tap at sealing plug 2:  
DMV 507-520/11 Pressure tap 2, sealing plug 3: DMV 525/11 p max. = 500 mbar.
11. Perform functional test.
12. Switch on firing system.

## 6.1 Adjustment of gas solenoid valve dungs MVD



### MVD:

1-step valve fast opening with max. flow adjustment.

Protection cover  
Flow adjustment  
Lock nut

### Flow adjustment MVD/5

Remove protection cover 1. Loosen lock nut 3. Turn the flow adjustment screw 2 to the right = gas flow decreases or to the left = gas flow increases. Tighten the lock nut.

## 6.2 Recommended excess air when using default setting

Grade of gas	Excess air flue gases		Max. % CO <sub>2</sub>
	% O <sub>2</sub>	% CO <sub>2</sub> Lambda 1.2	
Natural gas	3-5	≈10	11.9
Propane	3-5	≈11.5	13.9
Butane	3-5	≈11,5	14,1
Liquefied petroleum gas (LPG)	3-5	≈11	13,8

## 6.3 Determining the gas quantity for the system

The heat values indicated are normal values; the heat value varies according to the origin of the gas. For more exact information on values, contact the gas distributor.

Lower heat value Hu at normal state 15°C and 1013.25 mbar EN676

Grade of gas		kWh/Nm <sup>3</sup>	MJ/Nm <sup>3</sup>	kcal/Nm <sup>3</sup>
Natural gas	G20	9.5	34.02	8126
Natural gas	G25	8.2	29.25	6986
Propane	G31	24.6	88.00	21019
Butane	G30	32.5	116.09	27728

### 6.3.1 Example of how to calculate the gas quantity (natural gas G20):

$V_0 =$	Desired quantity of gas	[Nm <sup>3</sup> /h]
$Q =$	Boiler output	[kW]
$H_u =$	Gas heat value	[kWh/Nm <sup>3</sup> ] or [MJ/Nm <sup>3</sup> ] or [kcal/Nm <sup>3</sup> ]
$\eta =$	Boiler efficiency	[%]

Calculation example:

$Q =$  500 kW

$H_u =$  Example A: 34020 MJ/Nm<sup>3</sup>

Example B: 9.5 kWh/Nm<sup>3</sup>

Example C: 8126 kcal/Nm<sup>3</sup>

$\eta =$  90%

$$\begin{aligned}
 \text{Example A} \quad V_{0A} &= \frac{Q \cdot 3600}{H_u \cdot \eta} = \frac{500 \cdot 3600}{34020 \cdot 0.90} \approx 58.8 \text{ Nm}^3/\text{h} \\
 \text{Example B} \quad V_{0B} &= \frac{Q}{H_u \cdot \eta} \approx \frac{500}{9.5 \cdot 0.90} \approx 58.5 \text{ Nm}^3/\text{h} \\
 \text{Example C} \quad V_{0C} &= \frac{Q}{H_u \cdot 0.00116 \cdot \eta} = \frac{500}{8126 \cdot 0.00116 \cdot 0.90} \approx 58.9 \text{ Nm}^3/\text{h}
 \end{aligned}$$

If the barometer reading (altitude), pressure and temperature of the gas deviate significantly from normal values, this must be taken into account as follows:

$$\begin{aligned}
 T &= \text{Temperature of gas at the gas meter} && [^{\circ}\text{C}] \\
 B &= \text{Barometer reading} && [\text{mbar}] \\
 P &= \text{Pressure of gas at the gas meter} && [\text{mbar}] \\
 f &= \text{Factor calculated for multiplication with flow in Nm}^3/\text{h to} && \\
 &\quad \text{arrive at actual flow in Nm}^3/\text{h}. && \\
 V &= \text{Actual flow} && [\text{m}^3/\text{h}] \\
 f &= \frac{273}{273+T} \cdot \frac{B+P}{1013.25}
 \end{aligned}$$



Calculation example:

$$T = 15^{\circ}\text{C}$$

$$B = 945 \text{ mbar}$$

$$P = 15 \text{ mbar}$$

$$f = \frac{273}{273+15} \cdot \frac{945+15}{1013.25} \approx 0.90 \text{ Nm}^3/\text{h}$$

This means that the quantity of gas read from the gas meter should actually be read off as 1.11 . the calculated flow in a normal state.

$$\begin{aligned} V &= V_0 \cdot f \\ V_A &= V_{0A} \cdot f = 58.8 \cdot 0.90 \approx 53 \text{ m}^3/\text{h} \\ V_B &= V_{0B} \cdot f = 58.5 \cdot 0.90 \approx 53 \text{ m}^3/\text{h} \\ V_C &= V_{0C} \cdot f = 58.9 \cdot 0.90 \approx 53 \text{ m}^3/\text{h} \end{aligned}$$

## 6.4 Calculating the quantity of gas supplied

The quantity of gas supplied can be calculated if the system is equipped with a gas flow meter of some type. The procedure here is usually to measure how long it takes for the burner to consume a certain quantity of gas.

To measure:

t = Time for a certain quantity of gas consumed by the burner. [h]

M = Quantity of gas consumed. [m<sup>3</sup>]

V = Actual gas flow [m<sup>3</sup>/h]

$$V = \frac{M}{t} \text{ [m}^3/\text{h]}$$

Calculation example:

$$t = 1 \text{ min } 10 \text{ s}$$

$$M = 450 \text{ dm}^3 \text{ (litre)}$$

$$M = \frac{450}{1000} = 0.45 \text{ m}^3$$

$$t = \frac{1}{60} + \frac{10}{3600} = 0.0194 \text{ h}$$

$$V = \frac{M}{t} = \frac{0.45}{0.0194} \approx 23.2 \text{ m}^3/\text{h}$$

## 6. Service

Whoever carries out service and maintenance on the burner must be authorised to do so. If components need to be replaced, the replacements must be of the same make and type and be approved by the authorities. If the burner is to be used for a different grade of gas, a new adjustment must be carried out. If town gas is to be used, it is also necessary to convert the combustion assembly; in some cases the multi-block or valves and gas train may also need to be changed to a larger type.

### 6.1 Servicing the combustion assembly

Removal and installation

1. Switch off the main power supply and disconnect the Euro plugs from the burner.




If the burner is directly connected, ensure that all components on the burner are without power.

2. Remove the cover and disconnect the ignition cable and ionisation cable from the gas nozzle.
3. Loosen the nuts (B) and pull the burner body out of the guides.
4. Loosen the screw (A); this releases the combustion assembly and allows it to be lifted out.
5. Check and clean the brake plate and gas inlet. If necessary, replace the worn parts.
6. Check the ignition electrode (see chapter Gas nozzle). Replace if necessary.
7. Check the ionisation electrode (see chapter Gas nozzle). Replace if necessary.
8. Fit the combustion assembly in reverse order.
9. Press the burner together and lock using the nuts (B).
10. Fit the Euro plugs and turn on the main power supply.
11. Check/adjust the combustion.



Check the gas tightness.



172 615 17 2018-01-15

## 6.2 Servicing air dampers



### Removal and installation

1. Switch off the main power supply and disconnect the Euro plugs from the burner.



If the burner is directly connected, ensure that all components on the burner are without power.

2. Remove the cover and disconnect the ignition cable and ionisation cable from the gas nozzle.
3. Loosen the nuts (B) and pull the burner body out of the guides.
4. Remove the intake grille at the air intake.
5. Remove the screws (G) securing the damper motor mounting plate.
6. Lift up the damper motor.
7. Clean the air damper (F) and the intake. Lubricate any damper shaft.
8. Re-install the damper motor and mounting plate on the air intake. Ensure that the damper shaft and control arm are connected correctly.
9. Install the intake grille for the air intake.
10. Press the burner together and lock using the nuts (B).
11. Check/adjust the combustion.




## 6.3 Replacement of damper motor, air

### Removal and installation

1. Break the main current and disconnect the Euro plugs from the burner.



**!** If the burner is directly connected, ensure that all components on the burner are without power.

2. Note the connection position of the cables on the damper motor.
3. Disconnect the damper motor cable from the damper motor.
4. Loosen the screws (G) to the damper motor mounting plate.
5. Lift up the damper motor.
6. Remove (H) the control arm from the motor shaft.
7. Remove the screws (I) securing the damper motor to the mounting plate.
8. Remove the damper motor from the mounting plate (I).
9. Install the new damper motor on the mounting plate.
10. Fit the control arm on the damper motor shaft. It is important that the screw is perpendicular to the plane of the shaft.
11. Re-install the damper motor and mounting plate on the air intake. Ensure that the damper shaft and control arm are connected correctly.
12. Connect the damper motor cable.
13. Fit the Euro plugs and turn on the mains power.
14. Check/adjust the combustion.



#### - Releasing button

By pressing the button and snapping it down, the motor will be released and the damper can easily be turned. This function facilitates an exchange of damper motor.



## 6.4 Vibration

Maximum vibration level are 5,0 mm/s

- Check all bolts and nuts for correct torque
- Check fan wheel for damage and contamination. Change when dirty/unbalanced
- Check motor bearings. If worn change motor/bearings

Use lid screw for  
sensor mounting



## 7.5 Flame monitoring and ionisation current check


The standard version of the burner is monitored according to the ionisation principle. The ionisation current should be checked on initial start-up and at each service visit.

The reason for low ionisation current can be leakage current, poor connection to earth, fouling or incorrectly positioned ionisation electrode in the combustion head. Occasionally, an incorrect gas/air mix may result in poor ionisation current. Ionisation current is measured using a microammeter ( $\mu\text{A}$ ) connected in series with the ionisation electrode and gas burner control. Connect the  $\mu$  ammeter according to the diagram. The minimum required ionisation current is shown in the table. In practice, this current must be significantly higher, preferably more than  $10 \mu\text{A}$ . Connection of the  $\mu\text{A}$  instrument is made easier by the fact that all gas burners are equipped with a divisible ionisation cable.

### Technical data


For continuous operation!

Idle voltage at ION-terminals	AC 330-380V
<div style="display: flex; align-items: center;"> <div style="font-size: 2em; margin-right: 10px;">!</div> <div>Protect the ionisation electrode from electric shock!</div> </div>	
Short-circuit current	Max 0,5mA
Min. current for flame detection	Min 6 $\mu\text{A}$
Required current to ensure detection	Min 6 $\mu\text{A}$
Possible detection current	Max 200 $\mu\text{A}$



## 7.6 UV detector

This should not be exposed to temperatures higher than  $60^\circ\text{C}$ . The current passing through the UV detector, when it is lit up, should be at least  $70 \mu\text{A}$  for LFL1. This current can be measured using a multimeter, although this is only necessary if a malfunction is suspected.



## 7. Handing over of the installation

- Make repeated start attempts to ensure that the adjustments function.
- Close the ball valve during operation to check that the gas switch switches off at the set value.
- Remove the hose for the air pressure switch to check that the burner locks out.
- Check that all protective covers and measurement nipples are mounted and fastened.
- Fill out necessary test reports.
- Instruct the persons in charge of the operation on the service and maintenance of the installation and what to do should any troubles occur.
- Inspection and service must be carried out by authorized personnel.



Review and service should be performed by authorised personnel only

## 8. Fault location, functional troubles

Trouble free operation is dependent on three factors: electricity, gas and air supply. Should there be any changes in the ratio between these three factors there is a risk of break downs. It has been proved that most break downs are caused by simple faults. Before calling the service engineer, the following should therefore be checked:

- Is the gas cock open?
- Are all fuses in order and the current switched on?
- Are the thermostats correctly set?
- Are pressostats, overheating protection etc. in operating position and not locked-out?
- Is the gas pressure sufficient?
- Is the gas burner control in start position?
- Has the gas control or the motor protector locked out? - Reset.
- Is the circulation pump in operation?
- Is there a supply of fresh air to the installation?
- If integral components are of a different make from what is stated in this manual, see the enclosed loose-leaf.

# 10. Electric equipment

## 10.1 Safety system


Safety systems must be installed in accordance with regulations that are applicable for the appliance. This may differ according to the process burner are installed in to. Se local regulations for information.

Safety system cables must be run in separate cables outgoing signal must not come in same cable as incoming signal. Signals must be in different harnesses for safety reasons.

Safety system as door switches, water level, pressure, temperature and other safety limiters must be installed in safety loop according to process.



## 10.2 Wiring diagram LFL1....



## 10.3 List of components

A1	Gas burner control		SQN75.494.A21B	X1	Connection terminal board
A3	Valve, leak tester, Dungs VPS 504	S1	Operating switch	X2	Earth terminal
R1	UV-Detector	S2	Operating switch, stage 2	X3	Plug-in contact, burner
F1	Operating fuse	S3	Control thermostat	X4	Plug-in contact, boiler
F2	Operating fuse	S4	Temperature limiter	X5	Plug-in contact, stage 2, burner
F3	Operating fuse	S5	Micro switch for hinged door	X6	Plug-in contact, stage 2, boiler
H1	Lamp, low capacity	S6	Control thermostat, stage 2	X7	Plug-in contact, 3 phase, burner
H2	Lamp, high capacity (optional)	S7	Main switch	X8	Plug-in contact, 3 phase, boiler
K1	Motor contactor with thermal overload protector	S8	Air pressure switch	Y1	Gas solenoid valve 1 MultiBloc
K2	Auxiliary relay	S9	Gas pressure switch	Y2	Gas solenoid valve 2
M1	Burner motor	S10	Gas pressure switch, max	Y3	Safety solenoid valve
M2	Damper Motor L&S	S20	Main switch		
		T1	Ignition transformer		

Mains connection and fuse in accordance with local regulations.

Max loading K1

Connection A1,A2 / 95, 96 / 97, 98 Max 0,2A/15W

### Function

#### 1. Operating switch ON-Thermostat ON-Gas pressure switch ON-Air damper closed.

A control is made that the air pressure switch does not indicate fan pressure. Then the burner motor starts.

#### 2. Air damper motor opens.

The air damper motor opens the damper to max. position. A control is made that the air pressure switch indicates sufficient fan pressure.

#### 3. Air damper motor closes.

The air damper motor closes to min. load position. Then the ignition spark is formed.

#### 4. Main and safety valves open

The gas is ignited. The ionization electrode indicates a flame.

#### 5. The safety time expires.

The ignition spark goes out. The safety time expires. If there is no flame or if for some reason the flame disappears after this time limit, the burner control locks out.

#### 6. Operating position.

The burner is in operating position and can now change over to the capacity controlled by the regulator.

#### 7. Stop.

The operation of the burner can now be interrupted by means of the operating switch or the thermostat.

#### 8. The control locks out.

The red lamp in the control is lit. Restart the burner by pressing the reset button.

## Control programme under fault conditions and lockout indication

### Gas burner control: LFL1....

In the event of fault conditions the fuel supply is always interrupted immediately and, simultaneously, the sequence switch stops and thus the lockout indicator. The symbol appearing above the reading mark indicates the kind of fault:


- ◀ No start, because, e.g., the CLOSE signal has not been supplied to terminal 8 or a contact has not been closed between terminals 12 and 4 or 4 and 5.
- ▲ Interruption of the start-up sequence, because the OPEN signal has not been supplied to terminal 8 from damper motor to switch «max.». Terminals 6, 7 and 14 are under tension until the fault has been remedied.
- P Interruption of the start-up sequence, because the OPEN signal has not been supplied to terminal 8 from damper motor to switch «max.». Terminals 6, 7 and 14 are under tension until the fault has been remedied.
- Lockout due to a fault in the flame supervision circuit.
- ▼ Interruption of the start-up sequence, because the position signal for the low-flame position has not been supplied to terminal 8 by the damper motor. Terminals 6, 7 and 14 are under tension until the fault has been remedied.
- 1 Lockout because no flame signal has been received on completion of the 1st safety time.  
Any flame signal failure after completion of the first safety time also causes the control to go to lockout!
- 2 Lockout, because no flame signal has been received on completion of the 2nd safety time (flame signal of the main flame with interrupted pilot burners).
- █ Lockout, because the flame signal has been lost during burner operation or air pressure failure has occurred.
- ◀ Lockout on completion of control programme sequence due to extraneous light (e.g. flame not extinguished, leaking fuel valves) or due to a faulty flame signal.

#### Technical data

Pre-purge time with full air volume:	31,5 s
Pre-ignition time:	6 s
Safety time:	3 s
Post-ignition time:	3 s
Reset after lock-out	Immediately
Time of re-start:	18 s
Ambient temperature:	-20°C to +60°C
Protective standard:	IP 40

#### Supervision of ionization current

Voltage at the detector electrode	operation: 330V ± 10%
	test: 380V ± 10%
Short circuit current	max. 0,5 mA
<b>Min. required ionization current</b>	6 µA
Recommended range of measuring device	0...50 µA



a - b  
Start-up sequence

b - b'  
"idle steps" up to the self shut-down of the sequence switch

b (b') - a  
Post-purge sequence

## 9.4 Leakage control Dungs VPS 504

### Technical data

Test volume	≤	4,0 l
Pressure increase using motor pumps	≈	20 mbar
Backup (customer supply)		10A fast or 6.3A slow
Fuse integrated in housing, replaceable		T6, 3L 250V (IEC 127-2/111) (DIN41662)
Switching capacity		Operating outputs SO1, SO2, SO4: 4A Fault output T7: 1A Fault output SO4 1, 2, 3, T7: 1A
Release time	≈	10 - 30 s Dependent on test volume and input pressure.
Sensitivity limit		50 l/h
Max. number of test cycles		20 /h

### Program sequence

Idle state: Valves 1 and 2 are closed. Pressure buildup: The internal motor pump increases the gas pressure  $p_g$  in the section by approx. 20 mbar compared with the input pressure at valve V1. During the test time, the integrated differential pressure sensor monitors the test section for leaks. When the test pressure is attained, the motor pump switches off (end of test period). The release time (10-30 s) is dependent on the test volume (max. 4.0 l).

If the test section has no leaks, the contact is released to the control box after approx. 30 s and the yellow LED lights up.


If the test section is leaky or if the pressure increase by + 20 mbar is not attained during the test period (max. 26 s), the VPS 504 generates a fault. The red LED is lit as long as the contact is released by the regulator (heat requirement).

After a short voltage drop during testing or during burner operation, an automatic restart is performed.


Programmer Idle state

Pressure buildup

Operation



## Program sequende schedule



## Electrical connection


### VPS 504 series 02

The VPS 504 is connected in series between the temperature regulator and the control box via a 7-pin plug connector.

Connect the boiler connector to the connector socket of the VPS 504.

For contact assignment of VPS 504 connector and heat generator connector, refer to wiring diagram.

Switching feature: No isolation between operating voltage circuit and control circuit.



# 10. Troubleshooting

## Gas Burner

Conditions favourable to disruption-free operation of the system can only be guaranteed through the interaction between three factors – electricity, gas flow and combustion air. A change in any of these factors may cause disruptions.

It has been shown that a large proportion of disruptions can be attributed to relatively small things. Therefore, before requesting servicing, you should ascertain the following:

1. Are the system's gas taps open?
2. Are the fuses intact and is the power on?
3. Are control devices (room thermostat, boiler thermostat, etc.) correctly set?
4. Is gas pressure to the burner sufficient?
5. Are the burner controls on standby and not locked?
6. Is air supply to the burner adequate?

To facilitate troubleshooting, we have created a table of the most common faults that may arise in a gas burner system and how they should be rectified.

Cause of fault	Action
<b>Burner does not start</b>	
No gas	Make sure all gas taps are open
No power	Check the fuse, thermostat and electrical connections
Burner motor does not start	Motor protection has tripped. Motor faulty.
Burner control faulty	Replace
<b>Burner motor running, no ignition spark at the end of pre-aeration</b>	
No power in the terminals	Check the connector. Replace faulty burner controls
Ignition electrodes in contact with each other or earth	Adjust
Ignition electrode porcelain damaged	Replace the electrodes
Poor connection to cable connectors	Adjust connection
Ignition cables damaged	Replace
Transformer damaged, no power to secondary winding	Replace the transformer
Ignition cable and ionisation cable swapped around	Reconnect
<b>No flame propagation</b>	
Gas solenoid valve faulty	Replace
Gas solenoid valve does not open despite having power	Replace solenoid valve terminals, or entire valve
No power to solenoid valve	Check the connection
No electrical connection through air pressure gauge	Check the air pressure gauge's settings and functions
Ignition load incorrectly set	Increase/decrease gas supply Reduce airflow

Cause of fault	Action
Burner control faulty	Replace
Air pressure gauge incorrectly set or faulty	Check the settings and reset, or replace
No acknowledgement signal due to incorrect adjustment or misalignment of the control motor cams.	Check the settings and realign.
<b>Burner trips after safety time limit despite flame propagation</b>	
No ionisation current or UV cell incorrectly positioned	Adjust ionisation electrode and UV cell Check cables and connectors
Burner control monitor faulty	Replace burner control
Voltage lower than 185 V	Contact an electrician
Ignition electrodes disrupting ionisation current	Adjust ignition electrodes. Re-polarise the transformer
Poor earth connection	Ensure adequate earth connection
Phase and neutral swapped around	Check wiring diagram and change accordingly
<b>Burner trips during pre-aeration.</b>	
Air sensor faulty or incorrectly set	Increase/decrease air setting. Reduce air volume
Ignition load incorrectly set	Increase/decrease gas supply Reduce airflow
Gas pressure too low	Increase pressure. If necessary, contact gas supplier
<b>Pulsations at start-up</b>	
Ignition electrodes incorrectly set	Adjust
Gas pressure too high	Check and adjust using pressure gauge and pressure control valve
Flue gas side blocked	Check the chimney flue
<b>Burner pulsates during operation</b>	
Burner incorrectly set	Adjust
Burner dirty	Clean the burner
Incorrect chimney	Check and modify dimensions if necessary
<b>Burner functioning properly but with occasional blockage</b>	
Ionisation current too low	Check. Must be at least 6 $\mu$ A, but should ideally lie between 8 and 20 $\mu$ A
UV cell incorrectly positioned	Adjust
Voltage drop at certain times	Must not drop below 15% of rated voltage. Contact an electrician if necessary
Incorrectly set or faulty air sensor	Check the settings and reset, or replace
Ignition electrode overload	Replace
Burner control ambient temperature too high	Insulate for heat, Max. 60 °
Ignition spark too weak	Check the transformer
<b>Poor combustion</b>	
Poor draught conditions	Check the chimney

Cause of fault	Action
Flue gas temperature too high	Boiler overloaded Decrease the gas volume, sweep the chimney if necessary
CO <sub>2</sub> content too low	Choke the air supply. Check the boiler for any leakages. Choke the draught if too high
<b>CO content too high</b>	
Surplus air when using natural gas and liquefied petroleum (propane, butane)	Choke the air supply
Poor air supply	Open the air supply. Check flue gas damper
Holes in gas nozzle clogged.	Clean
Poor fresh air intake	Check and increase
Flame at incorrect angle due to combustion head out of position	Check the combustion head and readjust
<b>Condensation build up in boiler and chimney</b>	
Flue gas temperature too low or gas volume too low	Raise the flue gas temperature by increasing gas volume Insulate the chimney



# EU Declaration of conformity

Bentone Gasburners



Certificate No.	Type	Certificate No.	Type
CE-0123CT1269	BFG 1	CE-0123CT1326	BG 550
CE-0123CT1270	STG 120	CE-0123CT1337	BG 600
CE-0123CT1281	STG 146	CE-0123CT1348	BG 650
CE-0123CT1292	BG 300	CE-0123CT1359	BG 700
CE-0123CT1304	BG 400	CE-0123CT1360	BG 800
CE-0123CT1315	BG 450	CE-0123CT1371	BG 950

This declaration of conformity is issued under the sole responsibility of the manufacturer. The object of the declaration described above is in conformity with:

**Gas Appliance Regulation 2016/426/EU**

**Machinery Directive 2006/42/EC**

**EMC 2014/30/EU**

**Restriction of the use of certain hazardous substances (RoHS) Directive 2011/65/EU**

References to the relevant harmonised standards used or references to the other technical specifications in relation to which conformity is declared:

EN 676+A2:2008

(excluded Annex J/K)

Automatic forced draught burners for gaseous fuels

Additional information can be downloaded at:  
[www.bentone.com](http://www.bentone.com)

**Enertech AB**  
Box 309  
S-341 26 LJUNGBY

Ljungby February 15th, 2018

Håkan Lennartsson  
Managing Director  
Enertech AB



# 11. General instructions for gasburners

## 11.4.1 Installation

1. Follow standards and instructions applicable to the installation of gas burners
2. Ensure that the electric installation is made in accordance with existing regulations
3. Check that the fresh air intake of the boiler room is sufficiently dimensioned
4. Check by studying the data plate that the efficiency of the burner is adapted to the boiler output
5. Check that the burner is adapted to the gas quality in question
6. Check that the input pressure of the gas is correct
7. Check that the dampers of the boiler are open
8. Check that there is water in the system
9. Check that thermostats etc. are correctly adjusted
10. Read the instructions and follow the directions given for the burner as to starting-up and service

## 11.4.2 Maintenance

### General instructions

1. Keep the boiler room clean
2. Ensure that the fresh air intake of the boiler room is not restricted
3. Switch off the current and shut off the gas supply if the burner must be withdrawn from the boiler
4. Do not use the boiler for burning paper and waste if there is no special arrangement ( fire room ) for this

### Normal operation

1. Ensure that the air supply to the burner is not obstructed by dust and dirt
2. Have the installer make a yearly overhaul of the installation so that safety is not jeopardized
3. Have the installer at the yearly overhaul also adjust the burner to ensure optimal combustion economy
4. Check periodically that there is water in the system ( fill up if necessary ) and that thermostats etc. are normally adjusted
5. Ensure that there is no water or dampness in contact with the burner

## 11.4.3 If the burner has stopped

1. Press the reset button of the relay
2. Check that the max. thermostat has not cut out
3. Check other thermostats for example room thermostat, if any
4. Check that the gas pressure to the burner is sufficient
5. Check that the electric fuses have not blown
6. Make a new attempt to start the burner and check the counter of the gas meter to find out whether the solenoid valve opens
7. If the burner does not start in spite of repeated starting attempts call the installer

## 11.4.4 Shut-Off

1. Switch off the current with the main switch
2. Shut-off the gas supply with the shut-off cock on the burner

## 11.4.5 Warning

1. Never keep your face in front of the fire room door when starting up the burner
2. Do not use naked flame when inspecting the fire room

Authorized installer::

Address: .....

Telephone: .....



## Service- and inspection card

Installation		Boiler	
Name:		Type:	Efficiency kW:
Address:		Burner	
		Type:	Efficiency kW:
Installed by:		Date:	

Date		Governor		CO <sub>2</sub>	CO	Fluegas temp	Ionisation current	Pressure		Efficiency
	Nm <sup>3</sup> gas/h							Fire room	Chimney	
		Before	After	%	%	°C	μ A	mbar	mbar	%
	Small Flame									
	Large Flame									
	Measures									

Date		Governor		CO <sub>2</sub>	CO	Fluegas temp	Ionisation current	Pressure		Efficiency
	Nm <sup>3</sup> gas/h							Fire room	Chimney	
		Before	After	%	%	°C	μ A	mbar	mbar	%
	Small Flame									
	Large Flame									
	Measures									

Date		Governor		CO <sub>2</sub>	CO	Fluegas temp	Ionisation current	Pressure		Efficiency
	Nm <sup>3</sup> gas/h							Fire room	Chimney	
		Before	After	%	%	°C	μ A	mbar	mbar	%
	Small Flame									
	Large Flame									
	Measures									









